

HOWAY B09991MCMJ (Two Temperatures)

HOWAY Coffee Warmer and Mug Set User Manual

Model: B09991MCMJ (Two Temperatures) | Brand: HOWAY

1. INTRODUCTION

Thank you for choosing the HOWAY Coffee Warmer and Mug Set. This product is designed to keep your beverages at an ideal temperature, ensuring a warm drink throughout your day. This manual provides essential information for the safe and efficient operation of your new device.

What's Included:

- 1 x HOWAY Coffee Warmer Base
- 1 x Ceramic Mug (14 oz capacity) with Wooden Handle and Lid
- 1 x User Manual

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all safety warnings and instructions carefully before use to prevent injury or damage.

- Do not immerse the warmer base in water or any other liquid.
- Ensure the power cord is not damaged and is plugged into a compatible 110V outlet.
- The heating plate and the bottom of the mug become hot during operation. Avoid direct contact with bare skin.
- Keep the device out of reach of children and pets.
- Unplug the warmer when not in use or before cleaning.
- Do not use the mug in a microwave or dishwasher due to its metal base and wooden handle.
- Place the warmer on a stable, flat, heat-resistant surface.

3. PRODUCT OVERVIEW

The HOWAY Coffee Warmer and Mug Set consists of a sleek warming base and a specially designed ceramic mug.



Figure 3.1: The HOWAY Coffee Warmer and Mug Set, featuring a black ceramic mug with a wooden handle on a warming base.

Key Components:

- **Warmer Base:** Features a heating plate and a touch-sensitive power button.
- **Ceramic Mug:** 14 oz capacity, designed with a flat aluminum alloy bottom for efficient heat transfer. It includes a wooden handle for comfortable grip and a wooden lid to help retain heat and prevent dust.

FLAT-BOTTOMED CERAMIC MUG

Metal-flat bottom mug to
conduct heat efficiently



Figure 3.2: Detail of the flat-bottomed ceramic mug and the warmer's heating surface.



Figure 3.3: Product dimensions for the warmer base and mug.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the coffee warmer base on a dry, flat, and stable surface, away from water or heat sources.
3. **Connect Power:** Plug the power cord into a standard 110V electrical outlet.
4. **Initial Cleaning:** Before first use, hand wash the ceramic mug and lid with warm, soapy water and dry thoroughly.

5. OPERATING INSTRUCTIONS

The HOWAY Coffee Warmer is designed for ease of use with smart features to maintain your beverage's temperature.

Power On/Off and Temperature Settings:

- Place the filled ceramic mug onto the center of the warmer base.
- Touch the power button on the warmer base to turn it on.
- This model offers two temperature settings:
 - **Warm Setting:** Approximately 104°F (40°C) - Ideal for milk or oats.
 - **Hot Setting:** Approximately 140°F (60°C) - Ideal for coffee or tea.
- Cycle through the temperature settings by repeatedly touching the power button. The indicator light will change color to reflect the selected setting.
- To turn off the warmer, cycle through the settings until the indicator light turns off, or simply lift the mug from the base.

TWO TEMPERATURE SETTINGS



Figure 5.1: Illustration of the two available temperature settings.

Pressure-Activated Function:

For safety and energy efficiency, the warmer features a pressure-activated sensor. When the mug is lifted from the heating plate, the warmer will enter a low-power standby mode. It will resume heating once the mug is placed back on the plate.

PRESSURE-ACTIVATED POWER



THE HEATING PLATE GOES STANDBY WHEN YOU LIFT UP THE CUP

Figure 5.2: The warmer's pressure-activated standby mode.

Automatic Shut-Off:

The warmer is equipped with a smart auto shut-off feature that activates after 4 hours of continuous operation for added safety and power saving.

Using the Lid:

The included wooden lid helps to retain heat more effectively and prevent dust from entering your beverage. Place the lid on the mug while it is on the warmer for optimal heat retention.

Video Demonstration:

Video 5.1: Official HOWAY video demonstrating the features of the coffee warmer, including its flat-bottom mug, touch controls, pressure activation, and auto shut-off.

6. MAINTENANCE & CLEANING

Proper care ensures the longevity and performance of your HOWAY Coffee Warmer and Mug Set.

- Always unplug the warmer base from the power outlet before cleaning.

- Wipe the warmer base with a soft, damp cloth. Do not use abrasive cleaners or immerse the base in water.
- The ceramic mug and wooden lid should be hand washed only. Do not place them in a dishwasher or microwave.
- Ensure all parts are completely dry before storing or next use.

7. TROUBLESHOOTING

If you encounter any issues with your coffee warmer, please refer to the following common solutions:

Problem	Possible Cause	Solution
Warmer not turning on/no indicator light.	Not plugged in or power outlet issue.	Ensure the power cord is securely plugged into a working outlet.
Beverage not warming.	Warmer not activated or incorrect mug used.	Ensure the warmer is turned on and the mug is properly placed on the heating plate. Only use the provided flat-bottom mug for optimal performance.
Warmer turns off unexpectedly.	Automatic shut-off activated.	This is a safety feature. Simply turn the warmer back on if you wish to continue use.

8. SPECIFICATIONS

- **Capacity:** 14 ounces
- **Voltage:** 110 Volts
- **Wattage:** 20 Watt-hours
- **Maximum Temperature (Beverage):** 140 Degrees Fahrenheit (60 Degrees Celsius)
- **Warm Setting (Beverage):** 104 Degrees Fahrenheit (40 Degrees Celsius)
- **Product Dimensions:** 5.5"L x 4.5"W x 5.1"H (overall)
- **Item Weight:** 1.9 pounds
- **Color:** Black
- **Power Source:** Corded Electric

9. WARRANTY & SUPPORT

The HOWAY Coffee Warmer and Mug Set comes with a **1-year warranty** from the date of purchase,

covering manufacturing defects.

For warranty claims, technical support, or any questions regarding your product, please contact HOWAY customer service through the retailer's platform or the official HOWAY website.

Please retain your proof of purchase for warranty validation.