

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [MELOKEA](#) /

› [MELOKEA Ergonomic Office Chair User Manual](#)

MELOKEA DECHAF007R

MELOKEA Ergonomic Office Chair User Manual

Model: DECHAF007R

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- Always assemble the chair according to the provided instructions.
- Ensure the chair is placed on a flat and stable surface before use.
- Do not exceed the maximum weight capacity of **150 kg (330 lbs)**.
- Keep the chair away from direct heat sources and sharp objects to prevent damage and potential injury.
- Regularly check all bolts and screws to ensure they are tightened.

PRODUCT OVERVIEW

The MELOKEA Ergonomic Office Chair is designed to provide comfort and support for extended periods of sitting. Key features include an adjustable headrest, unique lumbar support, breathable mesh back, and a comfortable seat cushion.



Figure 1: Front view of the MELOKEA Ergonomic Office Chair in red with white frame.



Figure 2: The office chair positioned in a modern office environment, demonstrating its aesthetic integration.

Weight Capacity ≤150 KG



Figure 3: Detailed dimensions of the chair, including height (112.5-119.5cm), width (68cm), seat height (40.5-47.5cm), and seat cushion size (51cm wide, 49cm deep, 10cm thick). Maximum weight capacity is 150 kg.

SETUP AND ASSEMBLY

Assembly is required. Please follow the steps below carefully. It is recommended to assemble the chair on a soft, clean surface to prevent scratches.

- Unpack Components:** Carefully remove all parts from the packaging and lay them out. Verify all components are present against the parts list (not provided in this manual, refer to included assembly guide).
- Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the chair base. Push firmly until they click into place.
- Insert Gas Lift:** Place the gas lift cylinder into the center hole of the chair base.
- Assemble Seat Mechanism:** Attach the seat mechanism to the underside of the seat cushion using the provided screws. Ensure the front of the mechanism aligns with the front of the seat.
- Attach Armrests:** Secure the armrests to the seat cushion using the designated screws.
- Connect Backrest to Seat:** Attach the backrest to the seat assembly. Some users find it easier to attach the lower part of the backrest first, then align the upper part. Ensure all screws

are securely tightened.

7. **Place Assembled Seat onto Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is centered and stable.

Note: For detailed visual instructions, refer to the assembly diagram included with your product packaging.

OPERATING INSTRUCTIONS

This chair offers several adjustment features to customize your seating experience.



Figure 4: Overview of key adjustable features including adjustable headrest, lumbar support, breathable mesh, 10cm cushion, height adjustment, and tilttable design.



Figure 5: Demonstrates the tilt function (90° to 115° recline) and how to adjust the height and lock/unlock the tilt mechanism. Pulling the lever inwards locks the tilt, pulling it outwards unlocks it for height adjustment.

1. Height Adjustment

To adjust the seat height:

- **To raise the seat:** While standing, pull the lever located under the right side of the seat upwards. The seat will rise. Release the lever at the desired height.
- **To lower the seat:** While seated, pull the lever located under the right side of the seat upwards. The seat will lower. Release the lever at the desired height.

2. Tilt Function and Lock

The chair features a tilt mechanism allowing you to recline the backrest.

- **To recline:** Pull the lever located under the right side of the seat outwards to unlock the tilt. Lean back to recline.
- **To lock the tilt:** Push the lever inwards to lock the backrest in an upright position (90 degrees).
- **Adjusting Tilt Tension:** Rotate the round knob located under the front of the seat to adjust the tension of the tilt mechanism. Turn clockwise to increase tension (harder to recline) and counter-clockwise to decrease tension (easier to recline).

3. Adjustable Headrest

The headrest can be adjusted vertically to provide optimal neck support.

- Grasp the headrest and gently pull it upwards or push it downwards to adjust its height. It will click into place at various positions.

4. Lumbar Support

The chair features a unique S-shaped lumbar support designed to conform to the natural curve of your spine, promoting healthy posture.



Figure 6: Illustration of the ergonomic design, highlighting the support provided to the cervical, thoracic, and lumbar regions of the spine.

This support is integrated and adapts to your back as you sit.

Maintenance and Care

Proper maintenance will extend the life of your MELOKEA office chair.

- **Cleaning:**

- For fabric and mesh surfaces, use a soft cloth dampened with mild soap and water. Avoid harsh chemicals or abrasive cleaners.
- Wipe metal and plastic parts with a dry or slightly damp cloth.

- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary.

- **Casters:** Keep casters clean from hair and debris to ensure smooth rolling.

- **Avoid Overloading:** Do not exceed the maximum weight capacity of 150 kg.

- **Storage:** Store the chair in a dry, cool place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not adjust height.	Gas lift issue or lever not engaged.	Ensure the height adjustment lever is fully pulled. If the issue persists, the gas lift may need replacement.
Chair wobbles or is unstable.	Loose screws or uneven surface.	Check and tighten all assembly screws. Ensure the chair is on a flat, level surface.
Casters do not roll smoothly.	Debris caught in casters.	Turn the chair over and remove any hair, dust, or debris from the caster wheels.
Backrest does not recline or lock.	Tilt mechanism locked or tension too high.	Ensure the tilt lock lever is disengaged (pulled outwards). Adjust the tilt tension knob counter-clockwise to loosen.

If the problem persists after attempting these solutions, please contact MELOKEA customer support.

SPECIFICATIONS

Feature	Detail
Brand	MELOKEA
Model Number	DECHAF007R (F007)
Color	Red
Overall Dimensions (L x W x H)	49 x 51 x 120 cm (approx. 19.3 x 20.1 x 47.2 inches)

Feature	Detail
Seat Cushion Dimensions	50 x 49 x 10 cm (approx. 19.7 x 19.3 x 3.9 inches)
Adjustable Height Range	40.5 - 47.5 cm (approx. 15.9 - 18.7 inches)
Weight Capacity	150 kg (330 lbs)
Product Weight	14.1 kg (31.1 lbs)
Materials	Metal, Fabric, Nylon Mesh, Polyurethane Foam
Special Features	Adjustable Headrest, Integrated Lumbar Support, Height Adjustment, Tilt Function, Breathable Mesh Back

WARRANTY AND SUPPORT

MELOKEA is committed to providing high-quality products and excellent customer service.

For warranty information, product support, or if you have any questions or concerns regarding your MELOKEA office chair, please contact our customer service team. While specific warranty details are not provided in this manual, MELOKEA values customer experience and strives to provide the best products and services.




Please refer to the contact information provided with your purchase or visit the official MELOKEA website for the most up-to-date support details.

© 2023 MELOKEA. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.

Related Documents - DECHAF007R

	<p>MELOKEA CHAF043-CHAF008 Desk Chair Assembly and Adjustment Guide</p> <p>Comprehensive assembly instructions and adjustment guide for the MELOKEA CHAF043-CHAF008 desk chair. Learn how to assemble, adjust seat height, backrest, seat depth, headrest, 4D armrests, and tilt resistance for optimal comfort and support.</p>
---	--

 <p>MELKEA DESK CHAIR Model # H045 Assembly Instructions</p>	<p><u>MELOKEA H045 Desk Chair Assembly and Adjustment Guide</u></p> <p>Comprehensive assembly instructions and adjustment guide for the MELOKEA H045 desk chair, covering headrest, armrest, seat height, depth, and recline adjustments.</p>
 <p>MELKEA DESK CHAIR Model # H045 Assembly Instructions</p>	<p><u>Melokea H045 Desk Chair Assembly Instructions</u></p> <p>Comprehensive assembly instructions for the Melokea H045 Desk Chair, covering all adjustment features and safety warnings in multiple languages.</p>
 <p>MELKEA DESK CHAIR Model # CHAF059 Assembly Instructions</p>	<p><u>Melokea CHAF059 Desk Chair Assembly Instructions</u></p> <p>Comprehensive assembly instructions and safety warnings for the Melokea CHAF059 desk chair, provided in multiple languages including English, German, French, Italian, Spanish, and Dutch.</p>
 <p>MELKEA DESK CHAIR Model # CHAE064 Assembly Instructions Customer service email address: CustomerService@CustomChair.com</p>	<p><u>MELOKEA CHAE064 Ergonomic Desk Chair Assembly Instructions User Guide</u></p> <p>Comprehensive assembly instructions and safety guide for the MELOKEA CHAE064 ergonomic desk chair. Includes parts list, step-by-step assembly, and important safety warnings.</p>