

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Starfrit](#) /

› [Starfrit Electric Hand Mixer Model 024226-004-0000 User Manual](#)

Starfrit 024226-004-0000

Starfrit Electric Hand Mixer User Manual

Model: 024226-004-0000

INTRODUCTION

This manual provides instructions for the safe and efficient operation of your Starfrit Electric Hand Mixer, Model 024226-004-0000. Please read all instructions carefully before first use and retain this manual for future reference.



Image: The Starfrit Electric Hand Mixer in white, equipped with beaters, positioned on a white surface. In the background, there are cupcakes and fresh strawberries, illustrating its use in baking.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the mixer.
- To protect against risk of electrical shock, do not immerse the mixer body, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Keep hands and utensils away from beaters during operation to prevent injury to persons and/or damage to the mixer.
- Always operate the mixer with the attachments fully inserted.
- Do not use the appliance for other than intended use.

PACKAGE CONTENTS

Verify that all items are present upon unpacking:

- Starfrit Electric Hand Mixer Unit
- 1 Set of Beaters (2 pieces)
- 1 Set of Dough Hooks (2 pieces)
- Instruction Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the components of your hand mixer:



Image: A detailed diagram of the Starfrit Electric Hand Mixer, highlighting its key components: the release button, the 5-speed variable control, the adjustable cord, and the included beaters and dough hooks.

- **Release Button:** For easy removal of beaters or dough hooks.

- **5-Speed Variable Control:** Adjusts mixing speed from 1 (slowest) to 5 (fastest).
- **Turbo Button:** Provides an instant burst of maximum power.
- **Beater Slots:** Where beaters are inserted.
- **Dough Hook Slots:** Where dough hooks are inserted.
- **Adjustable Cord:** For convenient usage and storage.

SETUP AND FIRST USE

1. **Unpack:** Carefully remove all packaging materials and inspect the mixer for any damage.
2. **Clean Attachments:** Before first use, wash the beaters and dough hooks in warm, soapy water, then rinse and dry thoroughly. The mixer body can be wiped with a damp cloth.
3. **Insert Attachments:**
 - Select the desired attachments (beaters or dough hooks).
 - Insert the stems of the attachments into the appropriate slots on the underside of the mixer until they click into place. Ensure they are securely locked.
4. **Connect Power:** Plug the mixer into a standard electrical outlet.

OPERATING INSTRUCTIONS

Using the Mixer

1. **Prepare Ingredients:** Place ingredients in a suitable mixing bowl.
2. **Select Speed:** With the attachments inserted and the mixer unplugged, set the speed control to the desired setting (1-5). Start with a lower speed to prevent splashing, then gradually increase as needed.
3. **Begin Mixing:** Plug in the mixer. Immerse the attachments into the ingredients before turning the mixer on. Turn the mixer on by sliding the speed control to the desired setting.
4. **Turbo Function:** For an extra burst of power at any speed setting, press and hold the "TURBO" button. Release to return to the selected speed.
5. **Stop Mixing:** Once mixing is complete, slide the speed control to "0" (off) and unplug the mixer from the outlet.
6. **Remove Attachments:** Hold the mixer over the mixing bowl and press the release button to eject the beaters or dough hooks. This allows excess batter to drip back into the bowl.

MULTIPLE APPLICATIONS FOR ALL YOUR MIXING NEEDS

BEAT • WHIP • MIX • KNEAD

FONCTIONS MULTIPLES POUR UNE PRÉPARATION SIMPLE

BATTRE • FOUETTER • MÉLANGER • PÉTRIR



Image: Four separate images demonstrating the Starfrit Electric Hand Mixer's versatility, showing it beating eggs, whipping cream, mixing dry ingredients with butter, and kneading dough.

**5-SPEED VARIABLE CONTROL and TURBO button
for easy operation and caters to your needs
250 W**

**COMMANDÉ À 5 VITESSES VARIABLES et bouton TURBO
pour une utilisation facile et adaptée aux besoins de vos recettes
250 W**



Image: A close-up view of the Starfrit Electric Hand Mixer's handle, clearly showing the 5-speed variable control dial and the "TURBO" button for enhanced power.

RELEASE BUTTON
easily and quickly remove beaters and dough hooks
from the hand mixer without making a mess

BOUTON DE RELÂCHEMENT
permet de retirer facilement et rapidement
les batteurs et les crochets pétrisseurs sans dégâts



Image: A hand demonstrating the use of the release button on the Starfrit Electric Hand Mixer, with red arrows indicating the direction of the button press and the ejection of the beaters.

MAINTENANCE AND CLEANING

Cleaning the Mixer Body

- Always unplug the mixer before cleaning.
- Wipe the exterior of the mixer body with a damp cloth. Do not immerse the mixer body in water or any other liquid.
- Do not use abrasive cleaners or scouring pads, as they may scratch the surface.

Cleaning Attachments

- The beaters and dough hooks are dishwasher safe.
- Alternatively, wash them in warm, soapy water, then rinse thoroughly and dry immediately to prevent water spots or corrosion.

STORAGE

After cleaning, store the mixer and its attachments in a dry place. The mixer features a self-stand design for convenient upright storage.

SELF-STAND DESIGN
for mess-free mixing and convenient storage

CONÇU POUR SE DÉPOSER DEBOUT
afin d'éviter les dégâts et pour un rangement pratique



Image: The Starfrit Electric Hand Mixer demonstrating its self-stand design, standing upright on a surface with the beaters removed and placed nearby, alongside the dough hooks.

ADJUSTABLE CORD CORDON AJUSTABLE



Image: An underside view of the Starfrit Electric Hand Mixer, highlighting its adjustable cord for tidy storage and management.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Mixer does not turn on.	Not plugged in; power outlet malfunction; speed control set to "0".	Ensure the mixer is securely plugged into a working outlet. Check if the speed control is set to a number other than "0".
Attachments are difficult to insert or remove.	Attachments not aligned correctly; release button not fully pressed.	Ensure attachments are aligned with the slots. Press the release button firmly when removing.
Mixer splashes ingredients.	Speed setting too high for initial mixing; bowl too full.	Start mixing at the lowest speed (1) and gradually increase. Use a larger mixing bowl or reduce ingredient quantity.
Mixer overheats during use.	Prolonged use; mixing very thick mixtures.	Allow the mixer to cool down for at least 10-15 minutes. Avoid continuous operation for extended periods, especially with heavy loads.

SPECIFICATIONS

Brand	Starfrit
Model Number	024226-004-0000
Power/Wattage	250 watts
Number of Speeds	5
Material	Stainless Steel (attachments)
Color	White
Product Dimensions	15.01 x 8.31 x 19 cm
Item Weight	1.2 kg
Special Features	Adjustable Speed Control, Adjustable Cord, Compact, Self-Stand Design

WARRANTY AND SUPPORT


For warranty information or technical support, please refer to the warranty card included with your product or visit the official Starfrit website. Keep your purchase receipt as proof of purchase for warranty claims.

Manufacturer: Starfrit

Website: www.starfrit.com



Related Documents - 024226-004-0000

 <p>Starfrit</p> <p>3-IN-1 HAND BLENDER MÉLANGEUR À MAIN 3-IN-1 MEZCLADOR DE MANO 3-IN-1 INSTRUCTIONS POUR L'USAGE ET ENTRETIEN INSTRUCCIONES PARA EL USO Y MANTENIMIENTO INSTRUCTIONS FOR USE AND CARE</p> <p>8.5 x 11.5 in 0.24 lb</p>	<p>Starfrit IM 3-in-1 Hand Blender 24224 User Manual Operation & Safety Guide</p> <p>Comprehensive user manual for the Starfrit IM 3-in-1 Hand Blender (Model 24224). Includes detailed instructions on safety, assembly, operation, cleaning, maintenance, and troubleshooting.</p>
 <p>Starfrit</p> <p>INSTRUCTIONS PASTA AND NOODLE MAKING</p>	<p>Starfrit Pasta and Noodle Machine: Instructions, Dough Recipe, and Usage Guide</p> <p>A comprehensive guide for the Starfrit Pasta and Noodle Machine, covering assembly, operation, a basic dough recipe, colored dough variations, noodle thickness settings, and cleaning instructions. Includes tips for optimal pasta making.</p>
 <p>STARFRIT Nutritional Kitchen Scale Instructions for use</p>	<p>Starfrit Nutritional Kitchen Scale: Instructions for Use</p> <p>User manual and instructions for the Starfrit Nutritional Kitchen Scale, detailing features, specifications, operation, and a comprehensive food code list for nutritional tracking.</p>

 <p>1-LITRE ELECTRIC KETTLE BOUILLONNIER ÉLECTRIQUE 1 LITRE TETERA ELÉCTRICA 1 LITRO INSTRUCTIONS POUR L'USAGE ET L'ENTRETIEN INSTRUCTIONS POUR L'USAGE ET L'ENTRETIEN INSTRUCCIONES DE USO Y MANTENIMIENTO</p> <p>R2 R3 R4</p>	<p><u>Starfrit 1-Litre Electric Kettle - User Manual and Care Instructions</u></p> <p>Comprehensive user manual and care instructions for the Starfrit 1-Litre Electric Kettle (Model 024009), including safety guidelines, operation, cleaning, and warranty information.</p>
 <p>ELECTRIC CAN OPENER OUVRE-BOÎTE ÉLECTRIQUE ABRE-CAJAS ELÉCTRICO INSTRUCTIONS FOR USE AND CARE INSTRUCCIONES DE USO Y MANTENIMIENTO INSTRUCCIONES DE USO Y MANTENIMIENTO</p> <p>R2 R3 R4</p>	<p><u>Starfrit Electric Can Opener User Manual and Safety Instructions</u></p> <p>Comprehensive guide to operating, cleaning, and maintaining the Starfrit Electric Can Opener (Model 024715), including important safety precautions and warranty information.</p>
	<p><u>Starfrit Drum Grater User Guide and Recipes</u></p> <p>Comprehensive user guide for the Starfrit Drum Grater, including assembly, disassembly, cleaning instructions, and recipes for spring rolls, mac and cheese, walnut pie, and iced coffee. Features four interchangeable grating drums for versatile food preparation.</p>