

[Manuals.plus](#) /

› [NISOO](#) /

› NISOO Projector M10 User Manual

NISOO M10

NISOO Projector M10 User Manual

Model: M10

Projector with WiFi and Bluetooth, Upgrade Outdoor Projector, Mini Movie Projector Supports 1080P Synchronize Smartphone Screen by WiFi/USB Cable for Home Entertainment

INTRODUCTION

Thank you for purchasing the NISOO M10 Projector. This manual provides essential information for setting up, operating, and maintaining your projector to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.



Image: The NISOO M10 Projector, a compact white device, is shown alongside a projected image on a screen outdoors and a smartphone mirroring its display. This illustrates its primary function for home entertainment.

What's in the Box

Upon unboxing your NISOO M10 Projector, please verify that all the following items are included:

- NISOO M10 Projector Unit
- HDMI Cable
- Power Cord
- Cleaning Kit
- Remote Control
- User Manual (this document)

SETUP GUIDE

1. Initial Placement and Power Connection

Place the projector on a stable, flat surface. Connect the power cord to the projector's power input and then to a power outlet. Ensure adequate ventilation around the projector.

2. Connecting Devices

The NISOO M10 Projector offers multiple connectivity options for various devices:

- **HDMI:** Connect TV boxes, laptops, PCs, gaming consoles (e.g., PS5), or DVD players using an HDMI cable.
- **USB:** Insert USB flash drives for direct media playback.
- **Micro SD:** Use Micro SD cards for media content.
- **3.5mm Audio Jack:** Connect external audio devices or headphones.

NEW MODEL

NISOO

1080P Support
8000:1 Contrast Ratio

Others

4000:1 Contrast Ratio



Image: The NISOO M10 Projector's side panel displaying its multiple input interfaces including USB, Audio, TF (Micro SD), and HDMI, with icons indicating compatibility with Android/iOS phones, tablets/PCs, TV sticks, and DVD players.

3. WiFi Connection (Screen Mirroring)

The projector supports convenient WiFi connectivity for screen mirroring from your smartphone or other devices. The WiFi connection steps have been updated for ease of use and stability, and connection speed has been improved for quicker pairing.

2.4G+5G Wireless WiFi Screen Mirroring

Faster transmission, more stable



Image: A visual representation of the NISO M10 Projector's 2.4G and 5G wireless WiFi screen mirroring feature, highlighting faster and more stable transmission compared to older technologies.

4. Bluetooth Connection

Enhance your audio experience by connecting external speakers via Bluetooth. This feature significantly improves sound quality to a theater-like experience.

- Use the projector as a Bluetooth speaker to connect with your phone.
- Connect to external speakers or headphones wirelessly for immersive sound.

Two-way Bluetooth Connection

Enjoy an immersive sound quality

- As a bluetooth speaker to connect with your phone
- Connect to the external speaker or headphone wirelessly



Image: The NISOO M10 Projector illustrating its two-way Bluetooth connection, allowing it to connect to a smartphone as a speaker or to external speakers/soundbars for enhanced audio output.

OPERATING INSTRUCTIONS

1. Powering On/Off

Press the power button on the projector or the remote control to turn the unit on or off.

2. Adjusting Projection Size and Distance

The NISOO M10 Projector can achieve a projection size ranging from 32 inches to 200 inches with a projection distance of 1.5m to 5m. For optimal viewing, a 100-inch projection size at a 3m distance is recommended.

Enjoy 200" Large Screen & Eye-protected




Image: A visual guide demonstrating the NISOO M10 Projector's ability to project screen sizes from 32 inches to 200 inches, with recommended distances for each size, emphasizing a 100-inch optimal projection at 3 meters.

3. Keystone and Focus Adjustment

Adjust the keystone correction and focus rings on the projector to achieve a clear and rectangular image. The projector supports $\pm 20^\circ$ vertical keystone correction and a 50%-100% zoom function.

Easy Adjustment In Three Seconds




±20° Vertical Keystone

Image: A diagram illustrating the NISOO M10 Projector's easy adjustment features, including keystone correction to square the image and a zoom function to adjust the screen size from 50% to 100% without moving the projector.

4. Usage Scenarios

The NISOO M10 Projector is versatile and suitable for various home entertainment needs:

- **Home Theater:** Enjoy movies, TV shows, and sports events on a large screen.
- **Video Gaming:** Connect your gaming console for an immersive gaming experience.
- **Online Classes & Educational Content:** Ideal for learning and educational videos in low-light environments.
- **Outdoor Activities:** Its palm-sized design makes it portable for outdoor movie nights.
- **Small Meetings:** Can be used in dark rooms for presentations, but it is not designed as a professional office projector for detailed PPT or text.

Palm-sized Mini Projector

Easy to carry for outdoor/home movie nights



Image: A NISOO M10 Mini Projector set up outdoors, projecting a movie onto a screen for a couple enjoying a movie night, highlighting its portability and suitability for outdoor entertainment.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your NISOO M10 Projector.

- **Cleaning the Lens:** Use the provided cleaning kit or a soft, lint-free cloth specifically designed for optical lenses. Do not use abrasive cleaners or cloths.
- **Cleaning the Exterior:** Wipe the projector's exterior with a soft, dry cloth. Avoid using liquid cleaners directly on the device.
- **Ventilation:** Ensure the projector's ventilation ports are clear of dust and obstructions to prevent overheating. Do not block the vents during operation.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight.

and extreme temperatures.

TROUBLESHOOTING

This section addresses common issues you might encounter with your NISOO M10 Projector.

No Audio from Fire Stick / External Device

If you are experiencing no audio when connecting a Fire Stick or similar streaming device, try the following solutions:

- 1. **Disable Dolby Sound Effects:** On your connected device (e.g., Fire Stick), navigate to its audio settings and turn off Dolby Digital Output or similar sound effects. For Fire Stick, go to **Settings > Display & Sounds > Dolby Digital Output** and turn **Dolby Digital Plus OFF**.
- 2. **Select PCM Option:** In the audio settings of your device, try selecting the**PCM** option for audio output.
- 3. **Check Mute Function:** If your remote control has a mute button, ensure the projector is not muted.
- 4. **Test with Another Device:** Connect a different device (e.g., USB stick, laptop) to the projector to determine if the sound is working properly with other sources.

Cannot Play Certain Videos via Phone Connection (WiFi or USB)

Due to copyright restrictions, some streaming services (such as YouTube, Hulu, Netflix, Amazon Prime Video) may prevent content from being played via direct phone connection (WiFi screen mirroring or USB cable). This is a limitation imposed by the content providers, not a defect of the projector. For these services, it is recommended to use a dedicated streaming device like a TV Stick (e.g., Amazon Fire TV Stick, Roku Stick) connected to the projector's HDMI port.

SPECIFICATIONS

Feature	Detail
Model Number	M10
Brand	NISOO
Manufacturer	Jinhu
Product Dimensions	7 x 5 x 2 inches
Item Weight	2.48 pounds
Display Resolution	1280 x 720 (Supports 1080P input)
Visible Screen Diagonal	100" / 254 cm
Connectivity Technology	3.5mm Jack, Bluetooth, HDMI, USB, Wi-Fi
Recommended Uses	Gaming, Home Cinema
Special Feature	Built-in Wi-Fi, Bluetooth, Keystone Correction, Zoom Function

Multiple Interfaces, All Need Compatible



USB



Audio



Android / iOS phone



Tablet / PC



Video Game



TF



HDMI



TF



TV Stick



DVD Player

Image: A comparison image showing the NISOO M10 Projector as a "NEW MODEL" with 1080P support and an 8000:1 contrast ratio, indicating superior image quality compared to older models or competitors.

WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your NISOO M10 Projector, please refer to the official NISOO customer support channels. You can often find contact details on the product packaging or the official brand website.

A digital version of this user guide is available for download:

[Download User Guide \(PDF\)](#)

You may also visit the official NISOO store for more product information and support:

Visit NISOO
Store

© 2025 NISOO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question