

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Wasserstein](#) /

> [Wasserstein Vertical Adjustable Mount for Google Nest Doorbell \(Battery\) Instruction Manual](#)

## Wasserstein NestDB2VerMtBlkUSA

# Wasserstein Vertical Adjustable Mount for Google Nest Doorbell (Battery)

Instruction Manual

### INTRODUCTION

---

This manual provides detailed instructions for the installation, operation, and maintenance of your Wasserstein Vertical Adjustable Mount for the Google Nest Doorbell (Battery). Please read this manual thoroughly before installation and retain it for future reference.

### WHAT'S IN THE BOX

---

- 1 x Wasserstein Vertical Adjustable Mount
- 1 x Installation Toolkit (screws and anchors)
- 1 x User Manual



made for  
Google Nest



Image: Back view of the Wasserstein Vertical Adjustable Mount, showing its design and mounting points.

## SETUP AND INSTALLATION

The Wasserstein Vertical Adjustable Mount is designed for hassle-free installation. Follow these steps to properly install

your mount and Google Nest Doorbell (Battery).

1. **Prepare the Mounting Surface:** Ensure the surface where you intend to install the mount is clean and suitable for drilling.
2. **Attach the Base Plate:** Use the provided screws and anchors to securely attach the mount's base plate to your desired location on the wall. If your doorbell is wired, feed the wires through the designated opening in the base plate.
3. **Adjust the Angle:** The vertical mount allows for adjustment from 0° to 10°. Position the adjustable part of the mount to achieve your desired vertical viewing angle. Secure the angle by tightening the small screw on the side of the mount.
4. **Mount the Google Nest Doorbell (Battery):** Carefully attach your Google Nest Doorbell (Battery) onto the adjustable mount. Ensure it clicks securely into place.



Image: Hands attaching the Wasserstein Vertical Adjustable Mount to a wall, demonstrating the installation process.

Video: Official video demonstrating the installation and key features of the Wasserstein Vertical Adjustable Mount for Google Nest Doorbell (Battery).

## OPERATION AND ADJUSTING VIEWING ANGLES

The primary function of this mount is to improve the viewing angle of your Google Nest Doorbell (Battery), especially when the doorbell is mounted at a suboptimal height or location. The adjustable design allows you to fine-tune the camera's vertical tilt.

- **Optimized View:** Adjust the mount to direct your doorbell camera downwards, capturing visitors and packages that might otherwise be out of frame.
- **Up to 10° Vertical Adjustment:** The mount provides up to 10 degrees of vertical tilt, allowing for precise positioning.



Image: Side-by-side comparison showing the doorbell's field of view 'Without mount' and 'With mount', highlighting the expanded vertical coverage.



Image: A Google Nest Doorbell (Battery) installed on the Wasserstein Vertical Adjustable Mount, demonstrating an improved viewing angle.

## MAINTENANCE

---

The Wasserstein Vertical Adjustable Mount is constructed from rugged materials designed to withstand harsh weather conditions, ensuring long-lasting performance with minimal maintenance.

- **Cleaning:** Periodically wipe the mount with a damp cloth to remove dust or dirt. Avoid using harsh chemicals that may damage the material.
- **Inspection:** Occasionally check the mounting screws to ensure they remain tight and secure.

## TROUBLESHOOTING

---

If you encounter any issues with your Wasserstein Vertical Adjustable Mount, please refer to the following:

- **Mount is loose:** Ensure all mounting screws are securely tightened. If the issue persists, re-install the mount using appropriate anchors for your wall type.
- **Difficulty adjusting angle:** Loosen the small adjustment screw slightly, reposition the mount to the desired angle, and then re-tighten the screw firmly.
- **Doorbell not fitting:** Verify that your doorbell is a Google Nest Doorbell (Battery) model. Refer to the compatibility section in this manual.

For further assistance, please contact Wasserstein customer support.

## SPECIFICATIONS

<b>Product Name</b>	Wasserstein Vertical Adjustable Mount
<b>Model Number</b>	NestDB2VerMtBlkUSA
<b>Compatible Devices</b>	Google Nest Doorbell (Battery)
<b>Product Dimensions</b>	1.57 x 1.97 x 6.4 inches
<b>Item Weight</b>	3.88 ounces
<b>Color</b>	Black
<b>Mounting Type</b>	Wall Mount
<b>Adjustability</b>	0° to 10° Vertical Adjustment



Image: Compatibility chart displaying a green checkmark for Google Nest Doorbell (Battery) and red crosses for other models.

## WARRANTY AND SUPPORT

This Wasserstein product is designed and manufactured to high-quality standards. It has passed the Made for Google certification, ensuring compatibility and reliability with Google Nest Devices.

- **Return Policy:** A 30-day refund/replacement policy is typically offered for this product. Please check with your retailer for specific return details.
- **Manufacturer:** Wasserstein
- **Support:** For product support, technical assistance, or warranty inquiries, please visit the official Wasserstein website or contact their customer service directly.