

[manuals.plus](#) /

- › [NC](#) /
- › [HF Hongfan Halloween Candy Bag User Manual](#)

NC B099NPZWRF

HF Hongfan Halloween Candy Bag User Manual

Model: B099NPZWRF

1. PRODUCT OVERVIEW

The HF Hongfan Halloween Candy Bag is a portable, decorative item designed for children's Halloween entertainment. It serves as a versatile container for candies, toys, and other small gifts, perfect for trick-or-treating, party favors, or classroom decoration. Its durable, reusable design ensures enjoyment for multiple Halloween seasons.



Image 1.1: Front view of a single Halloween candy bag featuring a pumpkin design.

2. KEY FEATURES

- **Multi-functional Use:** Ideal for classroom decoration, party events, trick-or-treating, or as a gift bag. Can be filled with various items such as Halloween toys, candies, cookies, candy corn, snacks, and small gifts.
- **Child-Friendly Design:** Features an appropriate strap length and lightweight construction, making it easy and comfortable for children to carry.
- **Durable and Eco-Friendly Material:** Constructed from non-woven fabric, ensuring durability and environmental consideration. The bag measures approximately 26x16.5 cm (10.23x6.49 inches).
- **Appealing Aesthetic:** Designed with cute and creative Halloween themes, such as smiling pumpkins, witches, cats, and skulls, to appeal to children.
- **Reusable and Easy to Maintain:** Engineered for repeated use over many years. Simple to store and clean; hand washing and natural drying are recommended.



Image 2.1: A collection of four distinct Halloween candy bag designs.

3. SETUP AND PREPARATION

The Halloween candy bag requires minimal setup. Upon receiving, gently unfold the bag. It is ready for immediate use.

3.1 Filling the Bag

1. Ensure the bag is clean and dry before filling.
2. Open the top of the bag.
3. Carefully place desired items such as candies, small toys, or snacks inside. Avoid overfilling to prevent damage to the bag or its contents.
4. If the bag has a drawstring closure, gently pull the strings to secure the contents.



Image 3.1: Illustration of an open candy bag with contents, alongside other designs.

4. OPERATING INSTRUCTIONS

The Halloween candy bag is designed for simple and direct use.

4.1 Carrying the Bag

- Hold the bag by its integrated strap or handle.
- Ensure the contents are secure, especially when moving.
- For trick-or-treating, present the open bag to receive treats.

4.2 Decorative Use

- The bags can be hung as decorations using their straps.
- They can also be placed on surfaces as festive accents.



Image 4.1: Halloween candy bags displayed as decorative items.

5. MAINTENANCE AND CARE

Proper care ensures the longevity and reusability of your Halloween candy bag.

5.1 Cleaning Instructions

- **Hand Wash Only:** Do not machine wash. Use mild soap and cold water.
- Gently spot clean any soiled areas.
- Rinse thoroughly to remove all soap residue.
- **Air Dry:** Allow the bag to air dry completely in a well-ventilated area, away from direct sunlight or heat sources. Do not tumble dry.

5.2 Storage

- Once completely dry, fold or flatten the bag for compact storage.
- Store in a cool, dry place, away from moisture and pests, to preserve the fabric and design.



Image 5.1: A Halloween candy bag ready for use or storage after cleaning.

6. TROUBLESHOOTING

While the Halloween candy bag is a simple product, here are solutions to common minor concerns:

- **Wrinkles/Creases:** Due to packaging, the bag may have creases. Gently iron on a low setting with a cloth barrier, or allow it to hang for a few days to naturally relax the fabric.
- **Minor Stains:** Refer to the "Cleaning Instructions" in Section 5.1 for spot cleaning. Avoid harsh chemicals.
- **Loose Threads:** If minor loose threads appear, carefully trim them with scissors. Do not pull them.

7. PRODUCT SPECIFICATIONS

Attribute	Detail
Model Number (ASIN)	B099NPZWRF
Brand	NC

Attribute	Detail
Outer Material	Non woven fabric
Dimensions (Approx.)	26 cm x 16.5 cm (10.23 inches x 6.49 inches)
Department	Unisex-child
First Available Date	23 August 2021



Image 7.1: Various designs of the Halloween candy bags, showcasing their form factor.

8. SAFETY INFORMATION

- This product is intended for holding lightweight items. Do not use for heavy or sharp objects that could damage the bag or cause injury.
- Supervise young children when using the bag, especially if it contains small items that could pose a choking hazard.
- Keep away from open flames or extreme heat sources.

- Regularly inspect the bag for any signs of wear or damage. Discontinue use if significant damage is observed.

9. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available documentation. For any product-related inquiries, support, or concerns, please contact the seller or retailer from whom the product was purchased.

Please retain your purchase receipt as proof of purchase for any potential support needs.

© 2024 NC Brand. All rights reserved.

This manual is for informational purposes only.