

[Manuals.plus](#) /

› [Satisfyer](#) /

› Satisfyer Pro 2 Air Pulse Vibrator Instruction Manual

## Satisfyer Pro 2

# Satisfyer Pro 2 Air Pulse Vibrator Instruction Manual

Model: 4009889

## 1. INTRODUCTION

The Satisfyer Pro 2 is an innovative personal wellness device designed for clitoral stimulation using Airpulse technology. This device delivers intense pressure waves across 11 distinct intensity programs, providing a unique and satisfying experience. It features a skin-friendly silicone material and an ergonomic design for comfortable handling.



Image 1: Satisfyer Pro 2 device and its retail packaging.

## 2. SAFETY INFORMATION

- For hygiene reasons, do not share the device with others unless it is specifically designed for multiple users with proper cleaning protocols.
- Keep the device out of reach of children.
- Consult a healthcare professional if you have any medical conditions or concerns before using this device.
- Discontinue use immediately if you experience any discomfort or pain.

## 3. PACKAGE CONTENTS

Your Satisfyer Pro 2 package should contain the following items:

- Satisfyer Pro 2 Air Pulse Vibrator
- Magnetic USB Charging Cable
- Instruction Manual (this document)

## 4. SETUP

---

### 4.1 Charging the Device

Before first use, fully charge your Satisfyer Pro 2. The device uses a magnetic USB charging cable.

1. Connect the magnetic end of the USB charging cable to the charging contacts on the device.
2. Connect the USB end of the cable to a standard USB power source (e.g., computer, USB wall adapter).
3. During charging, a white LED on the power button will flash.
4. The LED will remain steadily lit when the device is fully charged. A full charge typically takes approximately 2 hours.



Image 2: Illustration of the magnetic USB charging cable.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Controls Overview



## Comfortable to Hold and Easy to Use:



### INTENSITY UP

Press to INCREASE the intensity when the device is on



### INTENSITY DOWN

Press to DECREASE the intensity when the device is on



### POWER

Press and hold for 2 seconds to turn the device on/off

Image 3: Location of power and intensity buttons on the device.

- **Power Button ( ):** Press and hold for approximately 2 seconds to turn the device ON or OFF.
- **Intensity Up Button (+):** Press to increase the intensity of the pressure waves.
- **Intensity Down Button (-):** Press to decrease the intensity of the pressure waves.

## 5.2 Using the Device

The Satisfyer Pro 2 utilizes Airpulse technology for touch-free clitoral stimulation. It offers 11 distinct pressure wave intensities.

1. Ensure the device is fully charged.
2. Press and hold the Power Button ( ) for 2 seconds to turn the device ON. It will start at the lowest intensity setting.
3. Gently place the silicone head over the desired area for stimulation, such as the clitoris. The device is designed for external use.
4. Use the Intensity Up (+) and Intensity Down (-) buttons to adjust the pressure wave intensity to your preference. There are 11 programs to explore.

5. To turn the device OFF, press and hold the Power Button ( ) for 2 seconds.



Image 4: Detailed view of the control buttons.

A promotional graphic for Satisfyer. The background is a dark blue gradient. On the right, a blue and white Satisfyer vibrator is shown in profile. On the left, there is a circular graphic with the number '11' and a waveform, surrounded by the text 'INTENSITY PROGRAMS'. The Satisfyer logo is in the top right corner. Below the graphic, there is text describing the device's features.

**Satisfyer**

**11** INTENSITY PROGRAMS

**Enjoy Satisfyer's Patented Air Pulse Technology:**

- Touch-free clitoral stimulation
- Intense pressure waves for ultimate satisfaction

Image 5: Visual representation of the 11 intensity programs and Air Pulse technology.

## 6. MAINTENANCE

## 6.1 Cleaning

The Satisfyer Pro 2 is waterproof, making cleaning simple and hygienic.

1. After each use, clean the device thoroughly with warm water and a mild, toy-safe soap or a specialized toy cleaner.
2. Pay special attention to the silicone head, which can be gently detached for more thorough cleaning if desired.
3. Rinse the device completely to remove any soap residue.
4. Allow the device to air dry completely before storing.



Image 6: Waterproof icon, indicating suitability for water-based cleaning.



Image 7: Silicone material icon, highlighting the skin-friendly material.

## 6.2 Storage

Store the Satisfyer Pro 2 in a clean, dry place, away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent potential damage or reactions.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided magnetic USB cable. Ensure the cable is properly connected to both the device and a power source.
Device does not charge.	Charging cable not connected properly or power source issue.	Verify the magnetic connection is secure. Try a different USB port or power adapter. Ensure the power source is active.
Weak or inconsistent pressure waves.	Low battery or improper placement.	Recharge the device. Ensure the silicone head is placed flush against the skin. Adjust intensity settings.

## 8. SPECIFICATIONS

**Brand:** Satisfyer

**Model Name:** Pro 2

**Item Model Number:** 4009889

**Material:** Skin-friendly Silicone

**Color:** Blue (as per current variant)

**Technology:** Air Pulse Stimulation

**Intensity Programs:** 11

**Waterproof:** Yes

**Charging:** Magnetic USB Rechargeable

**Package Dimensions:** 9.76 x 7.32 x 3.19 inches

**Weight:** 14.46 ounces

## 9. WARRANTY AND SUPPORT

---

The Satisfyer Pro 2 comes with a **15-year warranty**, ensuring long-lasting satisfaction and product reliability. For warranty claims, technical support, or any questions regarding your device, please contact Satisfyer customer service through their official website or the retailer where the product was purchased.

For more information, visit the official [Satisfyer Store](#).