



Manuals.plus /

› Satisfyer /

› Satisfyer Pro 2 Air Pulse Stimulator User Manual

Satisfyer Pro 2

Satisfyer Pro 2 Air Pulse Stimulator User Manual

Model: Pro 2

1. INTRODUCTION

The Satisfyer Pro 2 is an innovative air pulse stimulator designed for clitoral stimulation. It features revolutionary Airpulse technology, offering 11 distinct pressure wave intensities for a unique experience. Constructed from skin-friendly silicone, this device is rechargeable and waterproof, ensuring both comfort and convenience.



Image: The Satisfyer Pro 2 device shown alongside its product packaging.

2. SAFETY INFORMATION

This product is made from body-safe silicone, ensuring it is gentle and non-irritating. While the device is waterproof, it is recommended to avoid full submersion for extended periods. Always use a water-based lubricant with silicone products to prevent material degradation. Statements regarding sexual wellness products have not been evaluated by regulatory bodies and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

3. SETUP

3.1 Charging the Device

Before first use, fully charge your Satisfyer Pro 2. The device uses a magnetic charging cable. Connect the magnetic end of the cable to the charging points at the base of the device. The power button will blink white during charging and remain solid white once fully charged. A full charge typically takes approximately 2 hours.



Image: Icon representing the magnetic charging cable.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

To turn the device **on**, press and hold the power button (circular button) for 2 seconds. To turn the device **off**, press and hold the power button for 2 seconds again.

4.2 Adjusting Intensity

The Satisfyer Pro 2 offers 11 distinct pressure wave intensities. Use the (+) button to increase the intensity and the (-) button to decrease it. Experiment with different settings to find your preferred level of stimulation.

SF

Comfortable to Hold and Easy to Use:



INTENSITY UP

Press to INCREASE the intensity when the device is on



INTENSITY DOWN

Press to DECREASE the intensity when the device is on



POWER

Press and hold for 2 seconds to turn the device on/off



Image: A hand holding the Satisfyer Pro 2, illustrating the power and intensity control buttons.

4.3 Usage

The device utilizes patented Air Pulse Technology for touch-free clitoral stimulation. Place the soft silicone tip over the desired area. It is recommended to experiment with placement and intensity to discover what works best for you. Using a water-based lubricant can enhance the experience.



Image: A diagram showing the air pulse technology emanating from the device's tip.

4.4 Product Demonstration Videos

For a visual guide on product features and usage, please refer to the following demonstration videos:

Video: A detailed review and demonstration of the Satisfyer Pro 2, including its various modes and features.

Video: Demonstration of the Air Pulse Clitoris Stimulator's sucking wave technology.

Video: Overview of the Satisfyer Pro 2's easy charging and 10 modes.

5. MAINTENANCE

5.1 Cleaning

The Satisfyer Pro 2 is made from body-safe silicone and is waterproof, making cleaning simple. Before and after each use, wash the device with warm water and a mild, fragrance-free soap. Rinse it thoroughly to remove any soap residue. Pat it dry with a clean cloth and allow it to air dry completely before storing.

Satisfyer



Image: The Satisfyer Pro 2 demonstrating its waterproof design and easy cleaning.

5.2 Storage

Store the device in a clean, dry place. Its compact and travel-friendly design makes it easy to store discreetly.

6. TROUBLESHOOTING

- **Device not charging:** Ensure the magnetic charging cable is securely connected to the charging points at the base of the device. The power button should blink white to indicate charging.
- **Device not turning on:** The device will not turn on if it is currently charging. Disconnect the charger and then press and hold the power button for 2 seconds. Ensure the device has sufficient charge.
- **Reduced performance:** Ensure the silicone tip is clean and free from debris. If using lubricant, ensure it is water-based. Experiment with different intensity settings and placement.

7. SPECIFICATIONS

Feature	Detail
Model Number	Pro 2
Brand	Satisfyer
Material	Silicone
Water Resistance Level	Waterproof
Style	Air Pulse (Suction)
Intensity Levels	11
Package Dimensions	10.35 x 6.26 x 3.19 inches
Item Weight	14.11 ounces

8. WARRANTY AND SUPPORT

The Satisfyer Pro 2 comes with a **15-year warranty**, ensuring long-lasting satisfaction and product reliability. For any issues, questions, or support needs, please contact Satisfyer customer service. Refer to the product packaging or the official Satisfyer website for contact information.