

PDEEY ELECTRIC-TOOTHBRUSH-CHARGER-CABLE

User Manual: Replacement USB Charger Cable for Fairywill Electric Toothbrushes

Model: ELECTRIC-TOOTHBRUSH-CHARGER-CABLE | Brand: PDEEY

1. INTRODUCTION

Thank you for choosing the PDEEY Replacement USB Charger Cable. This manual provides essential information for the proper use, setup, and maintenance of your new charging cables. Please read this manual carefully before use to ensure safe and efficient operation.

2. PRODUCT OVERVIEW

The PDEEY Replacement USB Charger Cable is designed to provide a reliable power source for compatible electric toothbrushes. This package includes two cables, one black and one white, offering convenience and versatility.

2.1 Key Features

- **USB to DC Round Tip Connector:** Ensures broad compatibility with various USB power sources.
- **Compact and Portable:** Easy to carry for travel or daily use.
- **Dual Pack:** Includes two cables (one black, one white) for convenience and backup.
- **Versatile Charging:** Can be charged via wall chargers, car chargers, AC adapters, power banks, laptops, or PCs.

2.2 Product Components



Image 2.2.1: Two USB to DC round tip charging cables (black and white).

This image displays the two USB charging cables included in the package. Each cable features a standard USB-A connector on one end and a round DC tip connector on the other, designed for charging electric toothbrushes.

Fairywill Toothbrush Charger Cable



Image 2.2.2: Cables in use with Fairywill toothbrushes.

This image illustrates the compatibility of the charging cables with various Fairywill electric toothbrush models. It shows how the cable connects to the toothbrush for charging.

Fairywill USB Cable



Image 2.2.3: Charging a toothbrush via laptop USB.

This image demonstrates the flexibility of charging, showing a Fairywill toothbrush being charged by connecting the USB cable to a laptop's USB port.

3. COMPATIBILITY

These replacement USB charger cables are compatible with a wide range of electric toothbrushes that utilize a DC round tip charging port. Specifically, they are designed for:

- **Fairywill Sonic Electric Toothbrushes:** FW-917, SG-508, FW-507, FW508, FW507 D1, D3, D7, D8, E6, E10, E11, P11 Plus Pro 2001, Kids TB-508, TB-507/BB.
- **Other Compatible Brands:** ut/KIPOZI, Dnsly, Sboly SY-508, SEAGO, WOVIDA, Initio, ATMOKO, and Gloridea electric toothbrushes.

Please ensure your electric toothbrush has a compatible DC round tip charging port before purchasing.

4. SETUP

Setting up your PDEEY USB Charger Cable is simple and straightforward:

1. **Identify the Charging Port:** Locate the DC round tip charging port on your electric toothbrush.
2. **Connect to Toothbrush:** Insert the DC round tip end of the charging cable firmly into the charging port of your electric toothbrush.
3. **Connect to Power Source:** Insert the USB-A end of the charging cable into a compatible USB power source. This can be:
 - A USB wall adapter (e.g., phone charger)
 - A computer or laptop USB port
 - A power bank
 - A car charger with a USB port
4. **Verify Connection:** Ensure both ends of the cable are securely connected. Most toothbrushes will indicate charging status with an LED light.

5. OPERATING INSTRUCTIONS

Once connected, the charging process will begin automatically. The cable acts as a conduit for power, transferring electricity from your USB power source to your electric toothbrush.

- **Charging Time:** Charging time will vary depending on the battery level of your toothbrush and the output of your USB power source. Refer to your toothbrush's original manual for specific charging durations.
- **Charging Indicator:** Monitor the charging indicator light on your electric toothbrush to determine when it is fully charged.
- **Disconnecting:** Once charging is complete, gently disconnect the cable from both the toothbrush and the power source.

6. MAINTENANCE

Proper care and maintenance will extend the lifespan of your charging cables:

- **Cleaning:** Wipe the cables with a soft, dry cloth to remove dust or dirt. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the cables in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cables, especially near the connectors, to prevent damage.
- **Handling:** Always grasp the plug ends when connecting or disconnecting the cables. Avoid pulling on the cable itself, as this can damage the internal wires.
- **Inspection:** Periodically inspect the cables for any signs of wear, fraying, or damage to the insulation or connectors. Discontinue use if any damage is observed.

7. TROUBLESHOOTING

If you encounter issues while using your charging cables, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Toothbrush not charging.	◦ Loose connection. ◦ Faulty USB power source. ◦ Incompatible toothbrush model. ◦ Damaged cable.	◦ Ensure both ends of the cable are securely plugged in. ◦ Try a different USB power source (e.g., another wall adapter, laptop port). ◦ Verify your toothbrush model is listed in the compatibility section. ◦ Inspect the cable for visible damage. If damaged, replace it.
Charging is slow.	◦ Low power output from USB source.	◦ Use a USB power source with higher output (e.g., a dedicated wall charger instead of a laptop port).
Cable feels hot during charging.	◦ Overload or internal short.	◦ Immediately disconnect the cable and discontinue use. Contact customer support if necessary.

8. SPECIFICATIONS

Feature	Detail
Brand	PDEEY
Model	ELECTRIC-TOOTHBRUSH-CHARGER-CABLE
Part Number	ELECTRIC-TOOTHBRUSH-CHARGER-CABLE
Product Type	Electronics
Compatible Devices	Fairywill Electric Toothbrush, Vekkia Electric Toothbrush, Dnsly Electric Toothbrush, Gloridea Electric Toothbrush, and others listed in Compatibility section.
Number of Units	2
Wattage	10 watts
Cable Type	USB
Connector Type	USB to DC Round Tip
Product Weight	41 g
Package Dimensions	17.4 x 10.39 x 1.8 cm
ASIN	B099PJCRZP

9. WARRANTY AND SUPPORT

Specific warranty information and direct customer support contact details are not provided within this manual. For any warranty claims or technical assistance, please refer to the product packaging or contact the seller directly through the

platform where the purchase was made.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question