

## Necchi NHB-8008

# Necchi NHB-8008 Air Fryer Instruction Manual

Model: NHB-8008

## INTRODUCTION

---

Welcome to your new Necchi NHB-8008 Air Fryer. This appliance utilizes rapid air circulation technology to cook food with little to no oil, offering a healthier alternative to traditional frying methods. Please read this manual thoroughly before first use to ensure safe and efficient operation.

## IMPORTANT SAFETY INSTRUCTIONS

---

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions carefully before operating the appliance.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- Keep the appliance out of reach of children. Close supervision is necessary when any appliance is used by or near children.
- Ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Do not block any air vents. Ensure adequate space around the appliance for proper ventilation.
- Do not touch hot surfaces. Use handles or knobs. Always use oven mitts when handling hot components.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The appliance is equipped with overheat protection and a safety switch for added security.

## PRODUCT COMPONENTS

---

Familiarize yourself with the parts of your Necchi NHB-8008 Air Fryer.



**Image 1:** Removable non-stick food basket and grill plate. These components are designed for easy food placement and cleaning.



**Image 2:** Top control panel featuring the temperature and timer dials for precise cooking adjustments.

## BEFORE FIRST USE

---

Follow these steps to prepare your air fryer for its initial operation:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Clean the food basket and grill plate thoroughly with warm soapy water. Rinse and dry completely.
3. Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners.
4. Ensure all parts are completely dry before assembly and use.
5. Place the air fryer on a stable, level, and heat-resistant surface, away from walls or other appliances to allow for proper airflow.

## OPERATING INSTRUCTIONS

---

## General Operation

1. Plug the power cord into a grounded wall outlet.
2. Carefully pull the food basket out of the air fryer.
3. Place your ingredients into the food basket. Do not overfill the basket to ensure even cooking.
4. Slide the food basket back into the air fryer until it clicks securely into place. The appliance will not operate if the basket is not fully inserted.
5. Adjust the temperature control dial to your desired cooking temperature (between 90°C and 200°C).
6. Set the timer dial to the required cooking time (up to 30 minutes). The air fryer will begin heating.
7. During cooking, for best results, pull out the basket halfway through the cooking time and shake the contents to ensure even browning. Then, slide the basket back in.
8. When the timer reaches zero, the appliance will automatically shut off. Carefully pull out the basket and remove the cooked food.

## Temperature and Timer Control

The Necchi NHB-8008 features a temperature range of 90-200°C and a 30-minute timer. These controls allow you to precisely manage the cooking process for various types of food. Refer to recipe guidelines for recommended settings.

## Cooking Tips

- For crispy results, lightly spray or brush food with a small amount of oil.
- Preheating the air fryer for 3-5 minutes can improve cooking performance.
- Smaller food items generally require shorter cooking times.
- Avoid overcrowding the basket to allow hot air to circulate effectively.

## CLEANING AND MAINTENANCE

---

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. The non-stick food basket and grill plate are dishwasher-safe. Alternatively, wash them with warm water and a mild dishwashing liquid. Use a non-abrasive sponge.
3. Wipe the exterior of the air fryer with a damp cloth. Do not use harsh chemicals or abrasive cleaning pads, as they may damage the surface.
4. Clean the interior of the appliance with a damp cloth and a mild detergent if necessary. Ensure no water enters the electrical components.
5. Ensure all parts are completely dry before storing or using the appliance again.

## TROUBLESHOOTING

---

If you encounter any issues with your air fryer, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Food basket is not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Push the food basket firmly into the main unit until it clicks into place.
Food is not cooked evenly.	Basket is overcrowded. Food was not shaken during cooking.	Reduce the amount of food in the basket. Cook in smaller batches. Shake the food basket halfway through the cooking process.
White smoke comes from the appliance.	Cooking fatty food. Residue from previous use.	This is normal for fatty foods. Ensure the basket is clean. Clean the food basket and grill plate thoroughly after each use.
Food is not crispy.	Not enough oil applied. Temperature too low or cooking time too short.	Lightly spray or brush food with a small amount of oil. Increase temperature or cooking time as needed.

## SPECIFICATIONS

Technical details for the Necchi NHB-8008 Air Fryer:

Feature	Specification
Brand	Necchi
Model Number	NHB-8008
Power	1000 Watts
Capacity	2.4 Liters
Dimensions (L x W x H)	22 x 22 x 30 cm
Weight	2.55 Kilograms
Material	Plastic (exterior), Non-stick metal (basket)
Temperature Control	Yes (90-200°C)
Timer	30 minutes
Automatic Shut-off	Yes
Dishwasher Safe Parts	Yes (basket, grill)
Overheat Protection	Yes

## WARRANTY AND SUPPORT

---

For warranty information, technical support, or service inquiries regarding your Necchi NHB-8008 Air Fryer, please refer to the documentation provided at the point of purchase or visit the official Necchi website for contact details and further assistance.