

[Manuals.plus](#) /

› [YUSONIC](#) /

› YUSONIC Unicorn Kids Headphones Instruction Manual

YUSONIC STN-27

YUSONIC Unicorn Kids Headphones Instruction Manual

Model: STN-27

Brand: YUSONIC

1. INTRODUCTION

Thank you for choosing the YUSONIC Unicorn Kids Headphones. These wireless headphones are designed specifically for children, featuring a unique unicorn design with flashing LED lights, comfortable over-ear soft pads, and a built-in microphone for clear communication. They offer a safe listening experience with a 93dB volume limit and stable Bluetooth 5.0 connectivity. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and enjoyment of your headphones.



Image: YUSONIC Unicorn Kids Headphones in white and pink, showcasing the light-up unicorn horn and ears, along with the product packaging.

2. PACKAGE CONTENTS

- YUSONIC Unicorn Kids Headphones (Model: STN-27)
- Charging Cable
- Audio Cable (3.5mm Jack, Detachable)
- User Manual

3. SETUP

3.1 Charging the Headphones

Before first use, fully charge the headphones.

1. Locate the charging port on the headphone earcup.
2. Connect the provided charging cable to the headphone's charging port and the other end to a USB power source (e.g., computer, wall adapter).

-

3.2 Bluetooth Pairing

1. Ensure the headphones are charged and powered off.

2. Press and hold the Power button until the indicator light flashes, indicating pairing mode.
3. On your device, enable Bluetooth and search for available devices.
4. Select "UNICORN HEADPHONES stn27" from the list.
5. Once connected, the indicator light will change (e.g., solid blue), and a voice prompt may confirm the connection.

The Latest Bluetooth 5.0

Ensures stable bluetooth
connection. say goodbye to
Fade in and out problem



Connection Distance

33 feet



Image: The headphones are shown wirelessly connected to a smartphone, demonstrating the Bluetooth 5.0 capability and a stable

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- To Power On: Press and hold the Power button until the indicator light illuminates.
- To Power Off: Press and hold the Power button until the indicator light turns off.

4.2 Volume Control and Track Navigation

The headphones feature button controls on the earcup.

- **Volume Up:** Press the "+" button.
 - **Volume Down:** Press the "-" button.
 - **Next Track:** Long press the "+" button.
 - **Previous Track:** Long press the "-" button.
 - **Play/Pause:** Press the Multi-function button (often the power button or a dedicated play/pause button).
-



Image: A detailed side view of the headphone earcup, highlighting the control buttons for volume, track navigation, and power.

4.3 Flashing LED Lights

The unicorn ears and horn feature flashing LED lights that change color with the rhythm.

- To turn lights ON: Press the "+" button two times quickly.
- To turn lights OFF: Press the "+" button two times quickly again.

4.4 Wired Mode (Optional)

The headphones can be used in wired mode with the provided 3.5mm audio cable, even if the battery is depleted.

- Connect one end of the 3.5mm audio cable to the headphone's audio jack.
- Connect the other end to the audio output jack of your device.

5. MAINTENANCE

- Clean the headphones regularly with a soft, dry cloth.

- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Store the headphones in a cool, dry place when not in use. The foldable design allows for compact storage.
- While the headphones are rated as "Waterproof", avoid submerging them in water or exposing them to heavy rain to prolong their lifespan.
- Do not attempt to disassemble or repair the headphones yourself, as this will void the warranty.



Image: The headphones are shown in their folded configuration, demonstrating the compact design for easy storage and portability.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Bluetooth is off on device; headphones not in pairing mode; too far from device.	Ensure Bluetooth is enabled on your device. Put headphones in pairing mode. Move headphones closer to the device (within 33 feet).

Problem	Possible Cause	Solution
No sound or low volume.	Volume too low on headphones or device; headphones not connected; incorrect audio source.	Increase volume on both headphones and device. Re-pair headphones. Check if the correct audio output is selected on your device.
LED lights not flashing.	Lights are turned off.	Press the "+" button two times quickly to activate the lights.

7. SPECIFICATIONS

Feature	Detail
Model Name	UNICORN HEADPHONES stn27
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth 5.0
Bluetooth Range	10 Meters (33 feet)
Earpiece Shape	Over Ear
Audio Driver Size	40 Millimeters
Sensitivity	94 dB (Volume Limited)
Frequency Response	20 Hz - 20 kHz
Battery Life	15 Hours
Charging Time	1.5 Hours
Headphones Jack	3.5 mm Jack (Detachable Cable)
Material	Acrylonitrile Butadiene Styrene (ABS)
Item Weight	250 Grams (8.8 ounces)
Product Dimensions	6.69 x 3.15 x 9.45 inches
Water Resistance Level	Waterproof

8. WARRANTY AND SUPPORT

For warranty information or technical support, please contact YUSONIC directly. You can often find support contact details on the manufacturer's official website or through the retailer where the product was purchased. Visit the official YUSONIC Store for more information:[YUSONIC Amazon Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B099R7Q5RH>

More documents and user manuals: **<https://manuals.plus/>**