

[Manuals.plus](#) /

› [Fetcoi](#) /

› Fetcoi GR-216B LPG Gas Stove Hob & Sink Combo User Manual

Fetcoi GR-216B

Fetcoi GR-216B LPG Gas Stove Hob & Sink Combo User Manual

Comprehensive instructions for installation, operation, and maintenance.

PRODUCT OVERVIEW

The Fetcoi GR-216B is a compact and efficient 2-burner LPG gas stove and sink combo unit, designed for use in recreational vehicles (RVs), caravans, campers, and boats. This integrated unit provides essential cooking and washing facilities in a space-saving design, featuring a durable tempered glass surface and stainless steel components.



Image: The Fetcoi GR-216B unit, showcasing its two gas burners and integrated sink, designed for compact spaces.

SAFETY INFORMATION

Always read and understand all instructions before installing or operating this appliance. Failure to follow these instructions could result in fire, explosion, property damage, personal injury, or death. This appliance must be installed in accordance with local codes, or in the absence of local codes, with the National Fuel Gas Code, ANSI Z223.1/NFPA 54.

- Ensure adequate ventilation when operating the stove.
- Do not store flammable materials near the appliance.
- Check for gas leaks regularly using a soapy water solution, never an open flame.
- Keep children and pets away from the appliance during operation.
- Turn off the gas supply when the appliance is not in use.

PACKAGE CONTENTS

Upon unpacking, verify that all components are present and undamaged:

- 1 x Fetcoi GR-216B Gas Stove Hob & Sink Combo Unit
- 1 x Stainless Steel Drip Tray
- 1 x Fixed Pot Rack
- User Manual (this document)



GR-216B



Image: The GR-216B unit along with various food items and a camper van, illustrating its intended use and versatility.

SETUP AND INSTALLATION

The Fetcoi GR-216B is designed for drop-in installation. Professional installation by a qualified technician is recommended for gas connections.

Installation Steps:

1. **Prepare the Opening:** Create a cutout in your countertop according to the product dimensions (refer to the Specifications section for exact measurements). Ensure sufficient clearance for ventilation and gas/water connections underneath.
2. **Position the Unit:** Carefully lower the GR-216B unit into the prepared opening. Ensure it sits flush and is stable.
3. **Connect Gas Supply:** Connect the LPG gas supply line to the appliance's gas inlet. Use appropriate gas-rated fittings and ensure all connections are tight. Perform a leak test using soapy water.
4. **Connect Water Supply (for sink):** Connect the water supply and drain lines to the sink. Ensure all water connections are secure and leak-free.
5. **Secure the Unit:** Use appropriate fasteners or clips (not included) to secure the unit to the countertop from underneath, preventing movement during travel.
6. **Install Drip Tray and Pot Rack:** Place the stainless steel drip tray under the burners and position the fixed pot rack securely on the burner grates.



Image: The GR-216B unit shown with a pan on one of the burners, illustrating active cooking, with a camper van in the background.

OPERATING INSTRUCTIONS

Using the Gas Burners:

1. **Ensure Gas Supply:** Confirm that the LPG gas supply is turned on.
2. **Ignition:** Push and turn the desired burner knob counter-clockwise to the "Ignite" position. You should hear a clicking sound as the igniter sparks.
3. **Flame Adjustment:** Once the flame ignites, continue to hold the knob for a few seconds to allow the thermocouple to heat up. Release the knob and adjust the flame intensity by rotating the knob between the high and low settings. The multi-level fire adjustment allows precise control for various cooking needs.
4. **Turning Off:** To turn off the burner, rotate the knob clockwise to the "Off" position. Ensure the flame is extinguished.

Note: The fixed pot rack ensures stability for cookware during use, enhancing safety and convenience.



Image: A top-down perspective of the GR-216B unit, featuring various prepared dishes and a camper van, highlighting its utility for diverse culinary tasks.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and safe operation of your Fetcoi GR-216B unit.

Cleaning the Glass Panel:

- Allow the glass panel to cool completely before cleaning.
- Wipe the tempered glass surface with a soft cloth and a mild detergent or glass cleaner.
- Avoid abrasive cleaners or scouring pads, as they can scratch the glass.

Cleaning the Stainless Steel Drip Tray and Burners:

- Remove the pot rack and burner caps/grates.
- The stainless steel drip tray can be easily removed for cleaning. Wash with warm soapy water.
- Clean burner caps and grates with warm soapy water. Ensure they are completely dry before reassembling.

- Periodically check burner ports for blockages and clean with a small brush if necessary.



Image: A direct front view of the Fetcoi GR-216B, highlighting its sleek design and compact form factor.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Burner does not ignite.	No gas supply; Igniter dirty or blocked; Loose connection.	Check gas cylinder and valve; Clean igniter and burner ports; Check gas line connections.
Flame is weak or uneven.	Low gas pressure; Partially blocked burner port; Incorrect burner cap placement.	Ensure adequate gas supply; Clean burner ports; Re-seat burner cap correctly.
Gas smell detected.	Gas leak.	Immediately turn off gas supply. Ventilate area. Do not operate appliance. Check all connections with soapy water. If leak persists, contact a qualified technician.
Water leak from sink.	Loose water connections; Damaged seal.	Check and tighten all water supply and drain connections. Inspect seals for damage and replace if necessary.



Image: An angled view of the GR-216B, providing a clear perspective of both the gas burners and the integrated sink.

SPECIFICATIONS

Brand:	Fetcoi
Model:	GR-216B
Installation Type:	Drop-In
Burner Type:	Open
Number of Heating Elements:	2
Control Console:	Knob
Fuel Type:	Liquefied Petroleum Gas (LPG)
Material:	Stainless Steel (body, drip tray), Tempered Glass (heater surface)
Product Dimensions (D x W x H):	13.39" x 31.1" x 5.12"
Special Features:	Three-dimensional air intake structure, multi-protection technology, fixed pot rack
Included Components:	Gas Stove, Stainless Steel Drip Tray, Fixed Pot Rack



Image: A detailed close-up of the GR-216B, focusing on the sink and one of the burners, showing the quality of materials.

WARRANTY AND SUPPORT

For warranty information and technical support, please contact Fetcoi customer service. Keep your purchase receipt as proof of purchase.

While specific warranty terms are not detailed in this manual, general product warranties typically cover manufacturing defects for a limited period from the date of purchase. Please refer to the product packaging or the manufacturer's official website for the most current warranty policy and contact information.

For assistance with installation, operation, or troubleshooting beyond the scope of this manual, it is recommended to consult a qualified professional or contact Fetcoi support directly.