

[Manuals.plus](#) /

> [Ollny](#) /

> Ollny 400LED 132FT Christmas Tree Lights Instruction Manual

Ollny HG-29V401C

Ollny 400LED 132FT Christmas Tree Lights Instruction Manual

PRODUCT OVERVIEW

This manual provides detailed instructions for the safe and efficient use of your Ollny 400LED 132FT Christmas Tree Lights. Designed for both indoor and outdoor decoration, these lights feature multiple lighting modes, timer functions, and adjustable brightness, all controllable via a remote.



Image: Olny 400LED 132FT Christmas Tree Lights illuminating a festive indoor scene with a family.

WHAT'S INCLUDED

Your package should contain the following items:

- 1x 400 LED Warm White Christmas String Lights
- 1x Remote Controller with battery
- 1x Controller box
- 1x UL Plug
- 1x User Manual

Image: Olny 400 LED Christmas Lights Package Contents including string lights, remote, plug, and manual.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the string lights and all components from the packaging.
2. **Placement:** Determine your desired location for the lights. These lights are suitable for both indoor and outdoor use. Ensure the power adapter is placed in a dry location, especially for outdoor installations.
3. **Installation:** Gently unroll the string lights. Avoid excessive pulling or tangling to prevent damage to the wires or LEDs. Secure the lights using appropriate clips or ties, ensuring they are stable and not a tripping hazard.
4. **Connect Power:** Plug the UL-certified adapter into a standard power outlet.
5. **Test:** Before final placement, plug in the lights to ensure all LEDs are functioning correctly.

Ollny Super Long Christmas Lights

400 LEDs

132 FT



400LED 132FT Christmas Lights with Remote

132 FT

9.8 FT



Image: Ollny 400 LED Christmas Lights illuminating a family gathering.

Why choose ollny



Ollny

Remote Control ✓

Bright LED Beads ✓

Durable PVC Wire ✓

P44 Waterproof ✓

No Remote

Dim LED Beads

Thin Copper Wire

No Waterproof



Traditional

Image: Ollny 400 LED Christmas Lights decorating an outdoor fence and house exterior.

OPERATING INSTRUCTIONS

Your Ollny Christmas lights come with a remote control for convenient operation. Ensure the remote's battery (CR2032, included) is properly installed.

Remote Control Functions:

- **ON/OFF:** Power the lights on or off.
- **Timer:** Select from 4H, 6H, or 8H timer settings. The lights will automatically turn off after the set duration and turn on again at the same time the next day.
- **8 Lighting Modes:** Cycle through various effects including Steady On, In Waves, Sequential, Slo-glo, Chasing Flash, Fade, Twinkle Flash, and Combination.
- **Brightness Adjustment:** Use the DIM buttons to increase or decrease the brightness (4 levels available).
- **Memory Function:** The lights will remember your last selected mode and brightness setting when turned back on.



Image: Ollny 400 LED Christmas Lights remote control with various buttons for modes, timer, and dimming.

Video Demonstration: Lighting Modes

Your browser does not support the video tag.

Video: This video demonstrates the 8 different lighting modes available with the Ollny 400LED Christmas Lights, showcasing their dynamic effects in a warm white setting.

Video Demonstration: Brightness Levels

Your browser does not support the video tag.

Video: This video illustrates the 4 adjustable brightness levels of the Ollny 400LED Christmas Lights, showing how to customize the intensity of the illumination.

SAFETY AND MAINTENANCE

- **Low Voltage:** These lights operate at 29V, making them cool to the touch and safe for use around children and pets.

- **Waterproof Design (IP44):** The lights are rated IP44 waterproof, protecting them against splashing water from any angle. This makes them suitable for outdoor use in various weather conditions, including rain and snow. However, ensure the power adapter is kept dry.
- **Storage:** When not in use, carefully coil the lights and store them in a cool, dry place to prevent tangling and damage.
- **Cleaning:** Wipe the lights gently with a soft, dry cloth if cleaning is necessary. Do not use harsh chemicals or abrasive materials.



Safe to Touch

Image: Ollny 400 LED Christmas Lights, safe to touch, with a child interacting with them.



Image: Ollny 400 LED Christmas Lights with IP44 waterproof rating, shown in rain.

TROUBLESHOOTING

- **Lights Not Turning On:**

- Ensure the power adapter is securely plugged into a working outlet.
- Check if the remote control battery is functional and correctly inserted.
- Verify that the remote control is pointed directly at the receiver on the plug/controller box. The remote has a limited range and requires direct line of sight.

- **Remote Not Responding:**

- Replace the CR2032 battery in the remote control.
- Ensure no obstructions are between the remote and the receiver.

- **Connecting Multiple Strands:** These lights are designed as a single, long strand. They are not designed to be connected in series with other light strands. Connecting multiple strands may cause dimming or malfunction.

SPECIFICATIONS

Feature	Detail
Brand	Ollny
Model Number	HG-29V401C
Color	Warm White
Number of LEDs	400
Length	132 Feet (40 Meters)
Extension Cord Length	10 Feet
Power Source	Corded Electric
Voltage	29 Volts
Wattage	6 Watts
Special Features	8 Lighting Modes, Timer Function, 4 Brightness Levels, Memory Function, Remote Controlled, Waterproof (IP44), UL Certified
Indoor/Outdoor Usage	Indoor, Outdoor
Material	Plastic
Controller Type	Remote Control
Remote Battery	1 CR2032 (included)

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided in the included user manual or visit the official Ollny website. Keep your purchase receipt for any warranty claims.

Video: Ollny 400LED Outdoor Indoor Christmas Lights

Your browser does not support the video tag.

Video: This video showcases the versatility of the Ollny 400LED Christmas Lights for both outdoor and indoor decoration, highlighting their warm white glow in various festive settings.

