#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- > VMAI /
- > VMAI Handle Cordless Electric Mop, for P700 Electric Mop User Manual

# **VMAI P700**

# **VMAI Handle Cordless Electric Mop Instruction Manual**

Model: P700

# PRODUCT OVERVIEW

This manual provides detailed instructions for the VMAI Handle Cordless Electric Mop, designed specifically as a replacement or accessory for the P700 Electric Mop. It covers essential information regarding setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your product.





Image: The VMAI Cordless Electric Mop Handle, showcasing its ergonomic design and metallic black finish.

# **SAFETY INFORMATION**

Please read all safety instructions carefully before using the product. Failure to follow these instructions may result in injury or damage to the product.

- Keep out of reach of children and pets.
- Do not attempt to modify or repair the handle. Contact customer support for assistance.
- Ensure the handle is securely attached to the P700 Electric Mop before each use.
- Store the handle in a dry place when not in use to prevent damage.

# PACKAGE CONTENTS

Verify that all items are present in the package:

• 1 x VMAI Handle Cordless Electric Mop (compatible with P700 Electric Mop)

# **SETUP**

# Attaching the Handle to the P700 Electric Mop

- 1. Unpack the VMAI Handle and the included screws from the packaging.
- 2. Align the base of the handle with the designated attachment point on your P700 Electric Mop unit.
- 3. Insert the provided screws into the pre-drilled holes on the handle and the mop unit.
- 4. Tighten the screws firmly using a suitable screwdriver until the handle is securely fastened. Avoid overtightening to prevent damage.



Image: A user demonstrating the VMAI Electric Mop in action, highlighting the handle's ability to reach under furniture for effective cleaning.

# **OPERATING**

# **Using the Keyless System**

The VMAI Handle features a keyless system for simplified usage. Once attached, the handle integrates seamlessly with your P700 Electric Mop's existing controls and functionality.

- To power on/off the mop, utilize the power button located on the main mop unit. The handle does not contain separate power controls.
- The handle provides an ergonomic grip and precise control for guiding the mop during cleaning tasks.
- Adjust the angle of the mop head by tilting the handle as needed to clean various surfaces and reach difficult areas, such as under furniture.

# **M**AINTENANCE

# Cleaning and Storage

- Wipe the handle with a soft, damp cloth to remove any dust or dirt. Do not use harsh chemicals or abrasive cleaners, as these may damage the finish.
- Ensure the handle is completely dry before storing to prevent moisture damage.
- Store the mop with the handle attached in an upright position in a cool, dry place, away from direct sunlight and extreme temperatures.

#### **Troubleshooting**

Problem	Possible Cause	Solution
Handle feels loose after installation.	Screws are not tightened sufficiently.	Retighten the screws firmly. If the issue persists, inspect the screw holes and screws for any damage or stripped threads.
Difficulty attaching the handle.	Misalignment or incorrect screws used.	Ensure correct alignment with the P700 Electric Mop's attachment point. Use only the screws provided with the handle.

#### **SPECIFICATIONS**

• Model: P700 (Handle for P700 Electric Mop)

• Brand: VMAI

• Material: High-quality Aluminum

• Color: Metallic Black

• Special Features: Easy to Install, Keyless System

• Item Weight: 6.4 ounces

Package Dimensions: 12.09 x 6.42 x 3.27 inches

#### WARRANTY AND SUPPORT

VMAI products typically come with a standard manufacturer's warranty. For specific warranty details pertaining to your VMAI Handle or the P700 Electric Mop, please refer to the warranty card included with your original product purchase or visit the official VMAI website.

For technical support, inquiries about replacement parts, or any other assistance, please contact VMAI customer service:

- Website: VMAI Official Store on Amazon
- **Email:** Please refer to your product packaging or the VMAI official website for the most current customer service email address.

© 2024 VMAI. All rights reserved.

#### **Related Documents - P700**



#### VMAI S5 2.0CH Soundbar User Manual

Instruction manual for the VMAI S5 2.0CH Soundbar, covering safety instructions, setup, operation, troubleshooting, and technical specifications.



#### VMAI 2.1 Channel Sound bar (Vmai X-bar) User Manual and Setup Guide

Comprehensive user manual for the VMAI 2.1 Channel Sound bar, model Vmai X-bar. Includes setup instructions, safety precautions, remote control guide, troubleshooting tips, and technical specifications for optimal home theater audio.




#### VMAI Soundbar 2.0CH User Manual

User manual for the VMAI Soundbar 2.0CH, model Vmai S5. Includes safety instructions, setup, operation, and troubleshooting.



#### VMAI 120W Soundbar Instruction Manual

Instruction manual for the VMAI 120W Soundbar, covering important safety instructions, setup, operation, remote control usage, and troubleshooting.



#### VMAI FS21HS-L Soundbar User Manual and Operating Instructions

Comprehensive user manual for the VMAI FS21HS-L soundbar, detailing remote control functions, setup, various connectivity modes (Bluetooth, AUX, USB, TV ARC, Optical), and FCC compliance information. Includes troubleshooting for smart TV app audio issues.



# Halcyon P700 4KNS LED High Bay Installation Guide

Step-by-step installation instructions for the Halcyon P700 4KNS LED High Bay light, including power settings and safety warnings.

#### Documents - VMAI - P700



#### Laptop Direct & ComX Computers Price Guide

Explore the comprehensive price guide from Laptop Direct & ComX Computers, featuring a wide array of products including electronics, appliances, and accessories. Find detailed product information and pricing.

lang:en score:17 filesize: 7.37 M page\_count: 2083 document date: 2023-07-20