ChooChoo ChooChoo-ET

ChooChoo Side Table with Drawer and Shelf - Assembly and Care Manual

Model: ChooChoo-ET

Introduction

Thank you for choosing the ChooChoo Side Table. This manual provides detailed instructions for the assembly, operation, and maintenance of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Information

Important Safety Guidelines:

- Always follow the assembly instructions carefully.
- Keep small parts out of reach of children to prevent choking hazards.
- Do not exceed the maximum weight recommendation of **45 pounds (20.4 kg)** for the table.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten fasteners as needed.

Assembly Instructions

The ChooChoo Side Table is designed for straightforward assembly. An assembly guide is included in the packaging. Each piece of wood and part is numbered to facilitate the process. Assembly typically takes approximately 30 minutes with one person.

Recommended Tools:

- Screwdriver (manual recommended; power tools should be used with caution at low torque to avoid overtightening or damage).

General Assembly Steps:

1. Unpack all components and verify against the included parts list.
2. Follow the step-by-step diagrams in the assembly guide.
3. Assemble the main frame of the table, ensuring all cam locks and screws are tightened.
4. Install the drawer slides onto the side panels and then assemble the drawer box.
5. Insert the drawer into the assembled frame.

6. Attach the bottom shelf and any other structural elements as indicated.



Figure 1: Product Dimensions. Overall dimensions are approximately 23.62"L x 11.22"W x 24.02"H. Drawer size is approximately 3.85"H x 6.96"W x 12.4"L.

Operating Instructions

The ChooChoo Side Table features a functional drawer and two open shelves, providing versatile storage and display options.

Drawer Functionality:

The integrated drawer is suitable for storing small items such as remote controls, chargers, or personal accessories, keeping your living space tidy. To open, gently pull the knob. To close, push the drawer back until it is flush with the table frame.



Figure 2: Side table with drawer open, displaying storage capacity.

Shelf Usage:

The two open shelves below the drawer offer additional space for books, magazines, decorative items, or small plants. These shelves are designed for easy access and display.



Figure 3: Close-up of shelves with decorative items.



Figure 4: Side tables positioned next to a sofa.

Maintenance

To maintain the appearance and longevity of your ChooChoo Side Table, follow these simple care instructions:

- **Cleaning:** Wipe the surface with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Immediately wipe up any spills with a dry cloth to prevent staining or water damage.
- **Fasteners:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Placement:** Avoid placing the table in direct sunlight or near heat sources to prevent warping or discoloration.

Troubleshooting

If you encounter any issues with your ChooChoo Side Table, consider the following common solutions:

- **Wobbly Table:** Ensure all screws and cam locks are fully tightened. Check that the table is placed on a level surface. Adhesive pads are included to protect floors and can help stabilize the table.
- **Drawer Not Sliding Smoothly:** Verify that the drawer slides are correctly installed and aligned. Ensure all small black screws on the rails are flush and securely tightened. Sometimes, slight adjustments to the rail placement can resolve this.
- **Difficulty with Screw Insertion:** Some pre-drilled holes may be tight. Apply firm, steady pressure while turning the screwdriver. Avoid using excessive force that could strip the screw head or damage the wood.
- **Missing or Damaged Parts:** If any parts are missing or damaged upon arrival, please contact customer service for assistance.

Specifications

Feature	Detail

Brand	ChooChoo
Model Name	ChooChoo-ET
Product Dimensions (L x W x H)	23.6" x 11.2" x 24" (59.99 cm x 28.49 cm x 60.96 cm)
Item Weight	24.8 lbs (11.25 kg)
Maximum Weight Recommendation	45 pounds (20.4 kg)
Frame Material	Engineered Wood (P2 MDF)
Color	Farmhouse White (with brown top, if applicable to variant)
Number of Drawers	1
Number of Shelves	1 (adjustable)
Assembly Required	Yes
Recommended Assembly Time	0.5 hour (30 minutes)
Product Care Instructions	Wipe with Dry Cloth

Customer Support

If you have any questions regarding the assembly, operation, or maintenance of your ChooChoo Side Table, or if you require assistance with missing or damaged parts, please contact our customer service team. We are committed to resolving any after-sales issues promptly.
Please refer to your purchase documentation or the retailer's website for specific contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question