

[Manuals.plus](#) /

› [ABUS](#) /

› ABUS Wall Anchor WCH + Chain ACH 9KS - 110 cm Instruction Manual

ABUS WCH + ACH 9KS

ABUS Wall Anchor WCH + Chain ACH 9KS - 110 cm Instruction Manual

Model: WCH + ACH 9KS

1. INTRODUCTION AND PRODUCT OVERVIEW

The ABUS Wall Anchor WCH combined with the Connection Chain ACH 9KS provides a high-security solution for protecting bicycles and motorcycles. This system is designed for secure anchoring in walls, offering robust anti-theft protection for your valuable two-wheelers in garages, cellars, or outside your home. The integrated anchor and chain system ensures a high level of security and ease of use.

This product features ABUS Security Level 13, indicating a high resistance against manipulation and theft attempts.

2. PRODUCT COMPONENTS

The ABUS Wall Anchor WCH + Chain ACH 9KS package includes the following main components:

- **Wall Anchor (WCH):** A robust, hardened steel housing designed for secure wall mounting.
- **Connection Chain (ACH 9KS):** A 110 cm long chain made of hardened steel, with a 9 mm thickness, featuring a textile coating to protect against paint damage.
- **XPlus Cylinder:** An integrated high-security cylinder providing excellent protection against picking and other manipulation methods.
- **Security Dowels:** High-security dowels specifically designed for firm and secure installation into masonry.



Image: The ABUS Wall Anchor WCH components, showing the main anchor body and the included security dowels for installation.

3. SETUP AND INSTALLATION

Proper installation of the ABUS Wall Anchor is critical for its security performance. Ensure you have the necessary tools and follow these steps carefully.

3.1 Required Tools (Not Included):

- Drill with appropriate masonry drill bit (a long drill head may be required).
- Hammer.
- Wrench or socket set for tightening bolts.
- Measuring tape and marker.

3.2 Installation Steps:

1. **Select Location:** Choose a suitable, solid masonry wall or concrete floor for installation. Ensure the location allows for easy access to secure your bicycle or motorcycle.
2. **Mark Drilling Points:** Position the wall anchor against the chosen surface and mark the drilling points for the security dowels.
3. **Drill Holes:** Using the appropriate masonry drill bit, drill holes at the marked points to the specified depth. Ensure the holes are clean and free of debris.
4. **Insert Dowels:** Carefully insert the security dowels into the drilled holes. They should fit snugly.
5. **Mount Anchor:** Place the wall anchor over the dowels and secure it using the provided bolts. Tighten the bolts firmly but avoid over-tightening, which can damage the dowels or the wall. Ensure the anchor is flush and stable against the surface.
6. **Test Stability:** After installation, test the stability of the anchor by applying moderate force. It should be firmly

fixed and not show any movement.



Image: A bicycle secured to an ABUS Wall Anchor using the integrated chain lock, demonstrating typical usage.

4. OPERATING INSTRUCTIONS

Once the wall anchor is securely installed, follow these steps to properly secure your bicycle or motorcycle:

1. **Position Vehicle:** Park your bicycle or motorcycle close to the installed wall anchor.
2. **Thread Chain:** Pass the hardened steel chain through a sturdy part of your vehicle's frame or wheel. The textile coating on the chain helps protect your vehicle's paintwork from scratches.
3. **Connect to Anchor:** Insert the end of the chain into the locking mechanism of the wall anchor.
4. **Lock System:** Use the key to engage the XPlus cylinder, locking the chain securely within the anchor. Ensure the lock is fully engaged and cannot be opened without the key.
5. **Remove Key:** Always remove the key after locking to prevent unauthorized access.

5. MAINTENANCE

Regular maintenance ensures the longevity and reliable operation of your ABUS Wall Anchor and Chain.

- **Lubrication:** Periodically lubricate the XPlus cylinder with a non-greasy lock spray (e.g., ABUS lock spray) to ensure smooth operation and prevent corrosion. Avoid using oil or graphite, which can attract dirt.
- **Cleaning:** Keep the anchor and chain clean from dirt, dust, and debris. Wipe down the components with a damp cloth as needed.
- **Inspection:** Regularly inspect the wall anchor for any signs of wear, damage, or loosening of the mounting bolts. Check the chain for cuts, rust, or damage to the textile coating. Address any issues promptly.

6. TROUBLESHOOTING

If you encounter issues with your ABUS Wall Anchor and Chain, consider the following:

- **Key Does Not Turn:**
 - Ensure the key is fully inserted and oriented correctly.
 - Apply a small amount of lock lubricant to the cylinder.
 - If the key still does not turn, there might be a manufacturing defect. Contact ABUS customer support.
- **Anchor Feels Loose After Installation:**
 - Re-check the tightness of the mounting bolts.
 - Ensure the dowels are properly seated in solid masonry. If the wall material is weak or the holes are oversized, the anchor may not hold securely. Professional installation might be required.
 - If screws broke during installation, it might indicate improper tools or excessive force. Contact ABUS for replacement parts and guidance.
- **Chain or Lock Mechanism Stiff:**
 - Clean any dirt or debris from the chain links and locking mechanism.
 - Lubricate the lock cylinder and chain links with appropriate lock spray.

7. SPECIFICATIONS

Feature	Detail
Brand	ABUS
Model Number	69061 (WCH + 9KS/110)
Security Level	ABUS Security Level 13
Chain Length	110 cm (43.31 inches)
Chain Thickness	9 mm
Material	Hardened Steel (Anchor & Chain), Aluminum (Lock components)
Special Feature	Sturdy, XPlus Cylinder, Textile Coating
Item Dimensions (L x W x H)	43.31 x 3.94 x 1.77 inches (overall, likely chain length x anchor dimensions)
Item Weight	7 Pounds
UPC	655043420232

8. WARRANTY INFORMATION

Warranty information for the ABUS Wall Anchor WCH + Chain ACH 9KS is not explicitly specified in the provided product details. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact ABUS customer support directly.

9. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your ABUS Wall Anchor and Chain, please contact ABUS customer service. You can often find contact details on the official ABUS website or through the retailer where you purchased the product.

Visit the [ABUS Store on Amazon](#) for more product information and support resources.

10. SAFETY INFORMATION

Please observe the following safety guidelines during installation and use:

- Always wear appropriate personal protective equipment (e.g., safety glasses, gloves) during installation.
- Ensure the wall or surface chosen for installation is structurally sound and capable of supporting the anchor and resisting theft attempts.
- Keep keys in a secure location and do not leave them in the lock.
- Do not attempt to modify the anchor or chain, as this may compromise its security features.
- Keep out of reach of children.

© 2026 ABUS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B099X62JHZ>

More documents and user manuals: **<https://manuals.plus/>**