Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geakv B099X83NGJ

GCC 24" x 18" White Shaker Bathroom Vanity Cabinet User Manual

Model: B099X83NGJ

1. Introduction

This manual provides essential information for the safe and proper installation, operation, and maintenance of your GCC 24" x 18" White Shaker Bathroom Vanity Cabinet. Please read all instructions carefully before beginning assembly or installation.



Figure 1: Front view of the GCC 24" x 18" White Shaker Bathroom Vanity Cabinet. This image shows the cabinet with its two shaker-style doors and a faux drawer front above, all in a white finish with satin nickel knobs.

2. Safety Information

Adherence to the following safety guidelines is crucial for preventing injury and ensuring the longevity of your product.

- Always ensure the cabinet is securely mounted to the wall. Improper mounting can lead to the cabinet falling, causing damage or injury.

- Be cautious of the open back of the cabinet to avoid pinch points when accessing plumbing during installation or maintenance.
- Use appropriate tools and safety gear during assembly and installation.
- Keep small parts away from children to prevent choking hazards.

3. Components and Parts List

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact customer support.

- Vanity Cabinet Frame (Plywood Box Construction)
- Shaker Style Doors (High Density Fiberboard)
- Solid Wood Face Frame
- Satin Nickel Knobs (Included)
- Adjustable European Style Hinges (Pre-installed on doors)
- Internal Shelf (1)
- Mounting Hardware (Not explicitly listed in product description, but implied for "securely mounted to the wall")



Figure 2: Interior view of the vanity cabinet with doors open, showing the internal shelf and the open back for plumbing access.

4. Setup and Installation

This vanity cabinet is designed for wall-mount installation. Professional installation is recommended.

1. **Preparation:** Ensure the installation area is clean, dry, and structurally sound. Identify plumbing lines and electrical outlets.
2. **Unpacking:** Carefully remove all components from the packaging. Inspect for any shipping damage.
3. **Pre-assembly (if required):** The cabinet arrives largely pre-assembled. Attach any loose components like knobs to the doors.
4. **Positioning:** Place the cabinet in its desired location. The open back allows for easy alignment with existing plumbing.
5. **Mounting:** Securely mount the cabinet to the wall using appropriate fasteners for your wall type (e.g., wood studs, drywall anchors). Ensure the cabinet is level before tightening all fasteners.
6. **Plumbing Connection:** Connect the sink and faucet plumbing (not included) through the open back of the cabinet. Ensure all connections are watertight.
7. **Final Adjustments:** Adjust the European style hinges on the cabinet doors to ensure proper alignment and smooth operation.



Figure 3: Dimensional diagram of the vanity cabinet, illustrating its 24" width, 18" depth, and 34.5" height, crucial for planning installation space.

5. Operation

The GCC Bathroom Vanity Cabinet is designed for storage in a bathroom environment. Its primary operation involves opening and closing the two shaker-style doors to access the interior storage space. The adjustable European style hinges allow for fine-tuning of door alignment.

- To open the doors, gently pull the satin nickel knobs.

- To close the doors, push them until they are fully shut.
- The internal shelf provides organized storage for linens or other bathroom essentials.

6. Maintenance

Regular cleaning and proper care will help maintain the appearance and functionality of your vanity cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive materials that can damage the satin finish.
- **Spills:** Immediately wipe up any water spills or moisture to prevent damage to the wood components.
- **Hinges:** Periodically check the adjustable hinges for tightness and smooth operation. Adjust if necessary.
- **Knobs:** Ensure the satin nickel knobs are securely fastened. Tighten if they become loose.

7. Troubleshooting

Problem	Possible Cause	Solution
Cabinet doors do not align properly.	Hinges are out of adjustment.	Adjust the screws on the European style hinges to realign the doors. Refer to hinge manufacturer's instructions if available.
Knobs are loose.	Screws securing the knobs have loosened over time.	Tighten the screws from the inside of the cabinet that secure the knobs.
Cabinet feels unstable after installation.	Insufficient or improper wall mounting.	Ensure the cabinet is securely fastened to wall studs or appropriate heavy-duty anchors. Re-check levelness. If unsure, consult a professional.

8. Specifications

Feature	Detail
Brand	Geakv
Manufacturer	GCC
Model Number	B099X83NGJ
UPC	619660007344
Product Dimensions (D x W x H)	18"D x 24"W x 34.5"H
Color	White
Mounting Type	Wall Mount
Door Style	Shaker
Frame Material	Solid Wood Face Frame
Door Material	High Density Fiberboard
Box Construction	Plywood

Feature	Detail
Hardware Included	Satin Nickel Knobs, Adjustable European Style Hinges
Number of Shelves	1
Assembly Required	Yes (for minor components/installation)
Back Access	Wide open for plumbing access

9. Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the retailer's policy or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.
Manufacturer: GCC
Brand: Geakv

© 2024 Geakv. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B099X83NGJ

More documents and user manuals: **https://manuals.plus/**