

[Manuals.plus](#) /

> [TOSHIBA](#) /

> User Manual for Toshiba 43" 1080p HD LED Fire Smart TV (43V35KU)

TOSHIBA 43V35KU

Toshiba 43" 1080p HD LED Fire Smart TV

MODEL: 43V35KU

User Manual

Introduction

Thank you for choosing the Toshiba 43" 1080p HD LED Fire Smart TV. This television is designed to provide a vibrant and immersive entertainment experience with its Full HD resolution, advanced picture technologies like Color Re-master and Contrast Booster, and the convenience of Fire OS. This manual will guide you through the setup, operation, and maintenance of your new television.



Image: Front view of the Toshiba 43-inch Fire Smart TV, showcasing its display with a vivid nature scene.

Important Safety Information

Please read all safety and operating instructions carefully before using your television. Keep these instructions for future reference.

- **Power Source:** Connect the TV only to the power supply indicated on the label. Ensure the power cord is not walked on or pinched.
- **Ventilation:** Do not block any ventilation openings. Maintain adequate space around the TV for proper airflow to prevent overheating.
- **Cleaning:** Unplug the TV from the wall outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Water and Moisture:** Do not use the TV near water or moisture.
- **Lightning:** Unplug the TV during lightning storms or when unused for long periods.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

Package Contents

Verify that all items are included in your package:

- Toshiba 43" 1080p HD LED Fire Smart TV
- Stand (2 pieces)
- Power Cord
- Remote Control
- AAA Batteries (2)
- Quick Start Guide (QSG)
- Safety and Warranty Card

Setup

Attaching the Stand

To attach the stand to your television:

1. Carefully place the TV face-down on a soft, clean surface to prevent screen damage.
2. Align each stand piece with the corresponding slots on the bottom of the TV.
3. Secure the stands using the screws provided (refer to the Quick Start Guide for specific screw types and locations).
4. Ensure the stands are firmly attached before carefully lifting the TV to its upright position.



Image: Side view of the Toshiba 43-inch Fire Smart TV with its stand attached.

Wall Mounting (Optional)

If you prefer to wall mount your TV, ensure you use a VESA-compatible wall mount kit (not included) that supports the TV's weight and size. Consult a professional for installation if you are unsure. Refer to the wall mount kit's instructions for proper installation.

Connecting Peripherals

Your Toshiba TV offers various connectivity options:

- **HDMI Ports:** Connect Blu-ray players, game consoles, cable/satellite boxes, and other HDMI-enabled devices. This TV supports HDMI for high-definition audio and video.
- **USB Ports:** Two USB ports are available for connecting USB storage devices to view photos, play music, or watch videos.
- **Antenna/Cable Input:** Connect an antenna or cable TV coaxial cable for over-the-air or cable broadcasts.
- **Audio Output:** Use the digital optical audio output or HDMI ARC for connecting to soundbars or home theater systems.

Initial Power On

After connecting all desired devices and the power cord, plug the TV into a power outlet. The TV will guide you through the initial setup process, including language selection, network connection (Wi-Fi), and Fire OS account setup.

Operating Your TV

Remote Control Overview

The included remote control allows you to navigate the TV's features. It requires two AAA batteries (included). Familiarize yourself with the buttons for power, volume, channel, input selection, and dedicated app buttons for quick access to streaming services.

Smart TV Features (Fire OS)

Your Toshiba TV runs on Fire OS, providing seamless access to a vast library of streaming content. Key features include:

- **Preloaded Apps:** Enjoy instant access to popular services like Netflix, YouTube, and Amazon streaming apps.
- **Built-in Alexa:** Use voice commands via the remote control to search for content, control smart home devices, check weather, and more.
- **Wi-Fi Connectivity:** Connect to your home network wirelessly for streaming and online features.

Picture and Sound Settings

Customize your viewing and listening experience through the TV's settings menu:

- **Picture Modes:** Select from various preset picture modes (e.g., Standard, Movie, Sport) or customize settings like brightness, contrast, and color.
- **Color Re-master:** Enhances color accuracy and vibrancy for more lifelike visuals.
- **Contrast Booster:** Improves color depth and contrast for vivid and realistic scenes.
- **Picture Optimizer:** Adjusts shadows, brightness, and colors to enhance overall image quality.
- **REGZA Engine:** Enhances picture quality beyond Full HD, ensuring exceptional visuals.
- **Sound Modes:** Choose from preset sound modes or adjust bass, treble, and balance.
- **REGZA Power Audio:** Creates an immersive audio experience with the integrated speakers.
- **Dolby Audio:** Delivers rich, immersive sound quality.

Connectivity

The TV supports wireless connectivity for internet access and Bluetooth for connecting compatible audio devices like headphones or soundbars.

Maintenance

Cleaning the TV

- **Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, lightly dampen the cloth with water or a specialized screen cleaner (never spray directly onto the screen).
- **Body:** Wipe the TV's frame and stand with a soft, dry cloth.
- **Important:** Always unplug the TV before cleaning. Avoid using abrasive cleaners, waxes, or solvents.

Software Updates

Your Fire Smart TV may receive automatic software updates to improve performance and add new features.

Ensure your TV is connected to the internet to receive these updates. You can also manually check for updates in the TV's settings menu.

Troubleshooting

If you encounter issues with your TV, refer to the following common problems and solutions:

Problem	Possible Solution
No Power	Check if the power cord is securely plugged into the TV and the wall outlet. Test the outlet with another device.
No Picture, But Sound is Present	Ensure the correct input source is selected. Check cable connections (HDMI, antenna). Try resetting the TV by unplugging it for 60 seconds.
No Sound, But Picture is Present	Check the volume level and mute status. Verify audio cable connections. If using external audio, ensure it's powered on and correctly configured.
Cannot Connect to Wi-Fi	Ensure your Wi-Fi router is on and working. Re-enter the Wi-Fi password. Try restarting your router and the TV. Move the TV closer to the router if possible.
Remote Control Not Working	Replace the batteries. Ensure there are no obstructions between the remote and the TV's IR sensor.
Streaming Issues (e.g., HDCP error)	Ensure all connected devices (e.g., streaming sticks, Blu-ray players) and HDMI cables are HDCP compliant. Try a different HDMI port or cable. Some content providers require HDCP for playback.

Specifications

Feature	Detail
Brand	TOSHIBA
Model	43V35KU
Screen Size	43 Inches
Display Technology	LED
Resolution	1080p (1920 x 1080 pixels)
Refresh Rate	60Hz
Aspect Ratio	16:9
Smart TV Platform	Fire OS (with built-in Alexa)
Connectivity	Wireless (Wi-Fi), Bluetooth

Feature	Detail
Ports	HDMI, USB (2 total)
Dimensions (with stand)	95.5 x 8.64 x 55.88 cm (approx. 37.6 x 3.4 x 22 inches)
Weight	6.5 kg (approx. 14.3 lbs)
Included Components	TV, Stand, Power Cord, Remote, Batteries, QSG, Safety/Warranty Card

Warranty and Support

Your Toshiba 43" 1080p HD LED Fire Smart TV (Model 43V35KU) comes with a limited warranty. Please refer to the included Safety and Warranty Card for detailed terms and conditions, including warranty period and coverage.

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Toshiba customer service or visit the official Toshiba support website. Keep your purchase receipt and the TV's serial number (located on the back of the unit) handy when contacting support.

Manufacturer: Toshiba (Hisense Canada Co. Ltd)