

Rosebery Kids RK-4866-342531

Rosebery Kids Twin Over Full Metal Bunk Bed Instruction Manual

Model: RK-4866-342531

INTRODUCTION

This manual provides essential information for the safe assembly, operation, and maintenance of your Rosebery Kids Twin Over Full Metal Bunk Bed. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Rosebery Kids Twin Over Full Metal Bunk Bed is designed to maximize space in children's bedrooms or guest rooms. It features a twin-sized top bunk with protective guard rails and a full-sized bottom bunk, making it suitable for various age groups. Built-in ladders on each side provide convenient access to the top bunk.

SAFETY INFORMATION

- **WARNING:** Always follow the manufacturer's recommended mattress size for both upper and lower bunks.
- **WARNING:** The top bunk is not suitable for children under 6 years of age.
- **WARNING:** Ensure all connections are tight before use. Periodically check and tighten all fasteners.
- **WARNING:** Do not allow more than one person on the upper bunk.
- **WARNING:** Always use the ladder for entering and exiting the upper bunk. Do not use the bed as a climbing frame.
- **WARNING:** Do not attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, and jump ropes.
- **CAUTION:** Keep small parts away from children during assembly.
- **CAUTION:** Use only on a level surface.

PARTS LIST

Before assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

Part	Description	Quantity
------	-------------	----------

Part	Description	Quantity
A	Upper Bunk Frame (Twin)	1
B	Lower Bunk Frame (Full)	1
C	Side Rails (Upper)	2
D	Side Rails (Lower)	2
E	Guard Rails	2
F	Ladders (Built-in)	2
G	Support Slats (Twin)	Varies
H	Support Slats (Full)	Varies
I	Hardware Pack (Bolts, Nuts, Washers, Allen Wrench)	1

SETUP AND ASSEMBLY

- Assembly requires two adults. Please follow these steps carefully. Do not use power tools for assembly as this may overtighten and damage the fasteners.
- Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface (e.g., a carpet or blanket) to prevent scratching.
 - Assemble Lower Bunk:** Attach the lower bunk side rails (D) to the lower bunk frame (B) using the appropriate bolts and washers from the hardware pack (I). Hand-tighten all connections initially.
 - Install Lower Slats:** Place the full-sized support slats (H) onto the lower bunk frame. Ensure they are evenly spaced and secured if applicable.
 - Assemble Upper Bunk:** Attach the upper bunk side rails (C) to the upper bunk frame (A) using the appropriate bolts and washers. Hand-tighten.
 - Install Upper Slats:** Place the twin-sized support slats (G) onto the upper bunk frame. Ensure they are evenly spaced and secured.
 - Attach Guard Rails:** Secure the guard rails (E) to the upper bunk frame as indicated in the diagrams. Ensure they are firmly attached for safety.
 - Connect Bunks:** Carefully lift the assembled upper bunk and align it with the lower bunk frame. Securely attach the upper bunk to the lower bunk using the designated connection points and hardware. This step may require two people.
 - Final Tightening:** Once all components are in place and aligned, use the provided Allen wrench to fully tighten all bolts and fasteners. Do not overtighten.
 - Placement:** Position the assembled bunk bed against a wall, ensuring there is adequate space around it and that it is stable on a level floor.



Image 1: Fully assembled Rosebery Kids Twin Over Full Metal Bunk Bed. This image shows the complete blue metal bunk bed with a twin bed on top and a full bed on the bottom, complete with mattresses and bedding.



Image 2: Close-up view of the built-in ladder and upper bunk guard rail. This image highlights the sturdy metal construction of the ladder and the protective railing on the top bunk.

OPERATING AND USAGE

- **Mattress Requirements:** Ensure mattresses used comply with the recommended dimensions for twin (upper) and full (lower) beds. The maximum mattress thickness for the upper bunk should not exceed 6 inches to maintain adequate guard rail height.
- **Weight Capacity:** The upper bunk is designed to support a maximum weight of 175 lbs (including mattress). The lower bunk is designed to support a maximum weight of 350 lbs (including mattress). Do not exceed these limits.
- **Ladder Use:** Always use the built-in ladders for safe access to and from the upper bunk. Ensure the ladder is free from obstructions.
- **Guard Rails:** The full-length guard rails on the upper bunk are crucial for safety. Do not remove or modify them.
- **General Use:** Discourage rough play on or around the bunk bed. Do not jump on the bed.

MAINTENANCE

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.
- **Fastener Checks:** Periodically (e.g., every 3-6 months) check all bolts and fasteners to ensure they remain tight. Retighten if necessary, but do not overtighten.
- **Structural Integrity:** Inspect the bed frame for any signs of damage, bending, or cracks. If any damage is found, discontinue use immediately and contact customer support.
- **Mattress Care:** Follow the care instructions provided by your mattress manufacturer.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose fasteners. Uneven floor.	Check and tighten all bolts and screws. Ensure the bed is on a level surface; use shims if necessary.
Squeaking noises.	Loose connections. Friction between metal parts.	Tighten all fasteners. Apply a small amount of silicone spray or lubricant to connection points if squeaking persists.
Difficulty assembling parts.	Misalignment. Incorrect parts.	Refer to the assembly diagrams and ensure parts are correctly oriented. Double-check part numbers. Do not force parts together.

SPECIFICATIONS

- **Product Dimensions:** 78.5" L x 57" W x 59" H
- **Product Weight:** Approximately 97 lbs
- **Size:** Twin Over Full
- **Color:** Blue
- **Finish Type:** Metal
- **Included Components:** Guardrails, Built-in Ladders
- **Assembly Required:** Yes
- **Manufacturer:** Rosebery Kids
- **Model Number:** RK-4866-342531
- **UPC:** 680499326258
- **Country of Origin:** China

WARRANTY AND SUPPORT

For any questions, missing parts, or concerns regarding your Rosebery Kids Twin Over Full Metal Bunk Bed, please contact the retailer or manufacturer directly. Please have your model number (RK-4866-342531) and UPC (680499326258) available when contacting support.

This product is typically covered by a standard manufacturer's warranty against defects in materials and workmanship. Please refer to your purchase documentation for specific warranty terms and conditions. Returns are generally accepted

within 30 days of purchase, subject to retailer policy.
For product care instructions, always refer to this manual.

© 2024 Rosebery Kids. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question