

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [Steve Madden](#) /
- › Steve Madden Women's Lancer Fashion Sneaker User Manual

Steve Madden LANCER

Steve Madden Women's Lancer Fashion Sneaker User Manual

Model: LANCER

INTRODUCTION

The Steve Madden Women's Lancer Fashion Sneaker is designed for modern women seeking a blend of style and comfort. This manual provides essential information for the proper use, care, and maintenance of your sneakers to ensure their longevity and performance.

SETUP AND FIRST USE

Upon receiving your Steve Madden Lancer Fashion Sneakers, follow these steps for initial preparation:

- Unboxing:** Carefully remove the sneakers from their packaging. Inspect them for any visible defects or damage.
- Initial Inspection:** Check the laces, sole, and upper material to ensure everything is in order.
- First Wear:** Try on the sneakers to ensure a comfortable fit. Adjust the laces as needed for optimal support.



Figure 1: Steve Madden Lancer Fashion Sneaker, showcasing its design and materials.

USAGE GUIDELINES

These sneakers are designed for casual wear and fashion purposes. Adhere to the following guidelines for proper use:

- **Intended Use:** Suitable for daily casual activities, light walking, and fashion-oriented events.
- **Fit:** Ensure the sneakers fit comfortably without excessive tightness or looseness. Refer to the size guide if unsure.
- **Lacing:** Properly lace and tie your sneakers to provide adequate foot support and prevent slippage.
- **Surface Compatibility:** Best used on dry, even surfaces. Avoid prolonged exposure to rough or abrasive terrains to preserve the sole and upper.

MAINTENANCE AND CARE

Proper care extends the life of your Steve Madden Lancer Fashion Sneakers. Follow these maintenance tips:

- **Cleaning the Upper:** For the textile and neoprene upper, gently wipe with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.

- **Cleaning the Sole:** The rubber sole can be cleaned with a brush and soapy water to remove dirt and debris.
- **Drying:** Allow sneakers to air dry naturally at room temperature. Do not use direct heat sources like radiators or hair dryers, as this can damage materials.
- **Storage:** Store sneakers in a cool, dry place away from direct sunlight when not in use. Consider using shoe trees to maintain their shape.
- **Avoid Machine Washing:** Do not machine wash or tumble dry these sneakers, as it can compromise their structure and materials.

TROUBLESHOOTING

This section addresses common concerns you might encounter:

Problem	Possible Cause	Solution
Uncomfortable Fit	Incorrect size; Laces too tight/loose; Foot shape.	Verify size using the provided size guide. Adjust lacing for comfort. Consider trying different socks or insoles.
Stains on Upper	Dirt or liquid spills.	Clean immediately with a damp cloth and mild soap. For stubborn stains, consult a professional shoe cleaner.
Sole Wear	Regular use; Abrasive surfaces.	Sole wear is normal over time. To minimize, avoid dragging feet and excessive use on rough surfaces.

SPECIFICATIONS

Feature	Detail
Product Dimensions	11 x 9 x 4 inches; 10 ounces
Item Model Number	LANCER
Department	womens
Date First Available	May 22, 2017
Manufacturer	Steve Madden
ASIN	B06XHGMGKF
Fabric Type	Textile
Sole Material	Rubber
Outer Material	Neoprene
Closure Type	Pull-On

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or additional support, please refer to the official Steve Madden website or contact their customer service directly. You can also visit the [Steve Madden Store on Amazon](#) for more product details and assistance.