

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TOTAL](#) /

› [TOTAL Tvli2001 20V Portable Cordless Vacuum Cleaner User Manual](#)

TOTAL Tvli2001

TOTAL Tvli2001 20V Portable Cordless Vacuum Cleaner User Manual

Model: Tvli2001

1. INTRODUCTION

Thank you for choosing the TOTAL Tvli2001 20V Portable Cordless Vacuum Cleaner. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your vacuum cleaner. Please read this manual thoroughly before first use and keep it for future reference.

Note: This product is sold without a battery and charger. A TOTAL 20V Lithium-Ion battery (2.0Ah or 4.0Ah) and compatible charger are required for operation and must be purchased separately.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before using the appliance.
- Do not use the vacuum cleaner outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Use only with TOTAL 20V Lithium-Ion batteries and compatible chargers. Using other batteries or chargers may create a risk of injury and fire.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Turn off the appliance before attaching or detaching accessories.
- Empty the dust collector regularly to maintain optimal suction.
- Do not use without the dust collector and filter in place.

3. PRODUCT OVERVIEW

The TOTAL Tvli2001 is a versatile 20V portable cordless vacuum cleaner designed for various cleaning tasks. It

features a bagless design and comes with multiple attachments for different applications.

Components:

- Main Vacuum Unit (with motor, dust collector, filter, battery slot, power switch)
- Crevice Tool
- Brush Nozzle
- Floor Nozzle
- Extension Tubes (2 pieces)
- Flexible Hose



Figure 3.1: TOTAL Tvli2001 Portable Cordless Vacuum Cleaner and its accessories, including the main unit, flexible hose, extension tubes, crevice tool, brush nozzle, and floor nozzle.

4. SETUP

4.1 Battery Installation

1. Ensure the vacuum cleaner is turned off.
2. Align a charged TOTAL 20V Lithium-Ion battery (not included) with the battery slot on the vacuum cleaner.
3. Slide the battery into the slot until it clicks securely into place.

4.2 Attaching Accessories

Select the appropriate accessory for your cleaning task:

- **Crevice Tool:** Ideal for narrow gaps, corners, and hard-to-reach areas.
- **Brush Nozzle:** Suitable for delicate surfaces, upholstery, and dislodging stubborn dirt.
- **Floor Nozzle:** Best for larger flat surfaces, carpets, and hard floors when used with extension tubes.
- **Extension Tubes & Flexible Hose:** Use these to extend reach for floors, ceilings, or inside vehicles.

To attach an accessory, simply push it firmly onto the vacuum cleaner's suction opening or onto the end of the flexible hose/extension tube until it is secure.



Figure 4.1: The vacuum cleaner assembled with extension tubes and the floor nozzle for extended reach.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

Press the power switch located on the handle to turn the vacuum cleaner ON. Press it again to turn the vacuum cleaner OFF.

5.2 Vacuuming

Once powered on, guide the attached nozzle over the surface you wish to clean. For optimal performance, move the vacuum cleaner slowly and steadily.

- For general debris, use the main suction opening or the floor nozzle.
- For tight spaces, use the crevice tool.
- For dusting or delicate surfaces, use the brush nozzle.
- For car interiors or awkward angles, utilize the flexible hose with the appropriate attachment.



Figure 5.1: Example of the vacuum cleaner in use, demonstrating its portability for car interiors.

5.3 Emptying the Dust Collector

Empty the dust collector when it reaches its maximum capacity or when suction power decreases. The dust collector is transparent, allowing you to monitor the fill level.

1. Ensure the vacuum cleaner is turned OFF and the battery is removed.
2. Locate the dust collector release button or latch.
3. Press the release and carefully detach the dust collector from the main unit.
4. Hold the dust collector over a waste bin and open its lid to empty the contents.
5. Reattach the dust collector to the main unit, ensuring it clicks securely into place.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

6.1 Cleaning the Dust Collector and Filter

1. After emptying the dust collector (as per Section 5.3), remove the filter from inside the dust collector.
2. Tap the filter gently over a waste bin to remove fine dust.
3. If necessary, rinse the filter with cool water. Ensure it is completely dry before reinserting it into the dust collector. Do not use detergents or hot water.

4. Wipe the inside of the dust collector with a damp cloth if needed.
5. Once the filter is dry, reinsert it into the dust collector, then reattach the dust collector to the vacuum cleaner.

6.2 Storage

Store the vacuum cleaner and its accessories in a dry, cool place, away from direct sunlight and out of reach of children. Ensure the battery is removed if storing for extended periods.

7. TROUBLESHOOTING

If you encounter issues with your vacuum cleaner, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery not installed correctly Battery is discharged Power switch is faulty	Ensure battery is securely clicked into place Charge the battery Contact customer support
Low suction power	Dust collector is full Filter is clogged Nozzle/hose is blocked	Empty the dust collector Clean or replace the filter Check and clear any blockages in the nozzle or hose
Unusual noise during operation	Blockage in the suction path Loose component	Turn off and remove battery, check for and clear blockages Ensure all parts are securely attached. If noise persists, contact customer support.

8. SPECIFICATIONS


Feature	Specification
Model	Tvli2001
Brand	TOTAL
Voltage	20V (Battery not included)
Capacity	0.7 Liters
Air Flow Rate	7 KPa
Filter Type	Cyclonic
Special Features	Bagless, Portable, Cordless
Product Dimensions	10 x 20 x 37 cm
Item Weight	0.21 kg (209 g)


9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your purchase or contact TOTAL customer service through their official website or authorized distributors. Keep your proof of purchase for warranty claims.

© 2025 TOTAL. All rights reserved.

Related Documents - Tvl2001

 TOTAL TIRLI2028 LI-ION Cordless Impact Wrench User Manual & Safety Guide Comprehensive user manual and safety guide for the TOTAL TIRLI2028 LI-ION Cordless Impact Wrench. Learn about operation, maintenance, technical specifications, and warranty information.
 TOTAL TIDLI200215 20V Battery Hammer Drill User Manual Comprehensive user manual for the TOTAL TIDLI200215 20V Battery Hammer Drill, covering safety instructions, technical specifications, operation, maintenance, and environmental guidelines.
 TOTAL 20V Battery Brush Cutter User Manual and Safety Guide Comprehensive user manual for the TOTAL 20V Battery Brush Cutter (Model TSTLI20018), covering safety instructions, operation, maintenance, technical data, and environmental information.

 <p>TOTAL One-Stop Tools Station BATTERY HAMMER DRILL TRHLI1601</p> <p>20V</p>	<p>TOTAL Battery Hammer Drill TRHLI1601 User Manual and Safety Guide</p> <p>Comprehensive safety instructions, technical specifications, setup guide, work tips, maintenance, and environmental information for the TOTAL 20V Battery Hammer Drill, model TRHLI1601.</p>
 <p>TOTAL One-Stop Tools Station Pregadora a Bateria 20V TOTAL 20V BATTERY STAPLER TRSTI1601</p> <p>20V</p>	<p>TOTAL 20V Battery Stapler User Manual and Safety Guide</p> <p>Comprehensive user manual and safety guide for the TOTAL 20V battery-powered stapler (Pregadora a Bateria 20V), covering operation, maintenance, safety warnings, parts identification, and troubleshooting.</p>
 <p>TOTAL One-Stop Tools Station INDUSTRIAL Ръководство АКБИОДНА LED РАБОТНА ЛАМПА TWLI2025</p> <p>20V</p>	<p>TOTAL Cordless LED Work Lamp TWLI2025 Series - User Manual and Safety Information</p> <p>Comprehensive user manual for the TOTAL Cordless LED Work Lamp (TWLI2025 series), covering safety instructions, operation, specifications, maintenance, and warranty information. Includes model numbers TWLI20258, TWLI20258xy, TWLI2025xy, UTWLI20258, UTWLI20258xy, UTWLI2025xy.</p>