

- Manuals.plus /
- › [Bytech](#) /
 - › BYTECH BYAUBO910BK Bluetooth Chrome Headphones User Manual

Bytech BY-AU-BO-910-BK

BYTECH BYAUBO910BK Bluetooth Chrome Headphones User Manual

Model: BY-AU-BO-910-BK | Brand: Bytech

INTRODUCTION

Thank you for purchasing the BYTECH BYAUBO910BK Bluetooth Chrome Headphones. This manual provides essential information for setting up, operating, and maintaining your headphones to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.

PRODUCT OVERVIEW

The BYTECH BYAUBO910BK headphones are designed for wireless audio enjoyment, featuring Bluetooth connectivity and a lightweight, foldable design for portability. They are equipped with controls for managing audio playback and calls.



This image displays the BYTECH BYAUBO910BK Bluetooth Chrome Headphones. On the left, the headphones are shown in their unfolded, ready-to-use position. On the right, the same headphones are shown in their compact, folded position, highlighting their portability.

Key Features:

- Bluetooth Wireless Communication
- Lightweight Design
- Foldable for Easy Storage
- Integrated Touch Controls

SETUP

1. Charging the Headphones

Before first use, fully charge your headphones. Connect the charging cable (not included, as the product is listed as "Without Cable" for charging) to the charging port on the headphones and the other end to a USB power source. The indicator light will show charging status and turn off or change color when fully charged.

2. Powering On/Off

- **To Power On:** Press and hold the Power button (usually indicated by a power icon) for approximately 3-5 seconds until the indicator light flashes.
- **To Power Off:** Press and hold the Power button again for approximately 3-5 seconds until the indicator light turns off.

3. Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Power button for about 5-7 seconds until the indicator light flashes rapidly, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for new devices.
4. Select "BYAUBO910BK" or a similar name from the list of available devices.
5. Once paired, the indicator light on the headphones will typically stop flashing rapidly and may glow steadily or flash slowly.
6. If prompted for a password, enter "0000" (four zeros).

OPERATING INSTRUCTIONS

The BYAUBO910BK headphones feature touch controls for easy operation. Refer to the specific icons on the earcup for exact button functions.

Music Playback:

- **Play/Pause:** Tap the central button (often marked with a play/pause icon).
- **Next Track:** Tap the "Next" button (often marked with a forward arrow or >>).
- **Previous Track:** Tap the "Previous" button (often marked with a backward arrow or <<).
- **Volume Up:** Tap the "+" button.
- **Volume Down:** Tap the "-" button.

Call Management:

- **Answer/End Call:** Tap the central button during an incoming call to answer, or during an active call to end.
- **Reject Call:** Press and hold the central button for 2 seconds during an incoming call.
- **Redial Last Number:** Double-tap the central button.

MAINTENANCE

Cleaning:

- Wipe the headphones with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Avoid getting moisture into any openings.

Storage:

- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- When not in use, fold the headphones to protect them and save space.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Headphones not in pairing mode; device Bluetooth off; too far from device.	Ensure headphones are in pairing mode (rapid flashing light). Turn on Bluetooth on your device. Move headphones closer to the device (within 10 meters).
No sound.	Volume too low; headphones not connected; incorrect audio output selected on device.	Increase volume on both headphones and device. Re-pair headphones. Check device audio settings.
Poor sound quality.	Interference; low battery; device too far.	Move away from sources of interference (Wi-Fi routers, other Bluetooth devices). Charge headphones. Move closer to the device.

SPECIFICATIONS

Feature	Detail
Model Name	BYAUBO910BK
Model Number	BY-AU-BO-910-BK
Wireless Technology	Bluetooth
Form Factor	Over Ear
Material	Plastic
Control Method	Touch
Item Weight	318 g (0.7 lbs)
Product Dimensions	8.89 x 16.51 x 20.32 cm (3.5 x 6.5 x 8 inches)
Special Features	Lightweight

Note: Specifications are subject to change without notice.

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official Bytech website. Keep your proof of purchase for warranty claims.

Contact Information:

- Please refer to the manufacturer's official website or product packaging for the most current contact details.*

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09BBGJGZB>

More documents and user manuals: <https://manuals.plus/>