

[Manuals.plus](#) /

> [Skechers](#) /

> Skechers Men's Quartz Watch SR9066 User Manual

Skechers SR9066

Skechers Men's Quartz Watch SR9066 User Manual

Model: SR9066

INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your Skechers Men's Quartz Watch, Model SR9066. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

PRODUCT OVERVIEW

The Skechers SR9066 is a men's quartz watch featuring a black three-hand analog display. It comes with a durable polyurethane band and a round alloy case with a black dial. This watch is designed for everyday wear and is water resistant up to 30 meters.

Key Features:

- Quartz movement with 3-hand analog display.
- 44mm round alloy case with mineral crystal.
- Black polyurethane band with tang buckle closure.
- Water resistant up to 30 meters (suitable for splashes, not swimming or diving).
- Includes bracelet accessories.

SETUP

1. Unboxing and Initial Inspection

Carefully remove the watch and any included accessories from the packaging. Inspect the watch for any visible damage. The package includes the watch and bracelet accessories.



Image: The Skechers watch box, which contains the watch and bracelet accessories.

2. Setting the Time

1. Locate the crown on the right side of the watch case.
2. Pull the crown out gently to the time-setting position. You may feel a slight click.
3. Turn the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
4. Once the time is set, push the crown back in firmly against the watch case to start the watch movement.





Image: Side view of the watch, highlighting the crown used for setting the time.

Wearing the Watch

Adjust the polyurethane strap to fit comfortably around your wrist. The tang buckle closure allows for secure fastening.






Image: Close-up of the watch's black polyurethane strap and the Skechers-branded tang buckle.

Water Resistance

This watch is water resistant up to 30 meters (3 ATM). This means it is suitable for everyday use and can withstand splashes, rain, or brief immersion in water. **It is not suitable for swimming, showering, or diving.** Avoid operating the crown while the watch is wet to prevent water intrusion.

MAINTENANCE

Cleaning

To clean your watch, wipe the case and strap with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish. For the polyurethane strap, mild soap and water can be used, followed by thorough drying.

Battery Replacement

The watch is powered by a 12V battery. When the watch stops running or the time becomes inaccurate, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and maintain water resistance.

Storage

Store your watch in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, consider removing the battery to prevent leakage, though this is typically not necessary for modern quartz watches.

TROUBLESHOOTING

Watch Not Running

- **Check the Crown:** Ensure the crown is fully pushed in against the watch case. If it is pulled out, the watch will not run.
- **Battery:** The battery may be depleted. A 12V battery is included with the watch. If the watch is new and not running, the battery might be dead or require activation (some watches have a plastic stopper under the crown that needs to be removed). If the watch has been used for some time, the battery likely needs replacement.

Inaccurate Time

- **Battery Level:** A low battery can cause the watch to run slowly or intermittently.
- **Magnetic Fields:** Strong magnetic fields can affect quartz watch accuracy. Keep the watch away from strong magnets.
- **Impact:** Severe impacts can damage the internal mechanism.

If troubleshooting steps do not resolve the issue, contact Skechers customer support or a professional watch repair service.

SPECIFICATIONS

Model Number	SR9066
Movement	Quartz
Display Type	Analog (3-hand)
Case Material	Alloy
Case Diameter	44 mm
Case Thickness	5 mm
Band Material	Polyurethane
Band Width	17 mm
Dial Color	Black
Band Color	Black
Crystal Material	Mineral
Water Resistance Depth	30 meters (3 ATM)
Clasp Type	Tang Buckle
Item Weight	120 grams
Battery	1 x 12V (included)

WARRANTY AND SUPPORT

For warranty information or technical support regarding your Skechers SR9066 watch, please refer to the warranty card included with your purchase or visit the official Skechers website. You can also contact Skechers customer service for assistance.

Skechers Brand Store: [Visit Skechers Store on Amazon](#)

