

ORIGBELIE BT669

ORIGBELIE External CD/DVD Drive User Manual

Brand: ORIGBELIE | Model: BT669

1. INTRODUCTION

Thank you for choosing the ORIGBELIE External CD/DVD Drive. This device provides a convenient solution for reading and writing CDs and DVDs on modern computers that lack an optical drive. It also functions as a multi-port USB hub, expanding your connectivity options. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.



The ORIGBELIE External CD/DVD Drive, showcasing its sleek design and included accessories.

2. WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- DVD Burner x 1
- USB A to USB C Charging Cable x 1
- Drawstring Bag x 1
- User Manual x 1



All components included in the product packaging: the drive, cables, bag, and manual.

3. SETUP GUIDE

3.1 Connecting the Device (Plug & Play)

The ORIGBELIE External CD/DVD Drive is designed for simple plug-and-play operation. No additional drivers or external power supply are typically required.

1. **Connect to your Computer:** Use the integrated USB A or USB C data cable to connect the drive to an available USB port on your laptop, desktop, or MacBook.
2. **Automatic Detection:** Your computer should automatically detect the external CD/DVD drive.
3. **Mac OS Note:** For Mac OS systems, the device icon may not appear until a disc is inserted and successfully read.

Plug and Play

Supports reading & burning discs




The drive connected to a laptop, ready for use. It supports various functions like music, movies, data backup, and software installation.

3.2 Understanding the Ports and Features

The device features multiple ports for enhanced connectivity:

- **USB A 3.0 Port:** For high-speed data transfer.
- **USB A 2.0 Ports (x3):** For connecting various USB devices.
- **TF Slot:** For TransFlash (microSD) cards.
- **SD Slot:** For Secure Digital cards.
- **USB C Port:** For data transfer and power.
- **Indicator Light:** Shows device activity.
- **Pop-up Button:** For disc tray ejection.
- **Forced Ejection Hole:** For manual disc ejection in case of power failure or malfunction.

Note: The SD port and TF port cannot be used simultaneously.



Detailed view of the drive's dimensions and the labeling of its various ports, including USB A, USB C, TF, and SD slots.

4. OPERATING INSTRUCTIONS

4.1 Reading and Writing Discs

This drive supports reading and writing various disc formats including CD ± R/RW, CD-ROM, DVD ± R/RW, DVD-ROM, DVD-RAM, DVD + R DL, DVD-R DL, VCD, and SVCD.

1. **Insert Disc:** Press the pop-up button to open the disc tray. Carefully place your CD or DVD onto the tray, ensuring it is centered. Gently push the tray back into the drive until it clicks.
2. **Access Disc:** Your computer's operating system should recognize the disc. You can then access its contents through File Explorer (Windows) or Finder (Mac).
3. **Burning Discs:** To burn files to a blank CD or DVD, use your preferred burning software. The drive supports up to 24x CD read/write speeds and 8x DVD read/write speeds.
4. **Ejecting Disc:** Press the pop-up button again to eject the disc. Alternatively, you can eject the disc through your operating system (e.g., right-click on the drive icon and select 'Eject').

4.2 Using the USB Hub Functionality

The integrated 8-in-1 USB hub allows you to connect multiple peripherals and memory cards

The ORIGBELIE drive is designed to be slim and lightweight, making it highly portable and easy to carry in a laptop bag. It features a built-in thinnest chip design for a compact form factor.



The ultra-slim profile of the drive, measuring 0.7 inches thin and weighing 0.78 lbs, making it highly portable.

5.3 Anti-Slip Design

The bottom of the drive is equipped with non-slip rubber pads to prevent it from sliding on surfaces, ensuring stability during use.

Anti-slip design



The anti-slip design on the bottom of the drive, featuring rubber feet for stability on various surfaces.

6. COMPATIBILITY

6.1 Supported Operating Systems and Devices

The drive is widely compatible with various operating systems and computer types:

- **Operating Systems:** Windows 11/10/8/7/XP/Vista, Linux, Mac OS 10.6 or above.
- **Compatible Devices:** Apple MacBook Air, MacBook Pro, iMac, Laptops, Desktops.

Widely compatible



A visual representation of the drive's wide compatibility with various operating systems including Windows XP, 7, 8, 10, Mac OS, and Linux, and devices like MacBooks, iMacs, notebooks, desktops, and laptops.

6.2 Incompatible Devices

Please note that this drive is **not** compatible with the following devices:

- Cars
- Televisions (TVs)
- Tablets
- Phones
- Projectors
- Chromebooks
- Microsoft Surface devices
- Blu-ray discs

Know before You Buy

The following may cause the optical drive can't read the CD/DVD

Incompatible



Blu-ray



Phones



Tablets



Cars



TVs



Projectors



Chromes




PS4

Insufficient current supply



Note: Power bank and adapter are not included



Illustrates devices that are incompatible with the drive (Blu-ray, phones, tablets, cars, TVs, projectors, Chrome OS, PS4) and emphasizes the need for sufficient power supply, noting that power banks and adapters are not included.

7. SPECIFICATIONS

Feature	Description
Brand	ORIGBELIE
Model Number	BT669
Color	Black
Material	Acrylonitrile Butadiene Styrene (ABS)
Product Dimensions	14.3L x 15.3W x 1.9H cm (5.6L x 6.0W x 0.7H inches)
Hardware Interface	USB 3.0 Type-A, USB 3.0 Type-C
Total USB Ports	8 (1x USB 3.0, 3x USB 2.0, 1x TF, 1x SD, 1x USB C)
Optical Storage Write Speed	24x (CD) / 8x (DVD)

Optical Storage Read Speed	625 MB/s
Compatible Operating Systems	Windows 11/10/8/7/XP/Vista, Linux, Mac OS
Special Features	Lightscribe, Backward Compatibility, Error Correction, Noise Reduction Technology, Plug & Play

8. MAINTENANCE

To ensure the longevity and optimal performance of your ORIGBELIE External CD/DVD Drive, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the exterior of the drive. Do not use liquid cleaners or abrasive materials. For the optical lens, use a specialized CD/DVD lens cleaning kit if necessary, following its instructions carefully.
- **Storage:** When not in use, store the drive in its provided drawstring bag to protect it from dust and scratches. Keep it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Always handle discs by their edges to avoid fingerprints and scratches on the data surface. Avoid placing heavy objects on the drive.
- **Cable Care:** Do not bend or crimp the integrated USB cable excessively. Store it neatly when not in use.

9. TROUBLESHOOTING

If you encounter issues with your ORIGBELIE External CD/DVD Drive, refer to the following common problems and solutions:

- **Drive Not Detected:**
 - Ensure the USB cable is securely connected to both the drive and your computer's USB port.
 - Try connecting to a different USB port on your computer.
 - If using a desktop, try a USB port on the back of the computer, as front ports may sometimes have insufficient power.
 - Restart your computer.
- **Disc Not Reading/Writing:**
 - Check if the disc is clean and free of scratches or smudges. Clean the disc with a soft, lint-free cloth if necessary.
 - Ensure the disc format is supported by the drive (refer to Section 6.1). Blu-ray discs are not supported.
 - Verify that your computer has sufficient power. If connected to a low-power USB hub, try connecting directly to the computer.
 - For Mac OS, remember the device icon may not appear until a disc is successfully read.
- **Disc Tray Not Opening/Closing:**
 - Ensure the drive is properly connected and powered.
 - Gently press the pop-up button.

- If the tray is stuck, locate the small forced ejection hole on the front of the drive. Insert a straightened paperclip into this hole and push gently to manually open the tray.
- **Slow Performance:**
 - Ensure you are connected to a USB 3.0 port for optimal speed.
 - Close any unnecessary applications running in the background that might be consuming system resources.

10. WARRANTY AND SUPPORT

The ORIGBELIE External CD/DVD Drive comes with a **1-year manufacturer warranty**.

For technical support, warranty claims, or any questions regarding your product, please contact ORIGBELIE customer service through the retailer where you purchased the device or visit the official ORIGBELIE website for contact information.

Please retain your proof of purchase for warranty purposes.