

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Holdsound](#) /
- › [Holdsound BKM300 Wireless TV Headphones User Manual](#)

Holdsound BKM300

Holdsound BKM300 Wireless TV Headphones User Manual

MODEL: BKM300

1. Introduction

Thank you for choosing the Holdsound BKM300 Wireless TV Headphones. This manual provides detailed instructions for setting up, operating, and maintaining your new headphones and transmitter. Designed for a seamless audio experience, the BKM300 offers clear sound, extended wireless range, and comfortable wear, allowing you to enjoy your TV audio without disturbing others.



Image 1.1: Holdsound BKM300 Wireless TV Headphones and USB Transmitter.

2. Package Contents

Please check the box for the following items:

- Holdsound BKM300 Wireless Headphones
- USB Wireless Audio Transmitter
- USB Type-C Charging Cable
- 3.5mm Audio Cable
- RCA Audio Cable (Red/White)
- USB Power Adapter
- User Manual

3. Product Features

The BKM300 headphones are designed with advanced features for an optimal listening experience:

- **Easy to Use:** Simple plug-and-play setup with auto-pairing within 1 second. Powers directly from your TV's USB port, eliminating extra cables and power outlets.
- **Extended Wireless Range:** Enjoy a stable connection up to 165 feet (50 meters), providing whole-house coverage without signal degradation.
- **Crystal Clear Sound:** Equipped with 40mm drivers, the system filters out TV interface noise and static, delivering rich, detailed audio with low distortion.
- **Pressure-Free Comfort:** Lightweight design with ultra-soft protein leather earmuffs ensures comfort during long listening sessions.
- **Convenient Charging:** Recharge the headphones anywhere using the included USB adapter and Type-C cable. A 3-hour charge provides up to 20 hours of working time.

Multi-Functional TV Headphones **BKM300**



Image 3.1: Key features of the BKM300 headphones, including intelligent operation, 1-second connection, 165ft/50m range, no static, no delay, and excellent sound quality.

The Longest Distance Reaches 165ft/50m

Whole house coverage



Image 3.2: Illustration of the 165ft/50m wireless range, providing whole-house coverage.

Louder and Clearer

BKM300  

Others  



Image 3.3: Comparison highlighting the louder and clearer sound quality of BKM300 compared to other headphones.

Pressure-Free Comfort

The lightweight build with ultra-soft protein leather earmuffs also ensures they are comfortable for long listening.



Image 3.4: Close-up view of the ultra-soft protein leather earmuffs, emphasizing pressure-free comfort.

4. Setup and Installation

Follow these steps to connect your Holdsound BKM300 headphones to your TV:

- 1. Identify TV Audio Output:** Check your TV for available audio output ports. The BKM300 transmitter supports USB Audio Out, 3.5mm Audio Out, and RCA (red/white) Audio Out.
- 2. Connect the Transmitter:**
 - **For USB Audio Out:** Plug the USB transmitter directly into an available USB port on your TV.
 - **For 3.5mm Audio Out:** Connect one end of the 3.5mm audio cable to your TV's 3.5mm audio output jack and the other end to the 3.5mm input on the transmitter. Plug the transmitter's USB connector into a TV USB port for power.
 - **For RCA Audio Out:** Connect the RCA audio cable (red and white plugs) to the corresponding red and white audio output jacks on your TV. Connect the other end to the RCA input on the transmitter. Plug the transmitter's USB connector into a TV USB port for power.

NOTE: If your TV only has an optical output, an additional optical adapter (not included) will be required.

Please contact Holdsound support for recommendations.

3. **Power On:** Once the transmitter is connected and powered (its indicator light will flash green slowly), turn on your BKM300 headphones.
4. **Automatic Pairing:** The headphones and transmitter will automatically pair within 1 second. The indicator light on both devices will turn solid green once connected.

Plug & Play

Please check the suitable connection first, in case of inconvenience to you.

NOTE: TV only has optical output? Email us for an optical adapter.



Image 4.1: Diagram showing the USB, 3.5mm, and RCA audio output options for connecting the transmitter to a TV.

No Messy Cable



Image 4.2: Before and after comparison illustrating how the BKM300 system helps reduce cable clutter behind your TV.

5. Operating Instructions

Once connected, operating your BKM300 headphones is straightforward:

- **Power On/Off:** Press and hold the power button on the headphones for approximately 3 seconds to turn them on or off.
- **Volume Control:** Use the volume up (+) and volume down (-) buttons located on the headphones to adjust the listening volume.
- **Charging the Headphones:** When the battery is low, the indicator light on the headphones may flash or change color (refer to the LED indicator section in a full manual for specifics). Connect the included Type-C charging cable to the charging port on the headphones and the other end to the USB power adapter or a powered USB port. The indicator light will show charging status and turn off or change color when fully charged. A full charge takes approximately 3 hours and provides up to 20 hours of playback.

No Delay

Music ON, Distractions OFF



Image 5.1: A user enjoying the BKM300 headphones, illustrating the 'No Delay' audio experience.

Another Level of Charging Convenience

Charge the headphone ANYTIME ANYWHERE via the included Type-C cable and USB adapter.



Image 5.2: Visual representation of the charging time (3 hours) and working time (20 hours) of the BKM300 headphones.

6. Maintenance

To ensure the longevity and optimal performance of your Holdsound BKM300 headphones:

- **Cleaning:** Use a soft, dry cloth to clean the headphones and transmitter. Do not use abrasive cleaners or solvents.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the headphones frequently. Charge them regularly, even if not in use for extended periods.
- **Avoid Moisture:** Do not expose the headphones or transmitter to water or excessive moisture.

7. Troubleshooting

If you encounter issues with your BKM300 headphones, try the following solutions:

Problem	Possible Solution
No Sound	<p>Ensure the transmitter is properly connected to your TV's audio output and receiving power.</p> <p>Check if the headphones are powered on and paired (solid green light).</p> <p>Increase the volume on both the headphones and your TV.</p> <p>Verify your TV's audio output settings are configured correctly (e.g., external speakers, PCM audio).</p>
No Pairing / Disconnection	<p>Ensure both devices are within range (165ft/50m) and free from major obstructions.</p> <p>Power off and then power on both the headphones and the transmitter to re-initiate pairing.</p> <p>Ensure no other strong wireless signals are causing interference.</p>
Short Wireless Range	<p>Reduce obstacles between the transmitter and headphones (e.g., thick walls, large appliances).</p> <p>Ensure the transmitter is not placed near other wireless devices that may cause interference.</p>
Headphones Not Charging	<p>Check if the charging cable is securely connected to both the headphones and the power source.</p> <p>Try a different USB port or power adapter.</p> <p>Ensure the charging cable is not damaged.</p>

8. Specifications

Feature	Detail
Brand	Holdsound
Model	BKM300
Color	300-B
Ear Placement	On Ear
Form Factor	On Ear
Noise Control	None
Wireless Range	Up to 165ft (50m)
Charging Time	Approx. 3 hours
Working Time	Approx. 20 hours

9. Warranty and Support

Holdsound products are designed for reliability and performance. This product comes with a standard manufacturer's warranty. For detailed warranty information, product support, or to purchase accessories, please visit the official Holdsound website or contact our customer service team.

Holdsound Customer Service: Please refer to the contact information provided on the product packaging or the official Holdsound website for assistance.