

PJ Masks F4588

PJ Masks Ahoy Heroes Action Figure Set Instruction Manual

Model: F4588

1. INTRODUCTION

This manual provides essential information for the safe and proper use of the PJ Masks Ahoy Heroes Action Figure Set. This set includes four poseable action figures: Owlette, Gekko, Catboy, and Pirate Robot, along with one spatula launcher accessory. The figures are designed for imaginative play and are compatible with Hasbro Hero ID-equipped PJ Masks toys (sold separately).

WARNING: Small parts may be generated. Not for children under 3 years.

2. PACKAGE CONTENTS

Verify that all components are present in the package:

- 1 x Gekko Action Figure (Pirate-themed)
- 1 x Owlette Action Figure (Pirate-themed)
- 1 x Catboy Action Figure (Pirate-themed)
- 1 x Pirate Robot Action Figure
- 1 x Spatula Launcher Accessory



Image: The PJ Masks Ahoy Heroes Action Figure Set, including Gekko, Owlette, Catboy, and Pirate Robot, displayed with its cardboard packaging. The packaging indicates model F4588 and an age rating of 3+.

3. SETUP

This product requires no assembly. All figures are ready for play directly out of the package.

1. Carefully remove all figures and the accessory from the packaging.
2. Dispose of packaging materials responsibly.

4. OPERATING INSTRUCTIONS

4.1. Poseable Figures

The Gekko, Owlette, and Catboy figures, dressed in pirate-themed outfits with gold accents, are poseable. Their arms and legs can be moved to create various action poses for imaginative play.



Image: The three hero figures, Gekko (green), Owlette (red), and Catboy (blue), in their pirate-themed costumes with gold boots and hats, standing in dynamic poses.

4.2. Pirate Robot and Spatula Launcher

The Pirate Robot action figure is also poseable. The included spatula launcher accessory can be held by the Pirate Robot figure. To operate the launcher:

1. Insert the spatula projectile into the launcher.
2. Place the launcher into Pirate Robot's hand.
3. Press the button on the launcher to release the spatula projectile.



Image: The Pirate Robot figure, wearing a pirate hat, holding the spatula launcher accessory. The image also shows a close-up of the launcher being held by a hand.



Image: A close-up view of the spatula launcher accessory being held by a hand, demonstrating its design and the projectile mechanism.

4.3. Hero ID Compatibility

These figures are compatible with Hasbro Hero ID-equipped PJ Masks toys (sold separately). When placed on a Hero ID-compatible playset or accessory, the figures may trigger lights, sounds, or other reactions specific to the character.



Image: The Catboy figure standing on a blue platform with the "HERO ID" logo, illustrating the compatibility feature.

5. MAINTENANCE

5.1. Cleaning

- Wipe figures with a damp cloth as needed.
- Do not submerge figures in water.
- Avoid using harsh chemicals or abrasive cleaners, as these may damage the paint or plastic.

5.2. Storage

- Store figures in a cool, dry place away from direct sunlight to prevent fading or material degradation.
- Keep figures away from extreme heat sources, such as birthday candles, as this can cause melting.

6. TROUBLESHOOTING

If you encounter any issues with your PJ Masks Ahoy Heroes Action Figure Set, please consider the following:

- **Figure Stability:** Ensure figures are placed on a flat, stable surface for optimal standing. Adjust limbs for balance if necessary.
- **Spatula Launcher Malfunction:** Check that the spatula projectile is correctly inserted into the launcher. Ensure no debris is obstructing the launching mechanism.
- **Hero ID Incompatibility:** Verify that any additional PJ Masks toys you are using are specifically labeled as "Hero ID-equipped" for compatibility.

7. SPECIFICATIONS

Brand:	PJ Masks
Manufacturer:	Hasbro
Model Number:	F4588
ASIN:	B09BD61X3Y
Included Components:	4 figures, 1 accessory, 1 projectile
Material Type:	Plastic
Color:	Multicolored
Item Dimensions (L x W x H):	1.58 x 8.07 x 4.84 inches
Item Weight:	0.33 Pounds
Number of Pieces:	4 (figures)
Minimum Age:	36 Months (3 Years)
Assembly Required:	No

8. WARRANTY INFORMATION

For specific warranty details, please refer to the official Hasbro website or contact their customer support. Warranty terms typically cover manufacturing defects and vary by region.

9. CUSTOMER SUPPORT

If you require further assistance or have questions regarding your PJ Masks Ahoy Heroes Action Figure Set, please contact Hasbro customer service through their official website or the contact information provided on the product packaging.

You can visit the official Hasbro website for support:[Hasbro Customer Service](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question