

Volkano VX-142-BK[V2]

Volkano VX Gaming Hades Series 7200DPI Ultra-Lightweight Gaming Mouse Instruction Manual

Model: VX-142-BK[V2]

1. INTRODUCTION

Welcome to the instruction manual for your Volkano VX Gaming Hades Series Ultra-Lightweight Gaming Mouse. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new gaming mouse. Please read it thoroughly to ensure optimal performance and longevity of your device.

Key Features

- Ultra-lightweight honeycomb construction for optimal speed and agility.
- Adjustable DPI up to 7200 for exceptional sensitivity, suitable for gamers at all levels.
- Customizable with 2 side buttons, left and right mouse buttons, and a scroll wheel button.
- Stylish 7-color pulse effect lighting.



Image 1.1: The Volcano VX Gaming Hades Series Ultra-Lightweight Gaming Mouse, showcasing its ergonomic design and honeycomb shell.

2. SETUP

Follow these steps to connect your Volcano VX Gaming Hades Series mouse to your computer.

System Requirements

- Operating System: Universal (Windows, macOS, Linux compatible)
- Available USB port

Installation

1. Unpack the Volcano VX Gaming Hades Series mouse from its packaging.
2. Locate an available USB port on your computer.
3. Plug the USB connector of the mouse into the USB port.
4. Your computer should automatically detect and install the necessary drivers. This is a plug-and-play device, requiring no additional software installation for basic functionality.
5. Once installed, the mouse's lighting effects will activate, indicating it is ready for use.

3. OPERATION

Understand the functions of your gaming mouse and how to customize its settings.

Mouse Buttons

- **Left Click Button:** Primary action button.
- **Right Click Button:** Secondary action button, typically for context menus.
- **Scroll Wheel Button:** Functions as a middle click and for scrolling up/down.

- **Side Buttons (2):** Customizable buttons, often used for forward/backward navigation or in-game actions.

DPI Adjustment

The mouse features adjustable DPI (Dots Per Inch) settings, allowing you to change cursor sensitivity on the fly. The DPI can be adjusted up to 7200 DPI. The DPI button is typically located behind the scroll wheel. Press this button to cycle through different DPI levels. Each level may be indicated by a change in the mouse's LED lighting color or pattern.

Lighting Effects

The Volcano VX Gaming Hades Series mouse features a dynamic 7-color pulse effect for its lighting. This lighting automatically cycles through various colors, enhancing your gaming setup's aesthetic. No manual adjustment is typically required for the pulse effect.



Image 3.1: The gaming mouse highlighting its ultra-lightweight design, honeycomb surface, 7-color rainbow lighting, and 7200 DPI capability.

4. MAINTENANCE

Proper care and maintenance will extend the life of your gaming mouse.

Cleaning

- Disconnect the mouse from your computer before cleaning.
- Use a soft, dry, lint-free cloth to wipe the surface of the mouse.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals.
- Use a cotton swab or compressed air to clean dust and debris from crevices, especially around the scroll wheel and optical sensor.
- Ensure the mouse is completely dry before reconnecting it to your computer.

Storage

When not in use, store the mouse in a clean, dry environment away from direct sunlight and extreme temperatures. Avoid placing heavy objects on the mouse or its cable.

5. TROUBLESHOOTING

If you encounter issues with your Volcano VX Gaming Hades Series mouse, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Mouse not responding	Loose USB connection, faulty USB port, driver issue.	Ensure USB cable is securely plugged in. Try a different USB port. Restart your computer.
Lighting not working	Power issue, internal fault.	Check USB connection. Try a different USB port. If the mouse functions otherwise, the lighting may have an internal fault.
DPI not changing	DPI button malfunction, software conflict.	Ensure you are pressing the correct DPI button. Restart your computer. If the issue persists, contact support.
Cursor movement is erratic	Dirty optical sensor, unsuitable mouse pad surface.	Clean the optical sensor on the underside of the mouse. Use a clean, uniform-surface mouse pad.

6. SPECIFICATIONS

Detailed technical specifications for the Volcano VX Gaming Hades Series mouse.




Image 6.1: The gaming mouse with key specifications such as switch lifetime, DPI, backlight, button number, and honeycomb surface highlighted.

Feature	Detail
Model Number	VX-142-BK[V2]
DPI (Dots Per Inch)	Up to 7200 DPI
Connectivity	USB Wired
Cable Length	1.7 meters
Buttons	6 (Left, Right, Scroll Wheel, DPI, 2 Side Buttons)
Lighting	7-Color Pulse Effect
Sensor Type	Optical (Surplus 199)
Construction	Ultra-lightweight honeycomb
Item Weight	220 g
Package Dimensions	21.2 x 11.8 x 6.4 cm
Operating System	Universal

7. WARRANTY AND SUPPORT

Your Volcano VX Gaming Hades Series mouse is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Volcano website. If you require technical assistance or have questions not covered in this manual, please contact Volcano customer support or your retailer.

For further information, you may visit the [Volcano Store on Amazon](#).