YUYTE 420w1

YUYTE Mag 420w1 Replacement Remote Control User Manual

Model: 420w1 | Brand: YUYTE

Introduction

This manual provides instructions for the YUYTE Mag 420w1 replacement remote control. This remote is designed to be a direct replacement for the original remote controls of Mag 250, 254, 255, 260, 261, and 270 IPTV TV Boxes. Please read this manual carefully before use to ensure proper operation and longevity of your device.



Image: The YUYTE Mag 420w1 remote control positioned next to a modern television, illustrating its purpose as a replacement for IPTV TV Box remotes. The text on the image indicates compatibility with Mag 250, 254, 255, 260, 261, 270 IPTV TV Boxes.

Package Contents

- 1 x YUYTE Mag 420w1 Replacement Remote Control

Note: AAA batteries are not included and must be purchased separately.

Specifications

Feature	Detail
Model	420w1
Brand	YUYTE
Compatibility	Mag 250, 254, 255, 260, 261, 270 IPTV TV Boxes
Material	ABS

Color	Black
Remote Distance	Up to 10 meters (33 feet)
Power Supply	2 x AAA Batteries (not included)
Dimensions	17.5 x 4.4 x 1.8 cm (6.9 x 1.7 x 0.7 inches)
Weight	50g (1.76 ounces) (approximate, excluding batteries)



Image: A visual representation of the remote control with its dimensions labeled: 17.5 cm / 6.9 inches in length, 4.4 cm / 1.7 inches in width, and 1.8 cm / 0.7 inches in thickness.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover off.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: The back of the remote control with the battery cover removed, showing the empty battery compartment ready for AAA batteries.

The remote control is ready for use immediately after battery installation. No programming is required for compatible Mag IPTV TV Boxes.

Operating Instructions

Button Functions

The YUYTE Mag 420w1 remote control features standard buttons for navigating and controlling your Mag IPTV TV Box. Refer to the image below for a visual guide to the button layout.





Image: A clear, direct view of the YUYTE Mag 420w1 remote control, showcasing all its buttons and their labels, including power, function keys (F1-F4), navigation, volume, channel, and numeric keypad.

- **Power Button:** Turns the IPTV TV Box on or off.
- **F1-F4 Buttons:** Function keys, their specific use may vary depending on your IPTV TV Box model and software.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and select options.

- **Volume (+/-):** Adjusts the audio volume.
- **Channel (+/-):** Changes channels.
- **Numeric Keypad (0-9):** For direct channel input or other numerical entries.
- **Mute, A/V, Mode, Setup, APP, TV, Menu, Back, Home, Play/Pause, Stop, Fast Forward, Rewind:** Standard media and control buttons.

Remote Control Distance

The remote control operates effectively at a distance of up to 10 meters (33 feet). Ensure there are no significant obstructions between the remote and the IPTV TV Box for optimal performance.



Image: A living room scene showing the remote control being used from a sofa, with a television in the background. Text overlay indicates "Far Remote Distance Up to 10 meters remote control range."

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage.

- **Durability:** The remote is constructed from durable ABS material. Avoid dropping the remote or exposing it to extreme temperatures or moisture.



Image: A close-up view of the remote control, emphasizing its construction. Text overlay states "Durable material ABS environmentally friendly raw materials are durable and fall resistant."

Troubleshooting

Remote not responding:

- Ensure batteries are inserted correctly with the correct polarity.
- Replace old batteries with new ones.
- Check for any obstructions between the remote and the IPTV TV Box.
- Verify that the remote is pointed directly at the IPTV TV Box's infrared receiver.

Limited range:

- Ensure batteries are fresh.
- Remove any objects that might be blocking the signal path.
- Environmental factors or interference can sometimes reduce range.

Important Note on Product Variations

Due to manufacturing updates, you may receive either a "New Type" or "Old Type" version of this remote control. Both versions are fully compatible with the specified Mag IPTV TV Boxes and offer identical functionality. The differences are purely cosmetic.



Image: A side-by-side comparison of two remote controls, labeled "New Type" and "Old Type," illustrating minor cosmetic differences while maintaining the same button layout and functionality.

Warranty and Support

For warranty information or technical support, please refer to the retailer where the product was purchased or visit the official YUYTE brand store on Amazon: YUYTE Store.

© 2023 YUYTE. All rights reserved.