



Manuals.plus /

› FitSand /

› FitSand Hard Case for TOZO T5 Earbuds User Manual

## FitSand B09BDF7GCW

# FitSand Hard Case User Manual

For TOZO T5 Bluetooth Headphones True Earbuds Sport Earphones

---

## 1. PRODUCT OVERVIEW

The FitSand Hard Case is specifically designed to provide robust protection for your TOZO T5 Bluetooth Headphones True Earbuds Sport Earphones. Constructed from durable EVA material, this portable and lightweight case safeguards your earbuds from impacts, scratches, and general wear and tear, ensuring their longevity and pristine condition.



Figure 1.1: The FitSand Hard Case shown open, designed to securely hold TOZO T5 earbuds. Note the internal mesh pocket for small accessories.

The case features a secure zipper closure and a soft interior lining to prevent damage. An internal mesh pocket provides convenient storage for small accessories like charging cables or extra ear tips.



Figure 1.2: The interior of the FitSand Hard Case, highlighting the protective lining and the practical mesh pocket for accessory storage.

## 2. SETUP AND USAGE

### 2.1 Placing Earbuds in the Case

1. Open the zipper of the FitSand Hard Case completely.
2. Carefully place your TOZO T5 Bluetooth Headphones True Earbuds into the molded compartment of the case. Ensure they fit snugly without forcing.
3. If desired, place small accessories such as a charging cable or extra ear tips into the mesh pocket on the opposite side of the case.
4. Close the zipper securely to fully enclose and protect your earbuds.

### 2.2 Carrying and Storage

The compact design of the FitSand Hard Case makes it ideal for carrying your earbuds in a backpack,

purse, or luggage. Its robust exterior provides protection against bumps and drops during transit. Always ensure the case is fully zipped when carrying to prevent accidental opening and loss of contents.



Figure 2.1: The FitSand Hard Case in its closed state, ready for transport or storage, demonstrating its compact and protective form factor.

### 3. MAINTENANCE

To ensure the longevity and cleanliness of your FitSand Hard Case, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the exterior of the case with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used, followed by wiping with a clean, damp cloth to remove any residue. Allow the case to air dry completely before closing or storing.
- **Interior Care:** Gently wipe the interior lining with a dry, soft cloth to remove dust or debris. Avoid using harsh chemicals or abrasive materials, as these can damage the case's finish or interior.
- **Storage:** Store the case in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

### 4. TROUBLESHOOTING

While the FitSand Hard Case is a simple protective accessory, here are some common concerns and their solutions:

- **Earbuds do not fit:** Ensure you are using the case with TOZO T5 Bluetooth Headphones True

Earbuds Sport Earphones. This case is specifically designed for this model. Do not force earbuds into the case if they do not fit naturally.

- **Zipper sticking:** If the zipper becomes difficult to operate, gently clean any debris from the zipper teeth. A small amount of zipper lubricant (e.g., beeswax or a silicone-based lubricant) can be applied to the teeth to improve smoothness.
- **Case appears damaged:** Inspect the case for any cracks, tears, or significant deformities. If the structural integrity is compromised, the protective capabilities may be reduced, and replacement may be necessary.

## 5. SPECIFICATIONS

Feature	Specification
Brand	FitSand
Model Compatibility	TOZO T5 Bluetooth Headphones True Earbuds Sport Earphones
Material	EVA (Ethylene-vinyl acetate)
Color	Black
Form Factor	Case
Shell Type	Hard
Special Features	Heavy Duty Protection
Item Weight	1.41 ounces

## 6. WARRANTY AND SUPPORT

This FitSand product is designed for durability and protection. For information regarding returns or specific product support, please refer to the retailer's return policy at the point of purchase. Typically, a 30-day return policy is offered for refunds or replacements.

For any manufacturing defects or concerns not covered by standard troubleshooting, please contact FitSand directly through their official channels or the seller from whom you purchased the product. Keep your purchase receipt as proof of purchase.