

UPBRIGHT WNT-7 / ZDJ050100US Series Adapter

UpBright 5V AC/DC Adapter Instruction Manual

For Wahl Professional Hair Clippers and Trimmers

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your UpBright 5V AC/DC Adapter. This power supply is designed to provide reliable charging for various Wahl Professional hair clippers, shavers, and trimmers. Please read this manual thoroughly before use and retain it for future reference.

SAFETY INFORMATION

- **Indoor Use Only:** This adapter is intended for indoor use in dry locations. Do not expose to water, rain, or excessive humidity.
- **Voltage Compatibility:** Ensure the wall outlet voltage is within the adapter's specified input range (100-240VAC).
- **Proper Connection:** Always connect the adapter to the device first, then plug it into the wall outlet. When disconnecting, unplug from the wall first, then from the device.
- **Device Power Off:** Ensure the hair clipper or trimmer is switched **OFF** when charging to prevent damage and ensure efficient charging.
- **Avoid Damage:** Do not use the adapter if the cord or plug is damaged. Do not attempt to open or repair the adapter. Contact support if damaged.
- **Ventilation:** Ensure adequate ventilation around the adapter during use. Do not cover it with cloth or other materials.
- **Children and Pets:** Keep the adapter and its cord out of reach of children and pets.

PRODUCT OVERVIEW

The UpBright 5V AC/DC Adapter is a compact and efficient power supply designed for specific Wahl devices. It features a 2-prong input for standard wall outlets and a specialized 2-pin connector for your compatible Wahl clipper or trimmer.




Image: The UpBright 5V AC/DC Adapter, showing the main unit with its 2-prong wall plug and the attached output cable with a specialized 2-pin connector.

Compatible Wahl Models:

- Wahl Professional 2225, 2221, 2220, 2223W, 2226 LCD, 2227, 2228, 2235, 2235LCD Artist Series Hair Clippers, Shavers, and Trimmers.
- Adapter Type: WNT-7, WNT7, ZDJ050100US, ZDJ050100CN.

Come With A Suitable Outlet Adapter (Only One) to Fit
Your Country/Area For International Order



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UPBRIGHT® LIMITED WARRANTY



Image: A visual representation of several Wahl hair clippers and trimmers, illustrating the range of devices compatible with this UpBright AC/DC adapter.

SETUP

1. **Verify Compatibility:** Confirm that your Wahl device model is listed as compatible with this UpBright 5V AC/DC Adapter.
2. **Prepare Device:** Ensure your Wahl hair clipper or trimmer is switched **OFF** before connecting the adapter.
3. **Connect Adapter to Device:** Insert the 2-pin connector of the UpBright adapter firmly into the charging port of your Wahl device.
4. **Connect to Power Outlet:** Plug the 2-prong end of the adapter into a standard 100-240VAC wall outlet.
5. **Charging Indication:** Your device should now begin charging. Refer to your Wahl device's manual for specific charging indicators (e.g., LED lights).

UpBright AC Adapter Power Supply Compatible with:



Image: The UpBright adapter with its cable neatly coiled, demonstrating the compact design for storage and transport.

OPERATING INSTRUCTIONS

Once properly set up, the UpBright 5V AC/DC Adapter operates automatically to charge your compatible Wahl device. No further user interaction is required during the charging process.

- Allow the device to charge fully for optimal battery life.
- Disconnect the adapter from the wall outlet and the device once charging is complete or if the device is not in use for an extended period.

MAINTENANCE

- **Cleaning:** Disconnect the adapter from power before cleaning. Use a dry, soft cloth to wipe the adapter. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Inspection:** Periodically inspect the adapter and cable for any signs of wear, cuts, or damage. Discontinue use if damage is observed.

TROUBLESHOOTING

Device Not Charging:

- **Check Connections:** Ensure the adapter is securely plugged into both the wall outlet and the Wahl device.
- **Verify Power Outlet:** Test the wall outlet with another device to confirm it is supplying power.
- **Device Power State:** Confirm the Wahl clipper/trimmer is switched **OFF** during charging.
- **Adapter Condition:** Inspect the adapter and cable for any visible damage. If damaged, discontinue use.
- **Device Compatibility:** Double-check that your specific Wahl model is listed as compatible with this adapter.

If issues persist after performing these checks, please contact UpBright customer support.

SPECIFICATIONS

Input Voltage	100-240VAC, 50/60Hz
Output Voltage	5V DC
Output Amperage	1000mA (1A)
Connector Type	2-Pin (Specialized for Wahl)
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Item Weight	3 ounces
Manufacturer	UPBRIGHT



Image: The UpBright adapter displaying its caution label, indicating safety warnings and specifications.

WARRANTY AND SUPPORT

Your UpBright 5V AC/DC Adapter comes with the following assurances:

- **30-Day Refund:** If you are not satisfied with your purchase, you may be eligible for a refund within 30 days.
- **24-Month Exchange:** The product is covered by a 24-month exchange policy for manufacturing defects.

For support, warranty claims, or further inquiries, please visit the official [UPBRIGHT Store on Amazon](#) or contact their customer service directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09BFCX5FJ>

More documents and user manuals: <https://manuals.plus/>