



[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Twin Over Twin Floor Bunk Bed with Slide User Manual

## Bellemave LK8K

# Bellemave Twin Over Twin Floor Bunk Bed with Slide User Manual

Model: LK8K | Brand: Bellemave

## 1. IMPORTANT SAFETY INFORMATION

---

Please read and understand all instructions before assembling and using this bunk bed. Keep this manual for future reference.

- **Weight Limits:** The upper bunk has a maximum weight capacity of 175 lbs. The lower bunk has a maximum weight capacity of 275 lbs. Do not exceed these limits.
- **Age Recommendation:** The upper bunk is not suitable for children under 6 years of age.
- **Fall Hazard:** Ensure all guardrails are properly installed and secured. Do not allow children to play on the top bunk without supervision.
- **Slide Safety:** The slide is designed for single-user use at a time. Ensure the area around the slide is clear before use. Be cautious as the slide could pose a hazard if not used properly.
- **Assembly:** Proper assembly is crucial to prevent instability or collapse. Ensure all connections are tight and secure. Periodically check and tighten all bolts and fasteners.
- **Mattress Size:** Use only mattresses that comply with the recommended dimensions for twin beds to ensure proper fit and safety.
- **Ventilation:** Ensure adequate ventilation around the bed.

## 2. PRODUCT OVERVIEW

---

The Bellemave Twin Over Twin Floor Bunk Bed with Slide is designed to maximize space in children's bedrooms while providing a fun and secure sleeping environment. It features a low-profile design, a built-in ladder, and a convertible slide.



Figure 2.1: Bellemave Twin Over Twin Floor Bunk Bed with Slide (White)




Figure 2.2: Product Dimensions (77.3"L x 87.1"W x 54.1"H)

This bed offers versatile assembly options, allowing the slide and ladder to be positioned on either the left or right side. The bottom bunk also features guardrails for added security, and can be configured in three different assembly methods.



Figure 2.3: Three Assembly Methods

### 3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. The bed typically arrives in two boxes. If

any parts are missing or damaged, contact customer service.

## Components:

- Headboards and Footboards
- Side Rails (Upper and Lower)
- Ladder Components
- Slide Components
- Bed Slats
- Hardware (Screws, Bolts, Dowels, etc.)
- Assembly Tools (Hex Key, Screwdriver)

## 4. SETUP AND ASSEMBLY

---

Assembly requires two adults and approximately 2-3 hours. Follow the steps carefully. It is recommended to assemble the bed in the room where it will be used.

### Assembly Video Guide:



Video 4.1: Official Bellemave Floor Bunk Bed with Slide Assembly Instructions. This video provides a visual step-by-step guide for assembling the bunk bed.

### Step-by-Step Assembly (Refer to video for visual aid):

1. **Prepare End Panels:** Assemble the headboard and footboard sections using the provided hardware (dowel pins and long screws).
2. **Assemble Side Rails:** Attach the horizontal side rails to the vertical posts, ensuring proper alignment and secure fastening.
3. **Connect Bed Ends:** Join the assembled end panels with the side rails to form the main bed frame structure.
4. **Assemble Ladder:** Construct the ladder by attaching the rungs to the ladder side pieces.
5. **Assemble Slide:** Construct the slide by attaching the slide surface to the slide side rails.
6. **Attach Ladder and Slide:** Securely attach the ladder and slide to the main bed frame. These components are convertible and can be placed on either side.
7. **Install Bed Slats:** Place and secure the wooden bed slats onto the support rails for both the upper and lower bunks. Ensure all slats are evenly spaced and firmly attached.
8. **Final Checks:** Verify that all bolts, screws, and fasteners are tightened. Ensure the bed is stable and level.

*Note: The bed has three different assembly methods, allowing for conversion into a loft bed or two separate beds. Refer to the included paper manual for detailed diagrams of these configurations.*

## 5. OPERATING INSTRUCTIONS

---

Once assembled, the bunk bed is ready for use. Ensure children understand the proper use of the bed and slide.

- **Sleeping:** Place appropriate twin-sized mattresses on both the upper and lower bunks.
- **Ladder Use:** Always use the ladder to access the upper bunk. Do not climb on the side rails or other parts of the bed.
- **Slide Use:** Use the slide in a seated position, feet first. Ensure the landing area is clear.
- **General Use:** Avoid jumping on the bed or engaging in rough play that could compromise the bed's stability.

## 6. MAINTENANCE

---

Regular maintenance will prolong the life and safety of your bunk bed.

- **Cleaning:** Wipe down the wood surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. For deeper cleaning, use a mild soap solution and dry immediately.
- **Tighten Fasteners:** Periodically check all bolts, screws, and connections. Tighten them as needed to ensure the bed remains sturdy and safe. This should be done at least once every three months or if any wobbling is detected.
- **Inspect for Damage:** Regularly inspect the bed frame, ladder, and slide for any signs of wear, cracks, or damage. If damage is found, discontinue use and contact customer service for replacement parts or repair advice.
- **Mattress Care:** Follow the manufacturer's instructions for mattress care.

## 7. TROUBLESHOOTING

---

Common issues and their solutions:

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose fasteners.	Check and tighten all bolts and screws. Ensure all components are correctly aligned.
Squeaking noises.	Friction between wood parts or loose connections.	Tighten all fasteners. Apply a small amount of paraffin wax or silicone spray to contact points between wood pieces if squeaking persists.
Slide or ladder feels loose.	Improper attachment or loose hardware.	Verify that the ladder and slide are correctly installed according to the assembly instructions. Tighten all associated hardware.
Missing parts upon delivery.	Shipping error or packaging issue.	Contact Bellemave customer service immediately with your order details and a list of missing parts.

## 8. SPECIFICATIONS

---

Feature	Detail
Model Number	LK8K
Product Dimensions	77.29"L x 87.1"W x 54.1"H
Size	Twin Over Twin
Color	White
Finish Type	Wood
Material	Solid Pine Wood
Upper Bunk Weight Capacity	175 lbs

Feature	Detail
Lower Bunk Weight Capacity	275 lbs
Number of Slats	8 plywood slats for upper/down bunk
Assembly Required	Yes
Item Weight	121 pounds
UPC	733805235000

## 9. WARRANTY AND SUPPORT

---

Bellemave is committed to providing high-quality furniture and excellent customer satisfaction. For any inquiries regarding your product, including warranty claims, missing parts, or assembly assistance, please contact Bellemave customer service.

You can often find support contact information on the original packaging, purchase receipt, or by visiting the official Bellemave store on the platform where you purchased the product. Your satisfaction is our greatest motivation.

For more information and to explore other products, visit the [Bellemave Store](#).