

588562-00

Black & Decker Sander Dust Bag 588562-00 Replacement Instruction Manual

This manual provides instructions for the installation, operation, and maintenance of the 588562-00 replacement dust bag for compatible Black & Decker sanders.

1. PRODUCT OVERVIEW

This is a genuine OEM replacement dust bag, part number 588562-00, designed for various Black & Decker sander models. Its primary function is to collect dust and debris generated during sanding operations, contributing to a cleaner work environment and improved air quality.

Compatibility

This replacement dust bag is compatible with the following Black & Decker sander models:

- 11722
- BR318, BR318-B3, BR318-B3LZ
- DS321, DS321-B3, DS321-B3LZ
- STGS7221-AR, STGS7221-B2, STGS7221-B2C, STGS7221-B3, STGS7221-BR

2. SETUP: INSTALLATION INSTRUCTIONS

Follow these steps to properly install the replacement dust bag on your compatible Black & Decker sander.

- 1. Preparation:** Always ensure your sander is unplugged from the power source before attempting any installation, removal, or maintenance procedures.
- 2. Remove Old Dust Bag (if applicable):** If an old dust bag is currently attached, locate its connection point on the sander. This typically involves sliding it off a dust port or disengaging a clip. Carefully remove the old bag.
- 3. Attach New Dust Bag:** Align the opening of the new 588562-00 dust bag with the dust port on your Black & Decker sander. The plastic connector on the dust bag should match the shape of the sander's port.
- 4. Secure Connection:** Slide the dust bag firmly onto the port until it is securely seated. Some sander models may feature a specific clip or locking mechanism; ensure this is engaged to prevent accidental detachment.
- 5. Verify Attachment:** Gently tug on the dust bag to confirm it is securely attached and will not detach during sander operation.



An image showing the black fabric dust bag, featuring a zipper closure along one side and a rigid plastic connector designed for attachment to a sander's dust port. The bag is designed to collect sanding debris.

3. OPERATING: USAGE GUIDELINES

Once the dust bag is securely installed, you can operate your sander as usual. The dust bag will effectively collect sanding debris, contributing to a cleaner work area.

- **Monitor Dust Level:** Periodically check the dust bag during operation. A full dust bag will significantly reduce the sander's dust collection efficiency and can lead to dust escaping into the environment.
- **Empty Regularly:** For optimal performance and to prevent clogging, empty the dust bag before it becomes completely full.
- **Proper Disposal:** Dispose of collected dust and debris according to local environmental regulations and safety guidelines.

4. MAINTENANCE: CLEANING AND CARE

Regular cleaning and proper care of your dust bag will extend its lifespan and ensure continued effective dust collection.

1. **Emptying:** Detach the dust bag from the sander. If equipped with a zipper, unzip it and shake out the accumulated dust into a suitable waste receptacle.
2. **Cleaning (Optional):** For a more thorough cleaning, the fabric dust bag can be gently hand-washed with mild soap and cool water. Avoid harsh detergents or machine washing, which could damage the fabric.
3. **Drying:** Allow the dust bag to air dry completely before reattaching it to the sander. Ensure no moisture remains inside the bag, as this can lead to mold or mildew growth and affect performance.
4. **Inspection:** Periodically inspect the dust bag for any signs of wear, such as tears, holes, or damage to the zipper or attachment mechanism. Replace the bag if significant damage is found to maintain dust collection efficiency.

5. TROUBLESHOOTING COMMON ISSUES

Refer to the table below for solutions to common issues you might encounter with your dust bag.

Issue	Possible Cause	Solution
Poor Dust Collection	Dust bag is full.	Empty the dust bag.
	Dust bag is not securely attached.	Reattach the dust bag firmly to the sander's dust port.
	Dust bag is damaged (tear/hole).	Inspect the bag for damage; replace if necessary.
Dust Bag Detaches During Use	Improper attachment.	Ensure the dust bag is fully seated and any locking mechanisms are engaged.

6. PRODUCT SPECIFICATIONS


- Part Number:** 588562-00
- Material:** Fabric
- Color:** Black
- Dimensions (Approximate L x W x H):** 4.6 x 6.95 x 2.05 inches
- Item Weight (Approximate):** 1.06 ounces
- Power Source:** Manual (refers to the sander's dust collection mechanism)
- Compatible Devices:** Black & Decker Sanders (specific models listed in Compatibility section)




7. SUPPORT AND WARRANTY INFORMATION

As this is a replacement part, warranty coverage may vary. Please refer to the original product documentation or contact the seller from whom you purchased this item for specific warranty details and return policies.

For technical assistance regarding the operation or maintenance of your Black & Decker sander itself, please consult the sander's original instruction manual or contact the Black & Decker manufacturer's support channels directly.

Related Documents - 588562-00

	<p>Black & Decker KA88 Belt Sander Parts List and Diagram</p> <p>Comprehensive parts list and exploded view diagram for the Black & Decker KA88 Belt Sander. This document details all components with their respective part numbers, quantities, and descriptions, facilitating identification for maintenance and repair.</p>
---	---

	<p><u>Eberspächer Airtronic / Airtronic M Air Heaters: Technical Description, Installation, Operation, and Maintenance</u></p> <p>Comprehensive guide detailing the technical specifications, installation procedures, operating instructions, and maintenance requirements for Eberspächer Airtronic and Airtronic M series air heaters, designed for independent vehicle heating.</p>
	<p><u>Eberspächer Airtronic / Airtronic M: Tekninen kuvaus, asennus-, käyttö- ja huolto-ohjeet</u></p> <p>Tämä Eberspächerin Airtronic ja Airtronic M -sarjan ilmalämmittimien tekninen kuvaus, asennusopas, käyttöohjeet ja huolto-ohjeet tarjoaa kattavaa tietoa laitteiden turvallisesta asennuksesta, käytöstä ja ylläpidosta. Nämä lämmittimet on suunniteltu tarjoamaan luotettavaa suorituskykyä ja mukavuutta erilaisissa ajoneuvoissa ja sovelluksissa.</p>
	<p><u>Black & Decker CM600 Type 1 Lawn Mower Parts List</u></p> <p>Detailed parts list and diagram for the Black & Decker CM600 Type 1 lawn mower, including part numbers and quantities. Information current as of 2005.</p>
	<p><u>NanoScope Nano Operative Arthroscopy System by Arthrex</u></p> <p>Explore the Arthrex NanoScope™ Nano Operative Arthroscopy System, a revolutionary 1.9 mm micro-arthroscopy system offering high-definition imaging, minimally invasive procedures, and advanced instrumentation for various surgical applications.</p>
	<p><u>Black+Decker KS701E Jigsaw Parts List</u></p> <p>Detailed parts list for the Black+Decker KS701E Jigsaw, including part numbers, descriptions, and quantities for identification and service.</p>