

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Coleshome](#) /

› Coleshome 61-Inch L-Shaped Computer Desk Instruction Manual

Coleshome 61-Inch L-Shaped Desk

Coleshome 61-Inch L-Shaped Computer Desk Instruction Manual

Model: 61-Inch L-Shaped Desk | Brand: Coleshome

[List](#) [Setup](#) [Operating](#) [Introduction](#) [Safety Information](#) [Parts](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the Coleshome 61-Inch L-Shaped Computer Desk. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your desk. Designed for versatility, this desk is suitable for home offices, gaming setups, writing, and general workstation needs, offering ample space and a sturdy structure.

2. SAFETY INFORMATION

Important Safety Precautions:

- Do not exceed the maximum weight limit of 220 lbs (approximately 100 kg) on the desktop surface.
- Ensure all monitors and equipment are securely placed to prevent tipping or falling.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Always assemble the desk on a soft, clean surface to avoid scratching the components.
- Regularly check all screws and connections to ensure they remain tight and secure.

3. PARTS LIST

Before beginning assembly, please verify that all components listed below are present and undamaged. All necessary tools are included with your purchase.

- Desktop Panels (L-shaped sections)
- Metal Frame Legs
- Support Beams/Crossbars
- Adjustable Foot Pads
- Assembly Hardware (screws, bolts, Allen wrench)
- Instruction Manual

4. SETUP AND ASSEMBLY INSTRUCTIONS

The Coleshome L-Shaped Desk is designed for easy assembly, typically requiring only one person. Follow these steps carefully:

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface. Compare them with the parts list to ensure everything is accounted for.
2. **Assemble Frame Sections:** Attach the metal frame legs to the support beams using the provided hardware. Pay close attention to the orientation of each piece as indicated in the detailed diagrams. Ensure all holes align correctly before tightening screws.
3. **Connect L-Shape:** Join the two main frame sections to form the L-shape. Secure them with the designated connectors and screws.
4. **Attach Desktop Panels:** Carefully place the desktop panels onto the assembled frame. Align the pre-drilled holes in the desktop with the holes in the frame. Secure the desktop panels using the provided screws.
5. **Install Adjustable Foot Pads:** Screw the adjustable foot pads into the bottom of each leg. These can be adjusted later to level the desk on uneven surfaces.
6. **Final Tightening:** Once all components are loosely assembled, go back and securely tighten all screws and bolts. Do not overtighten.
7. **Position the Desk:** Carefully lift and place the desk in its desired location. Adjust the foot pads as needed to ensure stability.

Note: While assembly is straightforward, careful attention to detail, especially regarding component orientation and screw alignment, is crucial for a sturdy and stable desk.



Image 1: Diagram illustrating the dimensions of the Coleshome 61-Inch L-Shaped Computer Desk, showing measurements for length, width, and height.

Your browser does not support the video tag.

Video 1: An official video from Coleshome demonstrating the assembly and features of the L-shaped desk, highlighting its design and functionality.

5. OPERATING INSTRUCTIONS

The Coleshome L-Shaped Desk is designed for versatile use in various environments:

- **Placement:** Position the desk in a corner or against a wall to maximize space utilization. Ensure adequate clearance for movement and chair rotation.
- **Workstation Setup:** The L-shape provides ample surface area for multiple monitors, keyboards, mice, and other peripherals, making it ideal for complex computer setups or creative work.
- **Weight Distribution:** Distribute weight evenly across the desktop surface. Avoid placing heavy items solely on one corner or edge.
- **Leg Room:** The open design beneath the desk provides generous leg room, allowing for comfortable seating and movement of office chairs without obstruction.




Image 2: The Coleshome L-Shaped Desk configured as a gaming workstation, featuring multiple monitors, a gaming PC, and peripherals, demonstrating its spacious design.

6. MAINTENANCE

To keep your Coleshome L-Shaped Desk in excellent condition, follow these simple care instructions:

- **Cleaning:** Wipe the desktop surface with a damp cloth to remove dust and spills. For more stubborn marks, use a mild cleaning solution and then wipe dry immediately.
- **Drying:** Always wipe the desk dry with a clean, dry cloth after cleaning to prevent water damage or streaks.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong solvents, or harsh chemicals, as these can damage the finish of the desk.
- **Heat Protection:** Use coasters or protective pads under hot items to prevent heat marks on the desktop.
- **Regular Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.



Image 3: A close-up view of the desktop surface, highlighting the high-quality, anti-scratch, waterproof, and easy-to-clean wood finish of the Coleshome L-Shaped Desk.

7. TROUBLESHOOTING

If you encounter any issues with your Coleshome L-Shaped Desk, refer to the following common problems and solutions:

- **Desk is Wobbly:**
 - Ensure all screws and bolts are fully tightened.
 - Adjust the foot pads on each leg to level the desk on uneven floors.
 - Verify that the frame sections are correctly aligned and securely connected.
- **Parts Do Not Align During Assembly:**

- Double-check the instruction manual for correct orientation of each part. Some parts may appear similar but have specific alignment requirements.
 - Loosen all connections slightly, adjust the parts into alignment, and then retighten.
- **Scratches or Damage to Desktop:**
 - The desktop is designed to be wear-resistant. For minor scratches, furniture repair pens or waxes may help.
 - For significant damage, contact customer service for potential solutions or replacement parts.



Image 4: A close-up view of the sturdy metal frame and adjustable foot pads of the Coleshome L-Shaped Desk, emphasizing its robust construction and stability features.

8. SPECIFICATIONS

Feature	Detail
Brand	Coleshome
Model Name	Coleshome 61 L Shaped Desk Computer Desk
Product Dimensions (D x W x H)	60.6"D x 47.2"W x 29.1"H
Color	Pure Black
Style	Modern

Feature	Detail
Base Material	Metal
Top Material Type	Metal, Wood
Finish Type	Wood
Maximum Weight Recommendation	220 Pounds
Item Weight	18.62 Kilograms
Required Assembly	Yes
Recommended Number of People for Assembly	1
Includes All Assembly Tools	Yes

9. WARRANTY AND SUPPORT

Coleshome is committed to customer satisfaction. If you encounter any issues regarding product quality or experience any problems during use, please do not hesitate to contact our customer service team. Your satisfaction is our priority, and we are available to assist you.

For support, please refer to the contact information provided with your purchase or visit the official Coleshome website.