Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Zunate Zunateaxzdi5kgwg7408

Zunate Universal 3.5mm FM Radio Antenna Instruction Manual

Model: Zunateaxzdi5kgwg7408

1. Introduction

This manual provides instructions for the proper installation, operation, and maintenance of your Zunate Universal 3.5mm FM Radio Antenna. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Image 1.1: The Zunate Universal 3.5mm FM Radio Antenna. This image displays the antenna's full length, featuring a black, flexible rod with a 90-degree angled 3.5mm jack at one end.

2. Important Safety Information

Please observe the following safety guidelines:

- Do not expose the antenna to extreme temperatures or direct sunlight for extended periods.
- Keep the antenna away from water and moisture.
- Avoid bending or twisting the antenna excessively, as this may damage internal components.
- Do not attempt to disassemble or modify the antenna.
- Keep out of reach of children.

3. Package Contents

Verify that all items are present in your package:

- 1 x Zunate Universal 3.5mm FM Radio Antenna

4. Setup Guide

The Zunate Universal 3.5mm FM Radio Antenna is designed for simple plug-and-play functionality.

4.1 Connecting the Antenna

1. Locate the 3.5mm audio jack on your compatible device (e.g., FM radio, mini speaker, mobile phone with FM radio function).
2. Insert the 3.5mm plug of the antenna firmly into the device's 3.5mm audio jack. Ensure a secure connection.



Image 4.1: The antenna connected to a portable radio. This image shows the 3.5mm jack of the antenna inserted into the corresponding port on a red and black portable radio, demonstrating the connection process.



Image 4.2: A close-up view of the 3.5mm jack. This image highlights the gold-plated tip and rings of the 3.5mm connector, emphasizing the connection interface.

4.2 Compatibility

This antenna is compatible with devices that utilize a 3.5mm audio jack for FM radio reception, such as:

- FM radio card speakers
- Mobile phones with built-in FM radio functionality
- Other portable audio devices requiring an external FM antenna via a 3.5mm interface



Image 4.3: The antenna connected to a radio with 'Plug and Play' text. This image visually reinforces the ease of use, showing the antenna extending from a portable radio with a Wi-Fi signal icon, indicating enhanced reception.

5. Operating Instructions

Once the antenna is connected, your device should automatically recognize it as the external FM antenna.

1. **Power On:** Turn on your FM radio device.
2. **Tune to FM:** Switch your device to FM radio mode.
3. **Scan for Stations:** Use your device's tuning or scanning function to find available FM radio stations.
4. **Optimize Reception:** For best reception, try repositioning the antenna. Extending it vertically or horizontally may improve signal strength depending on your environment.

The antenna enhances the signal receiving capability, allowing for clearer and more stable FM radio reception.

6. Care and Maintenance

- **Cleaning:** Wipe the antenna with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the antenna in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Handling:** Handle the antenna gently to avoid damage to the connector or the rod.

7. Troubleshooting

Problem	Possible Cause	Solution
Poor or no FM reception	Antenna not fully connected Weak signal area Interference from other electronics	Ensure the 3.5mm jack is securely inserted. Reposition the antenna or move to a different location. Move away from other electronic devices that may cause interference.
Antenna does not fit device	Device does not have a 3.5mm audio jack Device's 3.5mm jack is not for FM antenna input	Verify your device has a standard 3.5mm audio jack that supports external FM antennas. Consult your device's manual.

8. Technical Specifications

Feature	Specification
Model	Zunateaxzdi5kgwg7408
Interface	3.5mm Jack
Antenna Type	FM Radio Antenna
Product Dimensions	Approximately 0.39 x 0.39 x 0.39 inches (Note: This dimension seems to be for packaging or a component, actual antenna length is longer as seen in images)
Item Weight	0.188 ounces
Impedance	50 Ohm
Maximum Range	3.5 Meters (This likely refers to effective reception range, not physical length)
Number of Channels	1

9. Warranty and Customer Support

For warranty information or technical assistance, please contact Zunate customer support through the retailer where the product was purchased or visit the official Zunate website. Please have your model number (Zunateaxzdi5kgwg7408) available when contacting support.

© 2023 Zunate. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09BHZNYB9

More documents and user manuals: **https://manuals.plus/**