

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Spare Part](#) /

› [Instruction Manual for Spare Part Oven Bake Element \(Part Number 316075104\) Compatible with Frigidaire Ovens](#)

Spare Part 316075104

Instruction Manual for Spare Part Oven Bake Element

Part Number: 316075104

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of the Spare Part Oven Bake Element, Part Number 316075104. This component is designed as a compatible replacement for various Frigidaire oven models. Please read this manual thoroughly before attempting any installation or repair to ensure safe and correct usage.

2. PRODUCT OVERVIEW

The oven bake element is a critical component responsible for generating heat during the baking cycle in an electric oven. This replacement element is constructed from durable nickel stainless steel alloy, designed for longevity and reliable performance.



Figure 1: Spare Part Oven Bake Element. This image displays the M-shaped heating element with terminal ends and mounting brackets.

3. SPECIFICATIONS

Part Number	316075104
Replaces Part Numbers	316075100, 316075102, 316075103, 316282600, 3203534, 5303051519
Rated Power	2600 Watts at 240 Volts
Dimensions (Front to Mounting Bracket)	15 1/2 inches (39.37 cm)
Width (at Front)	19 3/8 inches (49.21 cm)
Width (at Mounting Bracket)	14 inches (35.56 cm)
Mounting Bracket to Terminal End	3 1/2 inches (8.89 cm)
Material	Nickel Stainless Steel Alloy
Product Dimensions (Overall)	20 x 19 x 2 inches (50.8 x 48.26 x 5.08 cm)
Weight	9.6 ounces (272 grams)
UPC	092742234652
ASIN	B09BJRMBVC

4. COMPATIBILITY

This bake element is compatible with various Frigidaire oven models, including but not limited to:

- FFEF3015PBD
- FEF369CGSB
- CFEF3055TWB
- MEF300PXWD
- FFEF3015PBB
- CE303VP2W01-00
- FEF336BCH
- FEFL67GCA
- FEF326AQE

Note: Always verify the part number and dimensions against your existing element and oven model before purchase and installation.

5. SAFETY INFORMATION

WARNING: Before attempting any repair or installation on an electrical appliance, always disconnect the appliance from its power source. Failure to do so can result in electric shock, personal injury, or death. If you are unsure about performing this repair, it is recommended to consult a qualified technician.

- Ensure the oven is completely cool before beginning work.

- Wear appropriate personal protective equipment, such as gloves.
- Keep children and pets away from the work area.
- Do not use damaged tools or equipment.

6. INSTALLATION INSTRUCTIONS

This section outlines the general steps for replacing an oven bake element. Specific steps may vary slightly depending on your oven model. Refer to your oven's service manual for detailed instructions if available.

1. **Disconnect Power:** Unplug the oven from the wall outlet or turn off the circuit breaker supplying power to the oven. Verify power is off before proceeding.
2. **Access Oven Interior:** Open the oven door and locate the bake element at the bottom of the oven cavity.
3. **Remove Mounting Screws:** Using a screwdriver, remove the screws that secure the bake element to the back wall of the oven.
4. **Carefully Pull Element Forward:** Gently pull the element forward a few inches. This will expose the electrical terminals at the back.
5. **Disconnect Wires:** Note the position of the wires on the old element. Carefully disconnect the wires from the terminals. It may be helpful to take a picture before disconnecting. Ensure the wires do not fall back into the oven wall.
6. **Remove Old Element:** Once wires are disconnected, remove the old bake element from the oven.
7. **Install New Element:** Connect the wires to the terminals of the new bake element, ensuring they are securely attached.
8. **Secure New Element:** Push the new element into place, aligning the mounting brackets with the screw holes. Reinstall the mounting screws.
9. **Restore Power:** Close the oven door. Restore power to the oven by plugging it back in or turning on the circuit breaker.
10. **Test Functionality:** Turn on the oven to a bake setting and observe if the new element heats up properly.

7. OPERATING INSTRUCTIONS

As a component part, the bake element operates automatically as part of your oven's heating system. Once installed, its function is to heat when the oven is set to a bake cycle. No direct user operation of the element is required.

8. MAINTENANCE

The bake element generally requires minimal maintenance. To prolong its lifespan and ensure efficient operation:

- Avoid spilling food directly onto the element.
- Clean the oven cavity regularly according to your oven manufacturer's instructions.
- Do not use abrasive cleaners or sharp objects on the element.

9. TROUBLESHOOTING

This replacement element is designed to address common oven heating issues. If your oven was experiencing any of the following symptoms, this element is intended to provide a solution:

- Little to no heat when baking
- Element will not heat

- Oven not heating evenly
- Oven will not start (due to a faulty bake element)

If these symptoms persist after proper installation, further diagnosis of your oven's control board, thermostat, or other components may be necessary.

10. WARRANTY AND SUPPORT

This product is a generic replacement part and is not manufactured by or covered under any OEM (Original Equipment Manufacturer) warranty. The OEM brand names and logos mentioned are registered trademarks of their respective owners and are used solely for demonstrating compatibility.

A **30-day money-back guarantee** is offered from the date of purchase. If you are not satisfied with the product, a refund will be provided. For support or warranty claims, please contact your retailer.