Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EIH P1001

EIH Baby Playpen Instruction Manual

Model: P1001

Product Overview

The EIH Baby Playpen provides a safe and spacious environment for babies and toddlers to play indoors or outdoors. Designed with durable and child-safe materials, it offers a secure area for your child's activities while allowing for easy supervision.



Image: The EIH Baby Playpen in dark gray, filled with colorful ocean balls, showcasing its spacious design.

Safety Information

- Always supervise children when they are in the playpen.
- Ensure all parts are securely assembled before placing a child inside.
- Do not place the playpen near stairs, windows, or heat sources.
- Regularly inspect the playpen for any signs of wear or damage. Discontinue use if any part is broken or missing.
- The playpen is designed for children over 6 months of age.
- The external double zipper is designed to prevent accidental climbing out by the child.

Package Contents

Verify that all components are present before assembly:




Image: All components included in the package, such as steel pipes, connectors, pull rings, storage bag, and 50 ocean balls.

- 620mm Steel Pipes: 8 pieces
- 640mm Steel Pipes: 16 pieces
- Tee Connectors: 4 pieces
- Suction Cup Three-Link Connectors: 4 pieces
- Straight Three-Link Connectors: 8 pieces
- Playpen Fabric Cover: 1 piece
- Storage Bag: 1 piece
- Pull Rings: 2 pieces
- Ocean Balls: 50 pieces

Setup and Assembly

Follow these steps to assemble your EIH Baby Playpen:

1. Unroll the entire playpen fabric cover and lay it flat on the floor.
2. Insert the 620mm and 745mm steel pipes into the corresponding sleeves of the fabric cover. Ensure the pipes are fully inserted.
3. Connect the pipes using the appropriate Tee, Suction Cup Three-Link, and Straight Three-Link connectors. The snap design makes assembly easier.
4. Ensure all connections are secure and the frame is stable. The strong suction cups at the base provide additional stability.
5. Zip up the external door from the outside to secure the play area.
6. Attach the pull rings to the top rail of the playpen as desired.
7. Place the 50 ocean balls inside the playpen for your child to enjoy.



Image: Detailed view of the playpen's features, including the easy-to-disassemble zipper, thickened corners for safety, and the snap design for simplified assembly.

Image: A close-up showing the strong suction cap at the base, designed to enhance the playpen's stability.

Operating Instructions

The EIH Baby Playpen is designed for ease of use and child safety:

- **Entry and Exit:** The playpen features an external double zipper door for easy entry and exit for both children and adults. Always ensure the zipper is closed when the child is inside to prevent accidental climbing out.
- **Visibility:** The soft and breathable mesh walls provide a 360-degree view, allowing parents to easily monitor their child's activities.
- **Play Area:** The spacious interior (approximately 15.34 square feet) provides ample room for your child to play, crawl, and stand comfortably.
- **Portability:** For travel or storage, the playpen can be disassembled and stored in the included portable carry bag.

Image: A parent interacting with a baby through the external zipper crawling design, highlighting easy access.



Image: A mother and baby playing together inside the spacious EIH playpen, demonstrating the ample play area.

Maintenance

To ensure the longevity and hygiene of your EIH Baby Playpen:

- **Cleaning:** The fabric cover can be wiped clean with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Allow all parts to air dry completely before reassembling or storing to prevent mold and mildew.
- **Storage:** When not in use, disassemble the playpen and store it in the provided portable carry bag in a cool, dry place away from direct sunlight.



Image: Close-up of the 300D Oxford Fabric, highlighting its durable and environmentally friendly quality.

Troubleshooting

If you encounter any issues with your playpen, refer to the following common solutions:

- **Difficulty Assembling:** Ensure all pipes are correctly oriented and fully inserted into the connectors. Refer to the assembly steps and check that you have the correct number and type of pipes and connectors.
- **Playpen Instability:** Verify that all suction cups at the base are firmly pressed onto a smooth, clean surface. Ensure all pipe connections are tight and secure.
- **Zipper Malfunction:** Check for any fabric caught in the zipper. Ensure the zipper is aligned correctly before attempting to close it.
- **Missing Parts:** If any parts are missing upon arrival, please contact customer support immediately.

Specifications

Feature	Detail
Model Number	P1001
Dimensions (Assembled)	Approximately 47 in x 47 in x 27 in (Length x Width x Height)
Floor Area	15.34 Square Feet
Weight	13.52 pounds
Maximum Weight Recommendation	180 Pounds
Material	Oxford Cloth, Plastic, Soft Fabric
Color	Dark Grey
Included Accessories	50 Ocean Balls, 2 Pull Rings, Storage Bag



Image: Visual representation of the playpen's dimensions (47 inches by 47 inches by 27 inches high).

Warranty and Support

For any product-related inquiries, issues, or warranty claims, please contact EIH customer support. We are committed to ensuring your satisfaction and will respond to your concerns within 8 hours.
Please refer to your purchase documentation for specific warranty terms and contact information.

© 2023 EIH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09BKT97T5

More documents and user manuals: **https://manuals.plus/**