

Manuals.plus /

> MEWOOCUE /

> MEWOOCUE Gaming Mouse Pad Instruction Manual (Model 01)

MEWOOCUE 01

MEWOOCUE Gaming Mouse Pad Instruction Manual

Model: 01 | Brand: MEWOOCUE

1. PRODUCT OVERVIEW

The MEWOOCUE Gaming Mouse Pad (Model 01) is a large desk mat designed for gaming, office, and home use. It features a smooth surface for precise mouse control, a non-slip rubber base for stability, and a waterproof coating for easy cleaning. The design showcases the iconic 'Great Wave off Kanagawa' artwork, adding a stylish element to your workspace.

- Large Surface Area:** Provides ample space for your gaming mouse, full-size mechanical keyboard, and other desk items.
- Superior Control Surface:** Made with superfine fiber braided material for smooth mouse control and pinpoint accuracy.
- Non-Slip Base:** Dense, slip-resistant rubber shading firmly grips the desktop, ensuring the pad remains flat and stable.
- Waterproof & Easy to Clean:** Spill-proof coating protects against liquids. Can be wiped with a wet cloth or washed without fading.
- Durable Design:** Delicately stitched edges prevent fraying and peeling, ensuring long-lasting use.

2. SETUP INSTRUCTIONS

Setting up your MEWOOCUE Gaming Mouse Pad is a straightforward process.

- Unpack the Mouse Pad:** Carefully remove the mouse pad from its packaging. It may be rolled up; allow it to unroll and flatten naturally on your desk.
- Prepare Your Workspace:** Ensure your desk surface is clean and free of debris to allow the non-slip base to adhere properly.
- Position the Mouse Pad:** Place the mouse pad on your desired area of the desk. The non-slip rubber base will help it stay in place.
- Arrange Peripherals:** Position your keyboard, mouse, and other accessories on the pad as desired. The large surface provides flexibility for various setups.

Image: Top-down view of the MEWOOCUE mouse pad on a desk, showcasing its large size and how it accommodates a keyboard and mouse.

3. OPERATING INSTRUCTIONS

The MEWOOCUE Gaming Mouse Pad is designed for immediate use with your computer peripherals.

- **Mouse Movement:** Place your mouse on the smooth surface of the pad. The superfine fiber braided material ensures effortless gliding and precise tracking for all mouse types (optical, laser).
- **Keyboard Placement:** Your keyboard can be placed anywhere on the pad. The stable surface prevents unwanted movement during typing or gaming.
- **Enhanced Comfort:** The 3mm thick rubber bottom provides a comfortable experience for your wrists and forearms during extended use.

ULTRA SMOOTH SURFACE

Optimized for accurate optical tracking



Image: A hand demonstrating smooth mouse movement across the ultra-smooth surface of the MEWOOCUE mouse pad.

4. MAINTENANCE AND CLEANING

Maintaining your MEWOOCUE Gaming Mouse Pad is simple due to its durable and waterproof design.

- **Spot Cleaning:** For minor spills or dirt, simply wipe the affected area with a damp cloth or paper towel. The waterproof coating prevents liquids from soaking in.
- **Deep Cleaning:** For more thorough cleaning, the mouse pad can be hand-washed. Use mild soap and cold water. Gently rub the surface to remove dirt.
- **Drying:** After washing, rinse thoroughly and allow the pad to air dry completely. Do not machine wash or tumble dry.
- **Edge Care:** The stitched edges are designed to prevent fraying. Avoid harsh scrubbing on the edges to maintain their integrity.



Image: Demonstration of the mouse pad's waterproof feature, showing a liquid spill beading on the surface.

Video: Official MEWOOCUE video demonstrating the high-quality print, stitched edges, and waterproof properties of the mouse pad, including cleaning instructions.

5. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Mouse Pad Not Lying Flat:** If the mouse pad appears curled or uneven after unpacking, allow it to sit unrolled on a flat surface for 24-48 hours. The rubber material will naturally flatten out.
- **Mouse Tracking Issues:** Ensure the mouse pad surface is clean. Dust or debris can sometimes interfere with mouse sensors. If issues persist, try cleaning the mouse sensor.
- **Slipping on Desk:** Verify that the non-slip rubber base is clean and dry. Ensure the desk surface is also clean and smooth for optimal grip.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	MEWOOCUE
Model Number	01
Color/Design	A Kanagawa Surfing
Dimensions (L x W)	31.5" x 11.9" (80cm x 30cm)
Material	Rubber
Item Thickness	3 Millimeters
Item Weight	0.38 Kilograms
Special Features	Ergonomic, Non-slip, Washable, Waterproof
Recommended Uses	Gaming, Office, Home




Image: Visual representation of the mouse pad's dimensions (31.5 x 11.8 inches) and its suitability for dining tables, keyboard use, computer tables, and office desks.

7. WARRANTY AND SUPPORT

Your MEWOOCUE Gaming Mouse Pad is covered by a 30-day return policy. For any product-related inquiries, support, or warranty claims, please contact the manufacturer directly.

- **Return Policy:** 30 days from the date of purchase for refund or replacement.
- **Manufacturer:** MEWOOCUE
- **Contact:** Please refer to your purchase platform or the MEWOOCUE official store for specific contact information.

© 2026 MEWOOCUE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09BMTRLRP>

More documents and user manuals: <https://manuals.plus/>