

## FLOITTUY FLOITTUY 6-inch LED Mirror Digital Alarm Clock

# FLOITTUY 6-inch LED Mirror Digital Alarm Clock with Bluetooth Speaker User Manual

Model: B09BNRHC5V | Brand: FLOITTUY

## 1. INTRODUCTION

The FLOITTUY 6-inch LED Mirror Digital Alarm Clock is a versatile device combining a digital alarm clock with a Bluetooth speaker. It features a clear LED mirror display, dual alarm functionality with snooze, Bluetooth 5.0 connectivity, AUX input, TF/SD card playback, a sound recorder, and HD wireless calling capabilities. This manual provides detailed instructions for setup, operation, and maintenance of your device.

## 2. PACKAGE CONTENTS

- FLOITTUY 6-inch LED Mirror Digital Alarm Clock
- USB Charging Cable
- User Manual

## 3. PRODUCT FEATURES

- **6-inch LED Mirror Display:** Provides clear time and temperature readings, also functions as a mirror.
- **Dual Alarm with Snooze:** Set two independent alarms with a convenient snooze function.
- **Bluetooth 5.0 Speaker:** High-fidelity stereo sound with bass diaphragm for wireless audio streaming.
- **Multiple Playback Modes:** Supports AUX input and TF/SD card playback.
- **Sound Recorder:** Integrated recording function.
- **HD Wireless Calling:** Built-in microphone for hands-free calls.
- **Real-time Temperature Display:** Shows ambient temperature.
- **Adjustable Brightness:** Separate adjustments for night light (3 levels) and clock display (4 levels).
- **Integrated Phone Stand:** Convenient slot for holding a smartphone.

## 4. CONTROLS AND DISPLAY OVERVIEW

Familiarize yourself with the buttons and display elements of your alarm clock. The top panel typically houses control buttons, while the front features the LED mirror display.



Image 4.1: Front view of the FLOITTUY alarm clock, highlighting features like sound recorder, HD wireless calling, TF card slot, AUX input, temperature display, and Bluetooth 5.0. It also illustrates the night light and clock display brightness adjustments.



Image 4.2: Side view of the FLOITTUY alarm clock, showing the various input ports for charging and external connections.

### Button Functions (Typical Layout):

- **Power Button:** Press and hold to power on/off. Short press to switch modes.
- **Mode Button (M):** Short press to cycle through modes (Clock, Bluetooth, AUX, TF).
- **Play/Pause Button (▶/⏸):** Play/pause music. Answer/end calls.
- **Volume Up (+)/Next Track:** Short press for volume up. Long press for next track.
- **Volume Down (-)/Previous Track:** Short press for volume down. Long press for previous track.
- **Alarm Set Button:** Press to enter alarm setting mode.
- **Snooze Button:** Press to activate snooze during an alarm.
- **Brightness Button (\*):** Short press to adjust night light brightness. Long press to adjust clock display brightness.

## 5. SETUP

### 5.1 Initial Charging

Before first use, fully charge the alarm clock. Connect the provided USB charging cable to the charging port on the device and to a standard USB power adapter (not included) or a computer USB port. The charging indicator will illuminate and turn off once fully charged.

## 5.2 Powering On/Off

- **To Power On:** Press and hold the Power button for approximately 3 seconds. The display will light up.
- **To Power Off:** Press and hold the Power button for approximately 3 seconds. The display will turn off.

## 6. OPERATING INSTRUCTIONS

### 6.1 Setting the Time

1. In clock display mode, press and hold the **Mode (M)** button until the hour digits begin to flash.
2. Use the **Volume Up (+)** or **Volume Down (-)** buttons to adjust the hour.
3. Press the **Mode (M)** button again to switch to minute setting. The minute digits will flash.
4. Use the **Volume Up (+)** or **Volume Down (-)** buttons to adjust the minutes.
5. Press the **Mode (M)** button once more to confirm and exit time setting.

### 6.2 Setting Alarms (Dual Alarm)

This device supports two independent alarms (Alarm 1 and Alarm 2).

1. Press the **Alarm Set** button. "AL1" will appear, and the hour digits for Alarm 1 will flash.
2. Use the **Volume Up (+)** or **Volume Down (-)** buttons to set the desired hour for Alarm 1.
3. Press the **Alarm Set** button again to switch to minute setting for Alarm 1. Use **Volume Up (+)** or **Volume Down (-)** to set minutes.
4. Press the **Alarm Set** button again to set Alarm 2 (repeat steps 2-3 for "AL2").
5. After setting Alarm 2, press the **Alarm Set** button to confirm and exit.
6. To enable/disable an alarm, short press the **Alarm Set** button to cycle through AL1 ON, AL2 ON, AL1&AL2 ON, ALARMS OFF.

#### Snooze Function:

When an alarm sounds, press the **Snooze** button to temporarily silence it. The alarm will sound again after a few minutes (typically 5-10 minutes). To turn off the alarm completely, press any other button.

### 6.3 Bluetooth Mode

1. Press the **Mode (M)** button until "BT" appears on the display, indicating Bluetooth mode. The device will enter pairing mode.
2. On your mobile device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "FLOITTUY" from the list of devices to pair. A confirmation sound will indicate successful pairing.
4. You can now play audio from your device through the alarm clock speaker.



Image 6.3.1: The alarm clock demonstrating Bluetooth and wired connection capabilities with a desktop, laptop/iPad, and smartphone.

## 6.4 AUX Input Mode

1. Connect one end of a 3.5mm audio cable (not included) to the AUX port on the alarm clock.
2. Connect the other end of the audio cable to the headphone jack or AUX output of your external audio device.
3. Press the **Mode (M)** button until "AUX" appears on the display.
4. Audio from your external device will now play through the alarm clock speaker. Control playback from your external device.

## 6.5 TF/SD Card Playback Mode

1. Insert a TF/SD card (with MP3 audio files) into the TF card slot on the device.
2. Press the **Mode (M)** button until "TF" appears on the display.
3. The device will automatically begin playing audio files from the card.
4. Use the **Play/Pause**, **Volume Up (+)**, and **Volume Down (-)** buttons to control playback.

## 6.6 Adjusting Brightness

The alarm clock offers separate brightness controls for the night light and the main clock display.

- **Night Light Adjustment:** Short press the **Brightness** (\*) button to cycle through three levels: Bright, Dark, Off.
- **Clock Display Brightness Adjustment:** Long press the **Brightness** (\*) button to cycle through four levels: Dark, A Little Bright, Bright, Off.

## 6.7 Sound Recorder Function

Specific instructions for the sound recorder function are typically detailed in the product's original manual. Generally, this involves entering a dedicated recording mode via the Mode button and using a specific button (often Play/Pause or a dedicated Record button) to start and stop recording. Playback of recordings is usually done through the TF card mode.

## 6.8 HD Wireless Calling

When connected via Bluetooth to a smartphone, the alarm clock can be used for hands-free calling.

- **Answering a Call:** When a call comes in, press the **Play/Pause** (▶ / ■ ■) button to answer.
- **Ending a Call:** During a call, press the **Play/Pause** (▶ / ■ ■) button to end the call.
- **Rejecting a Call:** Press and hold the **Play/Pause** (▶ / ■ ■) button to reject an incoming call.

## 6.9 Temperature Display

The device automatically displays the ambient temperature on the LED screen, alternating with the time display. No user input is required for this function.

## 6.10 Phone Stand and Mirror Function

The design of the alarm clock includes a slot that can serve as a mobile phone bracket, allowing you to prop up your smartphone. The reflective LED display also functions as a mirror when the display is off or at a low brightness setting.

## HIDE MODE

CAN BE USED AS  
A MOBILE PHONE BRACKET



CAN BE USED AS  
A MIRROR EVERYDAY




Image 6.10.1: The alarm clock demonstrating its 'hide mode' feature, functioning as a mobile phone bracket and a daily mirror.

## 7. MAINTENANCE

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in constant use.
- **Water Exposure:** This device is not waterproof. Avoid exposure to water or high humidity.

## 8. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem                    | Possible Cause                                                                   | Solution                                                                                                                                                               |
|----------------------------|----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Device does not power on.  | Low battery or no power.                                                         | Charge the device using the provided USB cable. Ensure the charging cable and adapter are working correctly.                                                           |
| Bluetooth not connecting.  | Device not in pairing mode; Bluetooth off on source device; too far from source. | Ensure the alarm clock is in Bluetooth mode ("BT" displayed). Turn Bluetooth off and on again on your source device. Move the source device closer to the alarm clock. |
| Alarm not sounding.        | Alarm is disabled; volume is too low.                                            | Check if the alarm is enabled (AL1/AL2 icon visible). Increase the volume.                                                                                             |
| Display is too dim or off. | Brightness setting is low or off.                                                | Long press the <b>Brightness (*)</b> button to adjust the clock display brightness.                                                                                    |
| Sound quality is poor.     | Low battery; source audio quality; interference.                                 | Charge the device. Try a different audio source or file. Move away from potential sources of interference.                                                             |

## 9. SPECIFICATIONS

- **Brand:** FLOITTUY
- **Model:** B09BNRHC5V
- **Display Type:** Digital LED Mirror
- **Connectivity:** Bluetooth 5.0, AUX Input, TF/SD Card Slot
- **Power Source:** Battery Powered (1 Lithium Polymer battery included)
- **Product Dimensions:** 5.5"W x 2.7"H
- **Material:** ABS+PC Mirror, Plastic Frame
- **Special Features:** Dual Alarm, Snooze, Sound Recorder, HD Wireless Calling, Temperature Display, Adjustable Brightness, Phone Stand

## 10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the retailer/manufacturer directly. Keep your purchase receipt as proof of purchase.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**