LG TONE-FP5W

LG Tone FP5 Wireless Earbuds Instruction Manual

Model: TONE-FP5W | Brand: LG

Introduction

Thank you for choosing the LG Tone FP5 Wireless Earbuds. These earbuds are designed to provide a superior audio experience with advanced features such as Active Noise Cancellation, Meridian Audio technology, and an ergonomic design for comfortable, secure fit. This manual will guide you through the setup, operation, and maintenance of your new earbuds.



Image: LG Tone FP5 Wireless Earbuds and their compact charging case.

What's in the Box

- LG Tone FP5 Wireless Earbuds
- Charging Case
- USB-C Charging Cable
- Multiple Sizes of Ear Tips (Small, Medium, Large)

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. Place the earbuds into the charging case. Connect the USB-C cable to the charging case and a power source. The indicator light on the case will show charging status.



Image: The LG Tone FP5 charging case with earbuds inside, indicating charging status.

Quick Charge Feature

The earbuds support quick charging. A 5-minute charge provides approximately 1 hour of playback time.



Image: Illustration of the quick charge capability, showing 5 minutes of charge for 1 hour of use.

2. Pairing with Your Device

Open the charging case. The earbuds will automatically enter pairing mode. On your device (smartphone, tablet, laptop), enable Bluetooth and select 'LG TONE FP5' from the list of available devices. The earbuds support Bluetooth 5.2 for stable connectivity.



Image: The LG Tone FP5 earbuds and case shown next to a laptop, demonstrating fast pairing.

3. LG TONE Free App

Download the LG TONE Free app from your device's app store. The app allows you to customize sound settings, manage Active Noise Cancellation, configure touch controls, and access features like 'Find My Earbuds'.



Image: Screenshot of the LG TONE Free app interface, highlighting customization options.

Operating Instructions

1. Wearing the Earbuds

Select the ear tips that provide the most comfortable and secure fit for your ears. The ergonomic design ensures the earbuds stay in place during various activities.



Image: Various sizes of hypoallergenic silicone gel ear tips for optimal comfort.



Image: A person wearing the earbuds during physical activity, demonstrating their secure and perfect fit.

2. Active Noise Cancellation (ANC)

Activate Active Noise Cancellation to minimize external distractions and immerse yourself in your audio. This feature can be controlled via the touch controls on the earbuds or through the LG TONE Free app.



Image: Visual representation of Active Noise Cancellation, showing sound waves being blocked.

3. Ambient Sound & Conversation Modes

Switch to Ambient Sound Mode to hear your surroundings without removing the earbuds. Conversation Mode enhances voices, allowing for clear communication while keeping your earbuds in place. These modes are accessible via touch controls or the app.



Image: Icons illustrating Ambient Mode (hearing traffic) and Conversation Mode (hearing speech).

4. Clear Calls with Dual Microphones

The earbuds feature a dual microphone system for clear and crisp calls. This technology reduces external noise and cancels echo, ensuring your voice is heard clearly.



Image: Diagram showing the placement of the three microphones (exterior, interior, voice) for enhanced call clarity.

5. Meridian Audio & Sound Features


Experience high-resolution, realistic, and immersive sound with powerful bass, thanks to Meridian Audio technology and Headphone Spatial Processing. Enjoy nuanced sound with Digital Signal Processing (DSP), Meridian Lossless Packing (MLP), and Master Quality Authenticated (MQA) support.



Image: Exploded view of an earbud highlighting the Flex Action Bass technology for powerful low frequencies.

Almohadillas de Gel de Silicona

Hipoalergénicos y Cómodos



* Este dispositivo o cualquiera de sus partes no tiene la intención ni está implícito para prevenir o tratar ninguna condición de salud; no es un dispositivo médico, ni para usarse como tal o para reemplazar un dispositivo médico.
* El material base del gel de silicona para los oídos cumple con los requisitos de ISO 10993 y USP Clase VI

Image: A person enjoying music with the earbuds, illustrating the immersive 3D Sound Stage.



Image: Visuals representing Digital Signal Processing, Meridian Lossless Packing, and Master Quality Authenticated for high-fidelity audio.

6. Long-Lasting Battery

Enjoy up to 22 hours of total battery life with the charging case (earbuds + case). The earbuds provide extended playback on a single charge.



Image: The earbuds with a large '22 hrs' graphic, emphasizing long battery duration.

7. Private Mode

Utilize Private Mode for enhanced privacy during calls or when listening to sensitive content, ensuring your audio remains confidential.



Image: A person using the earbuds, with text indicating 'Private Mode' for privacy protection.

Maintenance

1. Cleaning

Regularly clean your earbuds and charging case with a soft, dry cloth. Remove ear tips and clean them with mild soap and water, ensuring they are completely dry before reattaching.

2. Water Resistance (IPX4)

The LG Tone FP5 earbuds are IPX4 water-resistant, meaning they are protected against splashing water from any direction. This makes them suitable for workouts and light rain, but they are not designed for submersion in water.



Image: The earbuds shown with water splashes, illustrating their IPX4 water resistance rating.

Troubleshooting

If you encounter any issues with your LG Tone FP5 earbuds, please refer to the following common solutions:

- **No Sound:** Ensure earbuds are charged and properly paired. Check device volume.
- **Pairing Issues:** Turn off Bluetooth on your device, then turn it back on. Reset the earbuds by placing them in the case, closing it, and then reopening.
- **Poor Sound Quality:** Ensure ear tips provide a good seal. Check audio source quality. Adjust equalizer settings in the LG TONE Free app.
- **ANC Not Working:** Verify ANC is enabled via touch controls or the app. Ensure earbuds are properly seated in your ears.
- **Battery Draining Quickly:** Reduce volume. Disable ANC if not needed. Ensure earbuds are placed correctly in the charging case when not in use.

For more detailed troubleshooting, consult the LG TONE Free app or the official LG support website.

Specifications

Feature	Specification
Model Name	TONE-FP5W
Brand	LG
Color	White
Connectivity Technology	Wireless (Bluetooth 5.2)
Noise Control	Active Noise Cancellation

Feature	Specification
Total Battery Life (Earbuds + Case)	Up to 22 Hours
Quick Charge	5 minutes charge for 1 hour playback
Water Resistance	IPX4 (Splash-proof)
Weight (Product)	160 Grams (including case)
Compatible Devices	Smartphones, Laptops, Tablets, Desktops
Control Type	Media Control, Remote Control
Material	Synthetic Leather (likely case detail)

Warranty and Support

Your LG Tone FP5 Wireless Earbuds come with a standard manufacturer's warranty. For detailed warranty information, product registration, and technical support, please visit the official LG website or contact LG customer service.
You can also find more information and support on the LG Brand Store on Amazon.