Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- HOMCOM /
- > HOMCOM Corner TV Stand Model 839-049 Instruction Manual

HOMCOM 839-049

HOMCOM Corner TV Stand Model 839-049 Instruction Manual

Model: 839-049 | Brand: HOMCOM

1. Introduction

This manual provides comprehensive instructions for the assembly, setup, operation, and maintenance of your HOMCOM Corner TV Stand, Model 839-049. Designed to fit neatly into room corners, this entertainment center accommodates TVs up to 50 inches and features integrated storage solutions. Please read this manual thoroughly before beginning assembly and retain it for future reference.

2. SAFETY INFORMATION

Important Safety Guidelines:

- Assembly required. Keep away from heat sources and excessive moisture.
- Do not place heavy objects on the open back compartment to prevent tip-over.
- Always follow the assembly instructions carefully.
- Ensure all connections are secure before placing a television or other items on the stand.
- Distribute weight evenly across the stand's surfaces.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- All necessary wood panels (top, side, bottom, back, drawer components)
- Hardware pack (screws, dowels, cam locks, drawer slides, handles)
- Instruction manual



Figure 3.1: Front view of the assembled HOMCOM Corner TV Stand.

4. ASSEMBLY INSTRUCTIONS

This product requires assembly. Please follow the detailed instructions provided in the separate assembly guide included with your package. Ensure you have adequate space and the necessary tools (typically a screwdriver) before starting.

- 1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the parts list in your assembly guide to identify each piece.
- 2. **Assemble Frame:** Begin by connecting the side panels to the base and top panel using the provided hardware. Ensure all connections are tightened securely.
- 3. **Install Drawer Slides:** Attach the drawer slides to the interior side panels as indicated in the assembly guide.
- 4. **Assemble Drawers:** Construct the two pull-out drawers. Attach the drawer handles.
- 5. **Insert Drawers:** Carefully slide the assembled drawers onto the installed drawer slides.
- 6. Final Checks: Verify that all screws are tightened and the stand is stable.



Figure 4.1: Detailed dimensions of the TV stand, including length, width, and height.

CORNER TV CABINET Save A Lot of Space Trapezoidal Can be placed in the corner

Figure 4.2: Illustration of the trapezoidal shape designed for corner placement.

5. SETUP

Once assembled, position the TV stand in your desired corner location. The trapezoidal design ensures a snug fit. This stand is suitable for televisions up to 50 inches. Ensure the TV's base fits within the 37.5-inch width of the stand's top surface.



Figure 5.1: The TV stand positioned in a corner, showcasing its functional use with a television and media player.



Figure 5.2: Visual guide indicating the stand's capacity to hold TVs up to 50 inches.

6. Operating the Storage Features

The HOMCOM Corner TV Stand offers versatile storage options:

- **Open Compartment:** Ideal for media devices such as DVD players, gaming consoles, or soundbars. The open back design facilitates easy access for cable management and ventilation.
- **Pull-out Drawers:** Two drawers provide concealed storage for remotes, game controllers, video games, or other small accessories.

AMPLE STORAGE

For storing books, decorations, DVDS and more

- ① 1 Compartment ② 2 Drawer
- 3 Hollowed-out design for easy going through the cables



Figure 6.1: The TV stand displaying its open compartment for media devices and two pull-out drawers for storage.




Figure 6.2: A close-up of an open drawer, highlighting the storage space.

7. MAINTENANCE

To maintain the appearance and longevity of your TV stand:

- **Cleaning:** Wipe surfaces with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- Spills: Clean spills immediately to prevent staining or damage to the engineered wood.
- Stability Check: Periodically check all screws and connections to ensure they remain tight and secure.
- **Elevated Design:** The 3.25-inch height of the supporting base allows for easy cleaning underneath the stand.

ELEVATED DESIGN 3.25" Prevent Moisture Easy Cleaning Good Ventilation And Mildew

Figure 7.1: Detail of the elevated design, providing clearance for easy cleaning beneath the unit.



Figure 7.2: A close-up view of the tabletop surface, showing the engineered wood finish.

8. TROUBLESHOOTING

- Wobbly Stand: Ensure all screws are fully tightened. Check that the stand is placed on a level surface.
- **Drawers Not Sliding Smoothly:** Verify that drawer slides are correctly installed and aligned. Apply a silicone-based lubricant if necessary.
- **Missing Parts:** If any parts were missing upon unboxing, refer to the package contents list and contact customer support for replacements.
- TV Overhangs: If your TV exceeds 50 inches or its base is wider than 37.5 inches, it may not fit securely. Consider a different stand or a smaller TV.

9. SPECIFICATIONS

Feature	Detail
Overall Dimensions	37.5" L x 17.75" W x 20.5" H
Material	Engineered Wood (MDF Frame)

Color	White, Natural (top)
Weight Capacity (Total)	88 lbs
Weight Capacity (Drawer)	7 lbs per drawer
Weight Capacity (Compartment)	11 lbs
Fits TVs Up To	50 inches
Number of Drawers	2
Item Weight	52.8 pounds
Model Number	839-049
UPC	842525157216

10. WARRANTY INFORMATION

For specific warranty details regarding your HOMCOM Corner TV Stand, please refer to the warranty documentation included with your purchase or contact the retailer from whom the product was acquired. Warranty terms typically cover manufacturing defects and may vary by region and retailer.

11. CUSTOMER SUPPORT

Should you require assistance with assembly, have questions about product functionality, or need to report missing/damaged parts, please contact HOMCOM customer support or the retailer where you purchased this product. Please have your model number (839-049) and proof of purchase ready when contacting support. For more information about HOMCOM products, visit the official HOMCOM store: HOMCOM Store on Amazon

Related Documents - 839-049



HOMCOM 839-649V00 TV Stand Assembly Instructions and Guide

Comprehensive assembly instructions and guide for the HOMCOM 839-649V00 TV Stand, featuring detailed steps, parts list, hardware information, and adjustment guides.



HOMCOM Modern Loveseat Sofa Assembly and Care Instructions

This document provides assembly instructions, usage guidelines, maintenance tips, and storage conditions for the HOMCOM Modern Loveseat Sofa. It includes multilingual safety warnings and contact information for customer support.



HOMCOM 839-540V00 Series TV Stand Cabinet Assembly Manual

Assembly instructions for the HOMCOM 839-540V00 series TV stand/cabinet. This guide provides a detailed breakdown of parts, hardware, and step-by-step instructions for assembling your furniture item.



HOMCOM 839-133V80 Lift Top Coffee Table Assembly Instructions

Step-by-step assembly guide for the HOMCOM 839-133V80 Lift Top Coffee Table. Includes parts list, hardware, and detailed instructions for building your coffee table.



HOMCOM 839-308 Recliner Chair User Manual and Assembly Guide

Official user manual and assembly guide for the HOMCOM 839-308 recliner chair. Includes instructions for use, maintenance, storage, and assembly steps. Features model number 839-308_V00_V01_V02_V70 and weight limit of 120 kg.



HOMCOM 833-778 TV Stand Assembly Instructions

Comprehensive assembly guide for the HOMCOM 833-778 TV Stand, featuring 3 compartments and 2 cabinets. This manual provides a detailed parts list, hardware identification, and step-by-step instructions for building your media console.