

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Hot Wheels](#) /

› [Hot Wheels Dragon Drive Firefight Playset \(Model HDP03\) Instruction Manual](#)

## Hot Wheels HDP03

# Hot Wheels Dragon Drive Firefight Playset (Model HDP03) Instruction Manual

## INTRODUCTION

---

### Product Overview

The Hot Wheels Dragon Drive Firefight Playset allows children to protect Hot Wheels City from the formidable dragon Dante, who threatens to demolish buildings and consume cars. This playset encourages imaginative play as children launch their Hot Wheels cars to defeat the monster and safeguard the city.

Designed with a fire station theme, this playset offers an engaging environment for developing storytelling skills through interactive play with toy vehicles.

To activate Dante, lift the lever. Then, pull back to send a car through the track integrated into the dragon's body. For a counter-attack, launch a car through the loop to challenge the dragon.

This playset can be connected to other Hot Wheels sets, enabling the creation of an expanded world filled with stunt adventures and thrilling battles.

Suitable for children aged 3-8, the Hot Wheels Dragon Drive Firefight Playset inspires exciting adventures and challenges. It includes one Hot Wheels vehicle, allowing for immediate play right out of the box.



A child engaging with the Hot Wheels Dragon Drive Firefight Playset, preparing to launch a car.

## SETUP

---

### Unboxing and Initial Assembly

The Hot Wheels Dragon Drive Firefight Playset (Model HDP03) is designed for easy setup and requires no complex assembly. Simply remove all components from the packaging.

Ensure that all parts are present: the main dragon playset unit, the fire station building, and the included Hot Wheels vehicle.



The Hot Wheels Dragon Drive Firefight Playset ready for play, showing all main components.

## OPERATING INSTRUCTIONS

---

### Playing with the Dragon Drive Firefight Playset

#### 1. Step 1: Place the Car

Position a Hot Wheels car on the launcher located at the fire station. Ensure it is seated correctly for optimal launch.



Step 1: Place a Hot Wheels car on the launcher and push the lever to activate the dragon's attack.

**2. Step 2: Activate Dragon Attack**

Push the lever to activate the dragon's attack. This action will cause the dragon to 'chomp' at the car, simulating an attack on the city.

**3. Step 3: Dragon Eats Car**

Pull back the lever to make the dragon 'eat' the car. The car will be drawn into the dragon's body, moving along an internal track.

**PULL BACK TO MAKE  
THE DRAGON "EAT" THE CAR**



Step 3: Pull back the lever to make the dragon 'eat' the car, sending it through its internal track.

**4. Step 4: Launch Through Loop**

Slam the launcher to propel the car through the loop. Aim to hit the dragon's head or other targets to defeat it and save the city.



Step 4: Slam the launcher to launch the car through the loop, aiming to defeat the dragon.

## Video Demonstration

Your browser does not support the video tag.

This video provides a visual demonstration of how to operate the Hot Wheels Dragon Drive Firefight Playset, including activating the dragon and launching cars through the track.

## MAINTENANCE

---

### Cleaning and Storage

To ensure the longevity and proper functioning of your Hot Wheels Dragon Drive Firefight Playset, follow these maintenance guidelines:

- **Cleaning:** Wipe all surfaces of the playset with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Avoid immersing any part of the playset in water.
- **Storage:** When not in use, store the playset in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically inspect the playset for any signs of wear, damage, or loose parts. If any damage is found, discontinue use and contact customer support.

## TROUBLESHOOTING

---

### Common Issues and Solutions

- **Car not launching effectively:**

Ensure the Hot Wheels car is properly seated on the launcher. Apply sufficient and consistent force when slamming the launcher mechanism. Check that the track path is clear of any obstructions.

- **Dragon mechanism not responding:**

Inspect the dragon's moving parts for any foreign objects or debris that might be obstructing its movement. Ensure that the activation levers are fully engaged and not stuck.

- **Playset not connecting to other sets:**

Verify that the connection points between the Dragon Drive Firefight Playset and other Hot Wheels sets are aligned correctly. Apply gentle pressure to ensure they are securely fastened.

## SPECIFICATIONS

---

Feature	Detail
Brand Name	Hot Wheels
Model Number	HDP03
Model Name	S29135
Age Range Description	Child (Recommended for ages 3-8 years)
Included Components	1 Playset, 1 Hot Wheels Vehicle
Product Dimensions (L x W x H)	18 x 77.5 x 30.9 cm
Product Weight	1320 Grams
Number of Pieces	1 (Main Playset Unit)
Assembly Required	No
Power Source	Battery Powered (AAA or AA batteries, not included, for potential electronic features)
Scale	1:64
Main Character	Dante (Dragon)
Material	Plastic
Compatibility	Connects to other Hot Wheels track sets and toys
Safety Warning	Choking Hazard - Small Parts. Not suitable for children under 36 months.

## WARRANTY AND SUPPORT

---

For detailed warranty information, product support, or to inquire about replacement parts, please contact Hot Wheels customer service directly. You can typically find specific contact details, including phone numbers and website addresses, on the product packaging or by visiting the official Hot Wheels website.

It is recommended to retain your purchase receipt as proof of purchase, as it may be required for warranty claims or customer service inquiries.

