



[Manuals.plus](#) /

› [Fisher-Price](#) /

› Fisher-Price Little People Big ABC Animal Train Instruction Manual

Fisher-Price 0194735067350

Fisher-Price Little People Big ABC Animal Train Instruction Manual

Model: 0194735067350

INTRODUCTION

The Fisher-Price Little People Big ABC Animal Train is designed to provide engaging and educational play for toddlers and preschool children aged 1-5 years. This large push-along toy train features interactive lights, sounds, music, and phrases, along with five Little People animal figures. It incorporates Smart Stages learning content to introduce fundamental concepts such as the alphabet, counting, and colors. The toy also offers multi-language support, allowing selection between English, Italian, Castilian Spanish, and Portuguese.

SETUP

Before first use, please follow these steps to set up your Fisher-Price Little People Big ABC Animal Train:

1. **Unboxing:** Carefully remove all components from the packaging. Ensure all parts are present.
2. **Check Contents:** Verify that you have the main train unit and the 5 Little People animal figures.
3. **Battery Installation:** Locate the battery compartment, typically on the underside of the train. Use a Phillips head screwdriver to open the compartment. Insert the required batteries (not included) according to the polarity indicators (+/-). Securely close the compartment.



The product as it appears in its packaging, ready for unboxing and setup.

OPERATING INSTRUCTIONS

The Little People Big ABC Animal Train offers various interactive features for engaging play:

- **Push-Along Play:** The train is designed for push-along play, allowing children to move it across surfaces, encouraging gross motor skills.
- **Figure Placement:** The 5 Little People animal figures can be placed in various locations on the train, including inside the passenger car, on the engine, or on the sides. This promotes fine motor skills and imaginative play.
- **Interactive Buttons:** Press the buttons located on top of the engine to activate fun songs, sounds, and phrases. The light-up smokestack also responds to interaction.
- **Smart Stages Learning:** The train features 3 Smart Stages learning levels. Use the Smart Stages switch to select the desired level, which adjusts the learning content to suit different developmental stages.
- **Language Selection:** Press and hold the globe button to cycle through available languages: English, Italian, Castilian Spanish, and Portuguese.
- **Animal Ramp:** The back ramp of the train can be opened to allow animal passengers to slide out, adding another dimension to play.



A child interacting with the train, showing its scale and how figures can be placed.



The train displayed with all five included animal figures.



Close-up of a hand activating the light-up smokestack feature.



Close-up of the interactive buttons on the train's engine.

MAINTENANCE

To ensure the longevity and proper functioning of your Fisher-Price Little People Big ABC Animal Train, please follow these maintenance guidelines:

- **Cleaning:** Wipe the toy with a damp cloth and mild soap as needed. Do not immerse the toy in water.
- **Battery Replacement:** When sounds and lights become faint or stop working, it is time to replace the batteries. Refer to the "Setup" section for battery installation instructions. Always use new batteries of the recommended type and ensure proper polarity.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

TROUBLESHOOTING

If you encounter any issues with your Fisher-Price Little People Big ABC Animal Train, please consult the following common troubleshooting tips:

- **No Sound or Lights:**

- Check if the batteries are installed correctly with the correct polarity.
- Replace old or depleted batteries with fresh ones.
- Ensure the power switch (if present) is in the "On" position.

- **Intermittent Functionality:**

- This may indicate low battery power. Try replacing the batteries.
- Ensure there is no debris obstructing the buttons or moving parts.

- **Language Not Changing:**

- Ensure you are pressing and holding the globe button for a few seconds until the language changes.

If problems persist after attempting these solutions, please contact Fisher-Price customer support for further assistance.

SPECIFICATIONS

Product Dimensions	19.29 x 7.8 x 10.98 inches
Item Weight	2.43 pounds
ASIN	B09BW56DWT
Item Model Number	0194735067350
Manufacturer Recommended Age	12 months and up
Language Options	English, Italian, Castilian Spanish, Portuguese
Manufacturer	Mattel (Fisher-Price)
What's in the Box	Fisher-Price Little People Big Abc Animal Train

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please contact Fisher-Price directly through their official website or customer service channels. Keep your proof of purchase for any warranty claims.

Visit the [Fisher-Price Store on Amazon](#) for more products and information.