

[Manuals.plus](#) /

› [PEIOUS](#) /

› PEIOUS Wireless Mouse User Manual

PEIOUS PEIOUS Wireless Mouse

PEIOUS Wireless Mouse User Manual

Model: PEIOUS Wireless Mouse

INTRODUCTION

This user manual provides comprehensive instructions for the PEIOUS Wireless Mouse, a versatile device combining a rechargeable LED mouse with an undetectable mouse jiggle function. Designed for laptops, this mouse ensures your computer remains active, preventing sleep mode or screen lockouts during periods of inactivity. It offers seamless plug-and-play functionality and is compatible with various operating systems.

PRODUCT OVERVIEW

Familiarize yourself with the components of your PEIOUS Wireless Mouse:

- **Left Button:** Standard left-click functionality.
- **Right Button:** Standard right-click functionality.
- **Scroll Wheel:** For vertical scrolling and middle-click.
- **DPI Button / Mouse Jiggler (On/Off):** Press to cycle DPI settings. Press and hold for 3 seconds to activate/deactivate jiggle mode.
- **Charging Port:** USB-C port for recharging the internal battery.
- **Light Mode Button:** Located on the underside, cycles through LED lighting effects.
- **Power Switch:** On/Off switch for the mouse.
- **USB Receiver:** Small USB dongle for wireless connectivity.

MOUSE JIGGLER

Take time analyzing a spreadsheet, do laundry etc,
without screen going black



Figure 1: PEIOUS Wireless Mouse Components

This image displays the top and bottom views of the PEIOUS Wireless Mouse with all its key components clearly labeled, such as the left and right click buttons, scroll wheel, DPI/Jiggler button, charging port, light mode button, power switch, and the USB receiver slot.

SETUP

1. **Charge the Mouse:** Before first use, connect the mouse to a USB power source using the provided charging cable. The LED lights will indicate charging status.




Figure 2: Charging the Mouse

This image shows the PEIOUS Wireless Mouse being charged via its USB-C port, highlighting the connection point for power input.

2. **Insert USB Receiver:** Locate the USB receiver stored in the bottom of the mouse. Plug this receiver into an available USB port on your laptop or computer.



Figure 3: Mouse and USB Receiver

This image displays the PEIOUS Wireless Mouse alongside its compact USB receiver, demonstrating the two main components required for wireless operation.

3. **Power On:** Slide the power switch on the underside of the mouse to the "On" position. The mouse will automatically

connect to the USB receiver.

4. **Plug & Play:** No additional drivers are required. The mouse is ready for use immediately after connecting the receiver and powering on.

OPERATING INSTRUCTIONS

Basic Mouse Functions

- **Left Click:** Press the left button for primary actions.
- **Right Click:** Press the right button for contextual menus.
- **Scroll:** Roll the scroll wheel up or down to navigate documents or web pages.
- **Middle Click:** Press the scroll wheel down for specific application functions (e.g., opening links in new tabs).

DPI Adjustment

The mouse supports adjustable DPI (Dots Per Inch) settings, allowing you to control cursor sensitivity and speed. To change the DPI:

- Press the **DPI Button** (located below the scroll wheel) briefly.
- Each press cycles through available DPI settings (800, 1200, 1600, 2000 DPI).
- The LED lights will flash once to indicate a change in DPI setting.



Figure 4: DPI Adjustment

This image demonstrates how to adjust the DPI settings on the PEIOUS Wireless Mouse, indicating the range of DPI values (800-2000) and how the LED lights change color to reflect the current setting.

LED Light Modes

The mouse features various LED lighting effects. To change the light mode:

- Locate the **Light Mode Button** on the underside of the mouse.

- Press this button to cycle through different lighting patterns and colors.



Figure 5: Light Mode Button Location

This image highlights the "Light Mode Button" located on the bottom of the PEIOUS Wireless Mouse, indicating its function for changing LED lighting effects.

Mouse Jiggler Function

The integrated mouse jiggler prevents your computer from entering sleep mode or locking the screen due to inactivity. This feature

provides random, undetectable cursor movements.



**1 MOUSE =
ALL ITEMS BELOW :**



LED Mouse

+



Rechargeable Mouse

+



Mouse Jiggler

Figure 6: Mouse Jiggler Functionality

This image visually represents the dual functionality of the PEIOUS Wireless Mouse, highlighting its capabilities as a standard LED mouse, a rechargeable device, and a mouse jiggle to keep computers awake.

To activate or deactivate the jiggle mode:

- Press and hold the **DPI Button** for approximately 3 seconds.

- When jiggler mode is active, the green lights on the scroll wheel will illuminate.
- To exit jiggler mode, press and hold the **DPI Button** again for 3 seconds. The green lights will turn off.
- In jiggler mode, the mouse will produce random movements. When you move the mouse manually, the jiggler function will temporarily pause and resume after 5 seconds of inactivity.



With Jiggler Mode:

The movement will stop automatically when you begin to move the cursor with the mouse

Figure 7: Activating/Deactivating Jiggler Mode

This image provides a visual guide on how to switch the PEIOUS Wireless Mouse into and out of jiggler mode by pressing and holding the DPI button for 3 seconds, with green lights indicating activation.

MAINTENANCE

- **Charging:** Recharge the mouse when the battery is low. The mouse juggler function can still operate even if the mouse battery is depleted, provided it is connected to power.
- **Cleaning:** Use a soft, dry cloth to clean the mouse. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use for extended periods, turn off the mouse using the power switch to conserve battery life. Store the USB receiver inside the mouse's designated slot.

TROUBLESHOOTING

Problem	Solution
Mouse not responding.	◦ Ensure the mouse is powered on. ◦ Check if the USB receiver is securely plugged into a USB port. ◦ Recharge the mouse battery. ◦ Try plugging the USB receiver into a different USB port.
Mouse Jiggler not working.	◦ Ensure the mouse is powered on. ◦ Press and hold the DPI button for 3 seconds to activate juggler mode (green lights should be on). ◦ Confirm the USB receiver is connected.
LED lights not working.	◦ Press the Light Mode Button on the underside of the mouse to cycle through modes. ◦ Ensure the mouse has sufficient battery charge.

SPECIFICATIONS

- **Product Dimensions:** 4 x 2.25 x 1.25 inches
- **Item Weight:** 2.82 ounces
- **Batteries:** 1 Lithium Ion battery (included)
- **Connectivity Technology:** USB Wireless
- **Movement Detection Technology:** Optical
- **DPI Settings:** 800, 1200, 1600, 2000
- **Special Features:** LED Mouse, Wireless Mouse with Jiggler Function
- **Compatibility:** Windows XP, Windows 7, Windows 8, Windows 10, Mac OS
- **Manufacturer:** PEIOUS
- **Country of Origin:** China

WARRANTY AND SUPPORT

This PEIOUS Wireless Mouse is backed by a **12-month warranty** from the date of purchase. If you encounter any issues or have questions regarding your product, please contact PEIOUS customer support through the retailer where you purchased the item or visit the official PEIOUS website for assistance.

Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question