

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Hk Audio](#) /

› [Hk Audio Linear 7 118 Sub A 2000W Active 18 Inch Subwoofer User Manual](#)

Hk Audio Linear 7 118 Sub A

Hk Audio Linear 7 118 Sub A Active 18-Inch Subwoofer User Manual

Model: Linear 7 118 Sub A

INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your Hk Audio Linear 7 118 Sub A active 18-inch subwoofer. The Linear 7 118 Sub A is a powerful and compact subwoofer designed to deliver phenomenal low-frequency performance, featuring network compatibility for various applications.



Image: Front-angled view of the HK Audio Linear 7 118 Sub A active 18-inch subwoofer, showcasing its robust grille and cabinet design.

SETUP

Proper setup is crucial for optimal performance and safety. Follow these steps to integrate your subwoofer into your audio system.

Unpacking and Placement

- Carefully remove the subwoofer from its packaging. Retain all packaging materials for future transport or storage.
- Place the subwoofer on a stable, level surface. The unit is designed for floor mounting.
- Ensure adequate ventilation around the unit to prevent overheating.

Connections

The Linear 7 118 Sub A features various input and output options for integration with different audio systems. Refer to the rear panel for connection points.



Image: Detailed view of the rear panel of the Hk Audio Linear 7 118 Sub A, displaying power input, audio inputs (XLR), Ethernet ports, and control settings.

- **Power Connection:** Connect the provided power cord to the 'Mains Input' on the rear panel and then to a suitable electrical outlet. The subwoofer operates on corded electric power.
- **Audio Input:** Connect your audio source (e.g., mixer, audio interface) to the 'Input' XLR connectors. The subwoofer is compatible with devices such as laptops, smartphones, and televisions.
- **Audio Output (Thru/Link):** Use the 'Thru' or 'Link' outputs to connect to other speakers or subwoofers in your system.
- **Network Connection:** For network-compatible features, connect an Ethernet cable to the designated 'Ethernet' ports.

OPERATING INSTRUCTIONS

Once properly set up, follow these instructions to operate your Hk Audio Linear 7 118 Sub A subwoofer.

Powering On/Off

- Ensure all connections are secure before powering on.
- Flip the 'Power' switch on the rear panel to the 'ON' position. The unit will initialize.
- To power off, flip the 'Power' switch to the 'OFF' position.

Adjusting Settings

- The subwoofer features a touch control method for adjusting various settings. Refer to the display and controls on the rear panel.
- Adjust volume, crossover frequency, phase, and other parameters as needed for your specific audio environment and desired sound.
- The audio output mode is mono, designed to augment the low-frequency response of your main speakers, typically in a 2.1 surround sound channel configuration.
- The subwoofer delivers a maximum output power of 2000 Watts. Adjust levels carefully to avoid distortion or damage to your hearing.

MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your subwoofer.

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the subwoofer. Do not use liquid cleaners or solvents, as they may damage the finish or internal components.
- **Ventilation:** Periodically check that the ventilation grilles are free from dust and obstructions.
- **Environmental Conditions:** This product is not waterproof and not water resistant. Avoid exposing the subwoofer to moisture, extreme temperatures, or direct sunlight.
- **Cable Inspection:** Regularly inspect all power and audio cables for any signs of wear or damage. Replace damaged cables immediately.

TROUBLESHOOTING

If you encounter issues with your subwoofer, refer to the following common troubleshooting steps.

- **No Power:**
 - Ensure the power cord is securely connected to both the subwoofer and a working electrical outlet.
 - Check the power switch on the rear panel is in the 'ON' position.
 - Verify the electrical outlet is functional by plugging in another device.
- **No Sound:**
 - Check all audio input cables for secure connections.
 - Ensure the audio source is active and sending a signal.
 - Verify the subwoofer's volume and other settings are not set to minimum or muted.
 - Confirm that the main audio system (e.g., receiver, mixer) is properly configured to send a low-frequency signal to the subwoofer.
- **Distorted Sound:**
 - Reduce the input level from your audio source or the subwoofer's volume.
 - Check for damaged cables.
 - Ensure the subwoofer is not placed too close to walls or corners, which can cause excessive bass resonance.

If these steps do not resolve the issue, please contact customer support.

SPECIFICATIONS

Detailed technical specifications for the Hk Audio Linear 7 118 Sub A subwoofer.

Feature	Specification
Model Name	Linear 7 118 Sub A
Speaker Type	Subwoofer
Woofer Diameter	18 Inches
Speaker Maximum Output Power	2000 Watts
Audio Output Mode	Mono
Control Method	Touch
Power Source	Corded Electric
Mounting Type	Floor Mount
Surround Sound Channel Configuration	2.1
Compatible Devices	Laptop, Smartphone, Television
Water Resistance Level	Not Water Resistant
Item Weight	110.2 pounds
Manufacturer	HK Audio

WARRANTY INFORMATION

The Hk Audio Linear 7 118 Sub A comes with a Limited Warranty. Please refer to the warranty documentation included with your purchase for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

SUPPORT

For technical assistance, service, or further inquiries regarding your Hk Audio Linear 7 118 Sub A subwoofer, please contact the manufacturer, HK Audio, or your authorized retailer. Contact information can typically be found on the manufacturer's official website or your purchase documentation.

Manufacturer: HK Audio



© 2024 Hk Audio. All rights reserved.

	<p>HK Audio LINEAR 9 Professional Loudspeaker Systems Manual</p> <p>User manual for HK Audio LINEAR 9 series professional loudspeakers, covering models like L9 210 LTA, L9 110 XA, L9 112 XA, L9 118 Sub A, L9 118 Sub BA. Includes setup, operation, safety, and technical specifications for versatile audio applications.</p>
	<p>HK Audio DSP Control Software User Guide</p> <p>Learn how to use HK Audio's DSP Control Software for managing presets, groups, delay, equalizer, and firmware updates. This guide provides step-by-step instructions for professional audio systems.</p>
	<p>HK Audio LINEAR 5 MK II 308 LTA & 118 Sub HPA User Manual</p> <p>Comprehensive user manual for the HK Audio LINEAR 5 MK II series, detailing the 308 LTA loudspeaker and 118 Sub HPA subwoofer. Covers safety instructions, connections, controls, setup, alignment, system configurations, technical specifications, and optional accessories for professional audio applications.</p>
	<p>HK Audio LINEAR 5 MKII Series User Manual</p> <p>Comprehensive user manual for the HK Audio LINEAR 5 MKII series of professional loudspeakers and subwoofers, covering safety, connections, setup, and technical specifications.</p>
	<p>HK Audio TB-45N Tilt Bracket Installation Instructions</p> <p>Comprehensive installation guide for the HK Audio TB-45N 2x Tilt bracket, detailing compatibility with HK Audio speaker series like Linear 3, Linear 5, Linear 7, and Premium PR:0 D2. Includes a parts list, step-by-step assembly instructions with textual descriptions of diagrams, and workload limit specifications.</p>
	<p>HK AUDIO DSP Control Software User Guide - Features and Operations</p> <p>Comprehensive guide to HK AUDIO's DSP Control Software, covering presets, groups, delay, equalizer, updates, background customization, and reset functions for professional audio systems.</p>