

## Donner DSJ-100

# Donner 30 Inch Kids Electric Guitar Beginner Kits ST Style Mini Electric Guitar DSJ-100 Instruction Manual

[Overview](#)

[Setup](#)

[Operating Instructions](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

## 1. PRODUCT OVERVIEW

This instruction manual provides essential information for the setup, operation, and maintenance of your Donner 30 Inch Kids Electric Guitar Beginner Kits ST Style Mini Electric Guitar, model DSJ-100. Designed for young beginners, this kit offers a lightweight, portable, and ergonomically crafted instrument with a full sound, complete with all necessary accessories to start playing immediately.

### Key Features:

- **Lightweight and Portable:** Weighs only 5.97 LB, reducing the physical burden and making it easier to play.
- **Designed for Beginner Kids:** Features a 35cm neck length and 4.3cm fingerboard width, optimized for children's body size and hand shape.
- **Skin-Friendly Craftsmanship:** Ergonomic design with a matte lacquer surface to protect skin from damage caused by long-term friction.
- **Excellent Tone:** Equipped with a classic single-coil pickup, delivering a sound comparable to full-sized electric guitars, suitable for various musical styles.
- **Ready to Play Kit:** Includes picks, cables, a gig bag, a strap, a professional mini amp with distortion and clean channels, and access to free online lessons.



Figure 1: Donner 30 Inch Kids Electric Guitar (Black ST-30 INCH model).

## 2. SETUP GUIDE

Your Donner electric guitar kit comes with everything needed for immediate use. Follow these steps to set up your instrument.

### 2.1 Unboxing and Component Check

Carefully remove all items from the packaging. Ensure all components listed below are present:

- Donner 30 Inch Electric Guitar
- Mini Amp (with distortion and clean channels)
- 600D Gig Bag
- Guitar Strap

- Guitar Cable (1/4 inch / 6.35mm audio jack)
- Digital Tuner
- Picks
- Extra Strings
- Cleaning Cloth
- Allen Wrench (for adjustments)

# MINI GUITAR AMPLIFIER



HEADPHONES



AUX IN



Figure 2: All included accessories in the Donner Electric Guitar Beginner Kit.

## 2.2 Attaching the Strap

Attach the guitar strap to the strap buttons located on the body of the guitar. Adjust the strap length for comfortable playing, whether standing or sitting.

## 2.3 Connecting the Mini Amp

1. Connect one end of the guitar cable to the output jack on the guitar.
2. Connect the other end of the guitar cable to the input jack on the mini amp.
3. Ensure the mini amp is charged or has fresh batteries.




Figure 3: The Donner Mini Guitar Amplifier, showing controls and input/output jacks.

## 2.4 Tuning the Guitar

Use the included digital tuner to accurately tune your guitar. Attach the tuner to the headstock of the guitar. Pluck each string individually and adjust the tuning pegs until the tuner indicates the correct pitch (E-A-D-G-B-E for standard tuning) and the display turns green.

*Tip: For a shorter scale mini electric guitar, tuning up 1 or 2 notes above standard tuning (e.g., EADGBE → AbC#F#BEbA) can increase string tension and pitch stability. New strings may require frequent tuning until they settle.*

## 3. OPERATING INSTRUCTIONS

Once set up, your Donner electric guitar is ready to play. Experiment with the controls to explore different sounds.

### 3.1 Basic Playing

Hold the guitar comfortably with the strap. Use the included picks to strum or pluck the strings. Practice basic chords and scales. Free online lessons are available to guide beginners.



Figure 4: A child demonstrating the comfortable size and playability of the Donner mini electric guitar.

### 3.2 Amplifier Controls

The mini amp features volume, tone, and distortion controls. Adjust these knobs to shape your sound:

- **Volume:** Controls the overall loudness of the guitar.
- **Tone:** Adjusts the brightness or warmth of the sound.
- **Distortion Channel:** Engages a distorted, rock-like sound. Turn this off for a clean tone.

The amp also includes headphone and AUX IN ports for private practice or playing along with backing tracks.

# LIGHTWEIGHT AND PORTABLE

Minimizing tiredness from standing and playing for an extended period of time



Figure 5: Close-up view of the guitar's volume and tone knobs, and the stable bridge.

### 3.3 Official Product Video: Donner 30 Inch Kids Electric Guitar Kits

Your browser does not support the video tag.

Video 1: An official product video from DonnerDirect showcasing the features and components of the Donner 30 Inch Kids Electric Guitar Kits, including the guitar, amp, and accessories.

## 4. MAINTENANCE

Proper maintenance will ensure the longevity and optimal performance of your electric guitar.

## 4.1 Cleaning

Use the provided cleaning cloth to wipe down the guitar body, neck, and strings after each use. This helps remove sweat, oils, and dust that can degrade the finish and strings.

## 4.2 String Replacement

Over time, guitar strings will wear out and lose their tone. Replace strings as needed using the included extra set or new strings of similar gauge. Consult online resources or a professional for guidance on string replacement if unfamiliar with the process.

## 4.3 Storage

When not in use, store the guitar in its gig bag to protect it from dust, scratches, and environmental changes. Avoid extreme temperatures and humidity.

# 5. TROUBLESHOOTING

---

Here are some common issues and their potential solutions:

- **Guitar won't stay in tune:** New strings often stretch and require frequent tuning. Continue to tune regularly. Ensure tuning pegs are tightened appropriately.
- **Amp produces humming noise:** Check all cable connections to ensure they are secure. Try a different power outlet or cable if possible.
- **Strings sound "raspy" or buzz:** This might indicate an issue with string action (height). The included Allen wrench can be used to adjust the bridge saddles. If unsure, consult a guitar technician.
- **No sound from amp:** Verify the guitar cable is fully inserted into both the guitar and amp. Check the amp's power and volume settings. Ensure the guitar's volume knob is turned up.

# 6. SPECIFICATIONS

---

Feature	Detail
Brand	Donner
Model Name	EC1375 (DSJ-100)
Color	Black
Instrument Size	30 Inch
Body Material	Poplar
Top Material Type	Maple Wood
Back Material Type	Poplar
Neck Material Type	Maple
Fretboard Material Type	Maple
Number of Strings	6

Feature	Detail
Scale Length	500mm
Guitar Pickup Configuration	S (Single-coil)
String Material Type	Nickel Plated
Hand Orientation	Right
Guitar Bridge System	Fixed Hardtail Saddle Bridge
Connector Type	1/4 inch (6.35mm) audio jack
Item Dimensions	30 x 30 x 30 inches <i>(Note: This dimension seems generic and might not reflect actual guitar size accurately.)</i>

## 7. WARRANTY & SUPPORT

---

Your Donner electric guitar comes with a **1-year warranty**. For any support needs, questions, or to explore more products, please visit the official Donner brand store or contact customer service.

[Visit the Donner Brand Store](#)