



Manuals.plus /

- › VEVOR /
- › VEVOR 150-inch Outdoor Movie Screen with Stand (Model: z4zx5s6o) Instruction Manual

VEVOR z4zx5s6o

VEVOR 150-inch Outdoor Movie Screen with Stand Instruction Manual

Model: z4zx5s6o

1. OVERVIEW

This manual provides instructions for the VEVOR 150-inch Outdoor Movie Screen with Stand. This portable projection screen is designed for both front and rear projection, offering a 16:9 aspect ratio and a 160-degree viewing angle for a wide range of applications, including home theater, outdoor events, office presentations, and gaming.



Image description: A VEVOR 150-inch outdoor movie screen set up in a living room, displaying a sports event, with people watching. This image illustrates the wide viewing angle and the screen's application in a home setting.

2. PACKAGE CONTENTS

Please verify that all the following components are included in your package:

- 1 x Projector Screen
- 1 x Storage Pouch
- 8 x Ground nails
- 4 x Ropes
- 1 x Needle & Thread Set



Image description: An overhead view of all components included in the VEVOR 150-inch outdoor movie screen package, including the screen fabric, frame poles, stand bases, ropes, ground nails, and a storage bag.

3. SETUP INSTRUCTIONS

The VEVOR 150-inch Outdoor Movie Screen is designed for quick and easy assembly without requiring special tools. It is recommended to have two people for initial setup.

1. **Unpack Components:** Carefully remove all parts from the storage bag.
2. **Assemble Frame:** Connect the aluminum and steel frame poles. The poles are designed to fit together securely. Ensure all connections are firm.
3. **Attach Screen Fabric:** Lay the screen fabric flat. Attach the screen to the assembled frame using the integrated Velcro straps located along the edges of the screen. Ensure the screen is taut and wrinkle-free.
4. **Install Stand Bases:** Insert the bottom poles of the frame into the provided stand bases.
5. **Secure for Outdoor Use:** If setting up outdoors, use the provided ground nails and ropes to anchor the stand firmly to the ground. This prevents the screen from being affected by wind.

CONVENIENT PORTABILITY

Easy storage without taking up space



Include a 420D portable hand-carry bag for easy storage

Image description: A VEVOR projector screen set up outdoors on a lawn, secured with ropes and ground nails, displaying a vibrant image. This illustrates the stability features for outdoor use.

Setup Demonstration Video

Video description: This video demonstrates the step-by-step assembly of the VEVOR projector screen with stand, highlighting the ease of setup and the use of Velcro straps for securing the screen.

4. OPERATING THE PROJECTOR SCREEN

The VEVOR 150-inch Outdoor Movie Screen offers versatile projection options and a wide viewing experience.

- **Projection Type:** The screen supports both front and rear projection. Position your projector accordingly based on your viewing environment and desired setup. For front projection, the projector is placed in front of the screen. For rear projection, the projector is placed behind the screen, projecting through the material.
- **Viewing Angle:** The screen provides a 160-degree wide viewing angle, ensuring a clear and vibrant image from various positions around the screen.
- **Image Quality:** For optimal 4K HD vivid imagery, ensure your projector is capable of 4K resolution and is properly

focused and aligned with the screen. Adjust the projector's distance and zoom to fill the screen evenly.

STABLE TRIPOD STAND

Stable for indoor and outdoor use



1 Rope



2 Ground Nail



Image description: A diagram illustrating the flexibility of the VEVOR projector screen, showing how it can be used for both front and rear projection setups, along with an indication of its 160-degree wide viewing angle.

5. MAINTENANCE

Proper care and storage will extend the life and maintain the quality of your VEVOR projector screen.

- **Cleaning the Screen:** The high-textile oxford cloth screen is designed to be wrinkle-free and easy to clean. Use a soft, damp cloth with mild soap and water to gently wipe the screen surface. Avoid harsh chemicals, abrasive materials, or excessive scrubbing, as these can damage the screen material.
- **Storage:** After each use, especially for outdoor setups, disassemble the screen and frame. Ensure all components are clean and dry before packing them into the provided portable and lightweight storage bag. This protects them from dust, moisture, and potential damage during transport or storage.
- **Wrinkle Prevention:** The screen material is inherently wrinkle-free. When storing, fold it neatly and avoid creasing it sharply to maintain its smooth projection surface.

WRINKLE-FREE MATERIAL, **CLEAR IMAGE**

Easy to clean and maintain




Image description: A visual comparison highlighting the wrinkle-free nature of the VEVOR screen material ("Our") versus a typical screen ("Other"), showing how it remains smooth even after folding.

6. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Unstable Stand:** Ensure all frame connections are fully tightened. For outdoor use, always utilize the provided ground nails and ropes to secure the stand against wind. Check that the stand bases are placed on a flat, stable surface.
- **Wrinkles on Screen:** While the screen is designed to be wrinkle-free, minor creases from prolonged storage can sometimes occur. These can often be smoothed out by gently stretching the screen when attaching it to the frame. If persistent, light steaming from a distance may help, but avoid direct heat or contact with the screen surface.
- **Poor Image Quality:** Check your projector's resolution settings and focus. Ensure the projection surface is clean and free of dust or smudges. Adjust the projector's distance and angle to ensure the image fills the screen evenly and is not distorted.

If you encounter issues not covered here, please contact VEVOR customer support for further assistance.

7. SPECIFICATIONS

Detailed specifications for the VEVOR 150-inch Outdoor Movie Screen:

Feature	Detail
Model Number	z4zx5s6o
Screen Size	150 inch
Aspect Ratio	16:9
Screen Fabric Material	Polyester Oxford Cloth
Viewing Angle	160 Degrees
Product Weight	6.4 Kilograms (15 lbs)
Mounting Type	Stand Mount
UPC	768558073524



Image description: A detailed diagram showing the dimensions of the 150-inch VEVOR projector screen and its stand, along with key specifications like screen size, aspect ratio, and material.

8. WARRANTY AND SUPPORT

Warranty Information

The manufacturer's warranty for this product is not specified in the provided information. Please refer to the product packaging or contact VEVOR customer service for detailed warranty terms and conditions.

Customer Support

For further assistance, technical support, or inquiries regarding your VEVOR 150-inch Outdoor Movie Screen, please visit the official VEVOR website or contact their customer service department through the contact information provided on their website or product packaging.

