

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [EarFun](#) /

› [EarFun Air Pro 2 Wireless Earbuds User Manual](#)

EarFun EarFun Air Pro 2

EarFun Air Pro 2 Wireless Earbuds User Manual

Brand: EarFun | Model: Air Pro 2

INTRODUCTION

The EarFun Air Pro 2 Wireless Earbuds offer a premium audio experience with advanced features such as Hybrid Active Noise Cancellation, Bluetooth 5.2 technology, and intuitive touch controls. Designed for comfort and superior sound, these earbuds are equipped with 10mm titanium diaphragm dynamic drivers and six microphones for clear calls.

What's in the Box

- EarFun Air Pro 2 ANC earbuds
- Charging case
- USB-C Cable
- Ear Tips

SETUP AND FIRST USE

Initial Pairing

Before pairing, ensure you remove the insulating film from the earbuds. Place the earbuds back into the charging case, then open the case to initiate pairing mode. Search for "EarFun Air Pro 2" in your device's Bluetooth settings to connect.



Image: The EarFun Air Pro 2 earbuds are shown resting in their open charging case, ready for initial setup and pairing.

Wearing Experience

For optimal sound quality and comfort, select the ear tips that best fit your ears. The earbuds are designed for a secure fit, enhancing both audio performance and noise isolation.

Video: This video demonstrates the activation process for the EarFun Air Pro 2 Wireless Earbuds, including removing protective film and placing them in the charging case.

OPERATING THE EARBUDS

Touch Controls

The EarFun Air Pro 2 features intuitive touch controls located on the stem of each earbud. These controls allow you to manage music playback, handle phone calls, adjust volume, activate your voice assistant, and switch between noise control modes without needing to access your smartphone.




Image: A diagram illustrating the various touch control functions on the EarFun Air Pro 2 earbuds, including volume adjustment, track skipping, play/pause, call management, voice assistance, and noise cancellation control.

Noise Control Modes

- **Active Noise Cancellation (ANC):** Reduces ambient noise by up to 40dB, ideal for focusing on audio in noisy environments.
- **Ambient Sound Mode:** Allows you to hear your surroundings while listening to audio, useful for situational awareness.
- **Normal Mode:** Standard audio playback without noise cancellation or ambient sound features.

EarFun Audio App

Download the EarFun Audio App to unlock additional features and customization options. The app allows you to switch between different EQ presets, customize touch controls, upgrade firmware, and more.

CHARGING AND BATTERY LIFE

The EarFun Air Pro 2 earbuds offer up to 7 hours of playtime on a single charge. The compact charging case extends the total listening time to 34 hours when Active Noise Cancellation is off. For quick power, a 10-minute charge provides 2 hours of listening.




Image: The EarFun Air Pro 2 earbuds and their charging case are depicted with a graphic indicating a total playtime of 34 hours.

The charging case supports both USB-C wired charging and Qi wireless charging, providing flexible power options.

Maintenance

Regular cleaning of your earbuds is essential for optimal performance and hygiene. Ensure the charging contacts are clean to prevent charging failures or connection issues. Remove ear tips and clean any earwax or dust from the ear tip area to maintain clear audio volume.

Video: This video provides a step-by-step guide on how to properly clean your EarFun Air Pro 2 earbuds, including the charging contacts and ear tip areas.

Troubleshooting

Resetting Your Earbuds

If you experience connectivity issues or other malfunctions, performing a factory reset can often resolve the problem. Place both earbuds into the charging case, keep the case open, then press and hold the charging case button for at least 8 seconds until both earbuds flash purple. Delete the old connection from your Bluetooth device and reconnect.

Video: This video demonstrates the process of resetting the EarFun Air Pro 2 earbuds to their factory settings.

Common Issues

- Ensure the insulating film is removed from the earbuds before first use.
- Always dry the earbuds completely before placing them back into the charging case to prevent damage.

Specifications

Feature	Detail
Model Name	EarFun Air Pro 2
Noise Control	Hybrid Active Noise Cancellation (up to 40dB)
Connectivity Technology	Wireless (Bluetooth 5.2)

Audio Driver Type	10mm Titanium Diaphragm Dynamic Driver
Microphones	6 (for enhanced call clarity)
Battery Life (Earbuds)	7 Hours (ANC off) / 6 Hours (ANC on)
Total Playtime (with Case)	34 Hours (ANC off) / 30 Hours (ANC on)
Charging Time (Earbuds)	1 Hour
Charging Time (Case)	2 Hours (USB-C) / 3.5 Hours (Wireless)
Water Resistance	IPX5 (Sweat & Water Resistant)
Weight	1.87 ounces (53 grams)
Dimensions	2.56 x 2.05 x 1.22 inches

WARRANTY AND SUPPORT

The EarFun Air Pro 2 Wireless Earbuds come with an 18-month warranty. For any problems or inquiries, please refer to the contact information provided in your product packaging or visit the official EarFun website for support.

Related Documents - EarFun Air Pro 2



 User Manual	<p>EarFun Air Pro 4 ANC Wireless Earbuds User Manual and Troubleshooting Guide</p> <p>Comprehensive user manual for EarFun Air Pro 4 ANC Wireless Earbuds, covering app features, pairing, in-ear detection, LDAC, reset, touch controls, LED indicators, specifications, and troubleshooting. Learn how to optimize your audio experience with these Hi-Res Audio Wireless earbuds featuring Qualcomm aptX Adaptive and Snapdragon Sound.</p>
 User Manual	<p>EarFun Air Pro 2 ANC Wireless Earbuds User Manual</p> <p>Comprehensive user manual for the EarFun Air Pro 2 ANC Wireless Earbuds, covering setup, charging, pairing, functions, specifications, and troubleshooting.</p>
 User Manual	<p>EarFun Air Pro ANC Wireless Earbuds User Manual Setup, Features, Troubleshooting</p> <p>User manual for EarFun Air Pro (TW302) ANC Wireless Earbuds. Learn about product features, setup, charging, specifications, pairing, functions, and troubleshooting for these active noise cancelling Bluetooth earbuds.</p>

Table of Contents	2
CONNECTION	2
WATERPROOF	3
CHARGING	3
SOUND	4
MODE	4
FAQ	5

[EarFun Air Pro Wireless Earbuds: Frequently Asked Questions](#)


Find answers to common questions about EarFun Air Pro wireless earbuds, covering connection, waterproofing, charging, sound, modes, and troubleshooting.



BC
User Manual

[EarFun Air Pro ANC Wireless Earbuds User Manual](#)

Comprehensive user manual for the EarFun Air Pro ANC wireless earbuds, covering setup, features, specifications, and troubleshooting. Learn how to pair, operate, and maintain your device.



BC
User Manual

[EarFun Air Pro ANC Wireless Earbuds User Manual](#)

User manual for the EarFun Air Pro ANC Wireless Earbuds, detailing product features, specifications, pairing instructions, functions, troubleshooting, and customer service information.