

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Contixo](#) /

› [Contixo Kids Tablet V10+ User Manual](#)

## Contixo V10+

# Contixo Kids Tablet V10+ User Manual

7-inch HD Tablet with Parental Control and Kid-Proof Case

## 1. INTRODUCTION

This manual provides essential information for the safe and effective use of your Contixo Kids Tablet V10+. Please read it thoroughly before operating the device and retain it for future reference. The Contixo V10+ is designed as a learning and entertainment device for children, featuring parental controls and a durable design.

## 2. WHAT'S IN THE Box

- Contixo Kids Tablet V10+
- Kid-proof Case
- Stylus

## 3. PRODUCT OVERVIEW

The Contixo Kids Tablet V10+ is equipped with features designed for a child-friendly experience. It includes a 7-inch HD display, a 1.5 GHz Quad Core Processor, 2 GB RAM, and 32 GB of internal storage, expandable via microSD. The tablet runs on Android 10 and comes with a protective case and a stylus.



Figure 3.1: Contixo Kids Tablet V10+ in its protective blue case, showing a video on screen.

### 3.1 Key Features

- **Educator-Approved Apps:** Pre-installed educational applications and creative tools.
- **Parental Control:** Features to manage screen time, content, and app access.
- **Durable Design:** Kid-proof case with raised edges for screen protection and a built-in kickstand.
- **Full Android Access:** GMS Certified, allowing access to Google Play Store for additional apps.
- **Performance:** 1.5 GHz Quad Core Processor, 2 GB RAM, and 32 GB storage (expandable up to 128GB via microSD).



Figure 3.2: Diagram showing the tablet's components including front camera, microphone, volume buttons, power buttons, reset button, 3.5mm headphone port, Micro SD card slot, Type-C USB port, speaker, rear camera, and kickstand.

## 4. SETUP INSTRUCTIONS

### 4.1 Initial Power On

1. Press and hold the **Power Button** located on the side of the tablet until the screen illuminates.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.

### 4.2 Charging the Tablet

Before first use, fully charge the tablet. Connect the provided Type-C USB cable to the tablet's charging port and the other end to a compatible USB power adapter. The charging indicator will show the charging status.

### 4.3 Inserting a MicroSD Card (Optional)

To expand storage, locate the Micro SD Card Slot on the side of the tablet. Gently insert a compatible microSD card until it clicks into place. The tablet supports up to 128GB microSD cards.

## 5. OPERATING INSTRUCTIONS

### 5.1 Navigating the Interface

The tablet runs on Android 10. Use touch gestures to navigate: tap to select, swipe to scroll, pinch to zoom. The home screen provides access to pre-installed apps and widgets.

### 5.2 Parental Controls (Kids Place)

The Contixo V10+ includes a dedicated Kids Place application for parental control. This feature allows you to

manage your child's tablet usage effectively.




Figure 5.1: The Kids Place parental control interface, showing options for managing apps, websites, and videos.

### 5.2.1 Setting Up Parental Controls

1. Open the **Kids Place** app.
2. Follow the on-screen instructions to create a profile for your child and set a PIN for parental access.
3. Within Kids Place settings, you can:
  - **Manage Apps:** Select which apps your child can access.
  - **Manage Websites:** Filter and approve websites.
  - **Set Time Limits:** Control daily usage duration.
  - **Advanced Security:** Prevent children from exiting Kids Place without the PIN.

### 5.2.2 Accessing Google Play Store

The tablet is GMS Certified, providing full access to the Google Play Store. Parents can download additional apps, games, videos, and music. Ensure parental controls are configured to manage access to downloaded content.

Video 5.1: An overview of the Contixo 7-inch Kids Learning Tablet V10+, demonstrating its features and educational content.

## 5.3 Using the Stylus

The included stylus is designed for children aged 3-10, offering an intuitive way to interact with the tablet for drawing, writing, and navigating apps. It helps develop fine motor skills and creativity.



Figure 5.2: A child using the stylus to draw on the Contixo Kids Tablet V10+ screen.

## 5.4 Kickstand Functionality

The integrated kickstand on the protective case allows for hands-free viewing, ideal for watching videos or participating in online learning sessions.

Video 5.2: A promotional video highlighting the features and benefits of the Contixo Kids Tablet, including its educational content and parental controls.

## 6. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen. For the case, a damp cloth can be used. Avoid harsh chemicals.
- **Storage:** Store the tablet in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the tablet frequently. Charge it regularly.
- **Software Updates:** Periodically check for system updates to ensure optimal performance and security.

## 7. TROUBLESHOOTING

### 7.1 Tablet Not Turning On

- Ensure the tablet is sufficiently charged. Connect it to the charger for at least 30 minutes before attempting to power it on again.
- Press and hold the Power Button for 10-15 seconds to perform a hard reset.

## 7.2 Slow Performance/Lagging

- Close unnecessary background applications.
- Clear cache data for frequently used apps.
- Ensure sufficient storage space is available. Uninstall unused apps or move media to a microSD card.
- Restart the tablet.

## 7.3 Battery Drains Quickly

- Reduce screen brightness.
- Disable Wi-Fi and Bluetooth when not in use.
- Close background apps that consume significant power.
- Limit streaming video or graphic-intensive games.

## 7.4 Screen Issues (e.g., unresponsive, lines)

- Restart the tablet.
- If the issue persists after a restart, contact customer support.

## 8. SPECIFICATIONS

Feature	Detail
Screen Size	7 Inches
Screen Resolution	1024x600 Pixels
Processor	1.5 GHz Quad Core Allwinner
RAM	2 GB
Internal Storage	32 GB
Expandable Storage	Up to 128 GB via MicroSD
Operating System	Android 10
Wireless Type	802.11a (Wi-Fi)
Average Battery Life	10 Hours (mixed use)
Item Weight	7.7 ounces
Product Dimensions	7.5 x 4.25 x 0.4 inches


## 9. WARRANTY AND SUPPORT

For warranty information or technical assistance, please refer to the official Contixo website or contact their customer support directly. Details are typically provided with your product packaging or on the manufacturer's

support pages.

© 2023 Contixo. All rights reserved.

## Related Documents - V10+

 User Manual for V8	<p><a href="#"><u>Contixo V8 Kids Tablet User Manual</u></a></p> <p>User manual for the Contixo V8 Kids Tablet, covering setup, features, Kids Place, connecting to a computer, factory reset, and troubleshooting. Learn how to use your Contixo V8 tablet safely and effectively.</p>
 V9-32 User Manual	<p><a href="#"><u>Contixo V9 Kids Tablet User Manual: Setup, Features, and Parental Controls</u></a></p> <p>This user manual provides comprehensive guidance for the Contixo V9 Kids Tablet, covering initial setup, hardware and software features, web browsing, Google services, the 'Kids Place' parental control system, and troubleshooting tips for an optimal child-friendly experience.</p>
 K81 USER MANUAL	<p><a href="#"><u>Contixo K81 Kids Tablet User Manual: Setup, Features, and Troubleshooting</u></a></p> <p>Comprehensive user manual for the Contixo K81 kids tablet, covering initial setup, hardware overview, software features like Google Kids Space and Family Link, troubleshooting, and product care. Learn how to set up and use your Contixo K81 tablet safely and effectively.</p>
 User Manual	<p><a href="#"><u>Contixo V8 Kids Tablet User Manual - Setup, Features, and Troubleshooting</u></a></p> <p>Comprehensive user manual for the Contixo V8 Kids Tablet. Covers initial setup, hardware overview, software features, navigation, camera, web browsing, Google Services, Family Link setup, connecting to a computer, factory reset, and troubleshooting. Learn how to use your Contixo tablet effectively.</p>
	<p><a href="#"><u>Contixo R1 Smart Voice-Controlled Robot User Guide</u></a></p> <p>Comprehensive guide to the Contixo R1 Smart Voice-Controlled Robot. Discover its interactive features, voice commands, theatrical modes, and operational instructions for optimal play and learning. Includes safety warnings and maintenance tips.</p>



### [Contixo Kids Tablet User Manual \(K2 & K3\) - Setup, Features, and Troubleshooting](#)

Comprehensive user manual for the Contixo Kids Tablet (Models K2 and K3, Versions V8 & V9) covering setup, hardware, software, product care, and troubleshooting. Learn how to get started and resolve common issues.