

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [zicBee](#) /

› User Manual: 10000 mAh MagSafe Power Bank for iPhone 15 14 13 12 Mini Pro Max Plus Portable Magnetic Wireless Charger Battery Pack; 22.5W PD Fast Charging USB-C iPhone, iPad, AirPods (Blue)

zicBee B09C5DXCZ6

User Manual: zicBee 10000 mAh MagSafe Power Bank

Model: B09C5DXCZ6

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your zicBee 10000 mAh MagSafe Power Bank. Please read this manual thoroughly before using the product and retain it for future reference.

The zicBee MagSafe Power Bank is a portable magnetic wireless charger designed for iPhone 15/14/13/12 Mini/Pro/Pro Max/Plus series, offering both wireless and wired fast charging capabilities for multiple devices simultaneously.

2. PRODUCT FEATURES

- **MagSafe Compatibility:** Designed for iPhone 15/14/13/12 Mini/Pro/Pro Max/Plus series with strong magnetic adsorption for fast wireless charging. Compatible with MagSafe-certified phone cases or without cases.
- **High Capacity:** Real capacity of 10000mAh.
- **Multi-Device Charging:** Can charge up to 3 devices simultaneously.
- **Fast Charging:**
 - Wireless: Supports 5W/7.5W/10W and 15W Max wireless charging.
 - Wired: 22.5W Max USB QC3.0 output and 20W USB-C PD3.0 input and output.
- **Advanced Protection:** Utilizes AI smart IC technology to prevent over-discharge, over-charge, over-temperature, short-circuit, and foreign object detection. UL standards compliant.
- **Digital Display:** Smart LED screen to check remaining battery capacity.
- **Portable Design:** Slim and light (0.4 lb) with double strong mag-suction (holds up to 700g). Designed not to scratch or block your phone camera.
- **Travel Friendly:** Able to be carried on airplanes.

3. WHAT'S IN THE BOX

- zicBee 10000 mAh MagSafe Power Bank (Blue)
- USB-C Charger Cable
- User Manual (this document)

4. PRODUCT OVERVIEW

Familiarize yourself with the components of your zicBee MagSafe Power Bank.



Figure 1: Power Bank Components (ON/OFF button, Type-C Input/Output, USB-A Output, LCD Digital Power Display)



Figure 2: MagSafe Power Bank in use with an iPhone.

5. SETUP

5.1 Initial Charging of the Power Bank

Before first use, fully charge your zicBee MagSafe Power Bank. Use the provided USB-C cable and connect it to a compatible USB-C power adapter (not included).

1. Connect the USB-C end of the cable to the Type-C port on the power bank.
2. Connect the other end of the cable to a USB-C power adapter.
3. The LCD digital display will show the charging progress. The power bank is fully charged when the display shows "100".

Figure 3: Charging the Power Bank via USB-C.

6. OPERATING INSTRUCTIONS

6.1 Wireless Charging (MagSafe Compatible Devices)

For iPhone 15/14/13/12 Mini/Pro/Pro Max/Plus series, the power bank offers magnetic wireless charging.

1. Ensure your iPhone is MagSafe compatible or has a MagSafe-compatible case.
2. Align the power bank with the back of your iPhone. The magnets will automatically snap into place, and charging will begin.
3. The power bank's strong magnetic adsorption ensures a secure connection.



Fast Mag-Safe Charger

Specials design to use with iPhone 12&13 series without mag-safe case.

- 10.000 mAh
- 15W Wireless Charger
- Strong Magnetic

Other model: Need mag-safe case to use magnetic wireless charger feature.
Only wireless charger: Support all Qi-Certified cellphones.

Figure 4: Magnetic Wireless Charging in action.

Strong Magnet Adsorption

Strong magnetic hold for a worry free charge



Figure 5: Demonstrating strong magnetic adsorption.

PHONE CASES FRIENDLY

(Thickness Under 3mm/0.12 in)



Metal objects



Credit card



Pop holder



✓ Magnetic Cases



✗ Non-Magnetic



Not compatible with non-magnetic phone cases!

Figure 6: Phone Case Compatibility for Wireless Charging.

Note: For optimal wireless charging, ensure your phone case is under 3mm (0.12 inches) thick and does not contain metal objects, credit cards, or pop holders, as these can interfere with magnetic charging.

For iPhone 12/13 series, the power bank is designed to not block the camera lens when attached.




Figure 7: Non-blocking camera design for iPhone 12/13 series.

6.2 Wired Charging (USB-C and USB-A)

The power bank supports wired charging for a wide range of devices using its USB-C and USB-A ports.

1. Connect your device's charging cable to either the USB-C (20W PD) or USB-A (22.5W QC3.0) output port on the power bank.
2. Connect the other end of the cable to your device.
3. Charging will begin automatically.

Charge Up To 3 Devices Simultaneously



iPhone 13 Mini/Pro/Pro Max

2.5 Charges



iPhone 12 Mini/Pro/Pro Max

3.0 Charges




Figure 8: Charging up to 3 devices simultaneously.

6.3 Checking Battery Level

The power bank features an LCD digital display that shows the remaining battery percentage.

1. Press the ON/OFF button once to activate the display and view the current battery percentage.



Figure 9: Digital Display showing battery level.

7. MAINTENANCE

- Keep the power bank dry and away from moisture.
- Do not expose to extreme temperatures (hot or cold).
- Clean the surface with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store in a cool, dry place when not in use for extended periods.
- Avoid dropping or subjecting the power bank to strong impacts.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging device wirelessly.	Device not MagSafe compatible or case is too thick/contains metal. Power bank battery is depleted. Improper alignment.	Ensure device/case is MagSafe compatible and free of obstructions. Recharge the power bank. Re-align the power bank and device.
Power bank not charging device via cable.	Cable is faulty or not fully connected. Power bank battery is depleted. Device is not compatible with charging output.	Try a different cable or ensure secure connection. Recharge the power bank. Verify device compatibility with USB-C PD or USB-A QC3.0.
Power bank gets hot during charging.	Normal operation for fast charging. Over-temperature protection activated.	Minor warmth is normal. If excessively hot, disconnect and allow to cool. The AI smart IC technology will automatically adjust current to control temperature.


Problem	Possible Cause	Solution
iPhone charging stops or is inconsistent (specific to iPhone).	iPhone's "Optimized Battery Charging" feature.	Go to iPhone Settings > Battery > Battery Health > and toggle off "Optimized Battery Charging". 

Figure 10: Disabling Optimized Battery Charging on iPhone.

9. SPECIFICATIONS

Feature	Detail
Model Number	B09C5DXCZ6
Battery Capacity	10000 mAh
Wireless Charging Output	5W / 7.5W / 10W / 15W Max
USB-C Input/Output	20W PD3.0
USB-A Output	22.5W QC3.0
Dimensions	4.3 x 2.6 x 0.6 inches
Weight	6.5 ounces
Battery Type	Lithium Polymer
Special Features	Digital Display, Auto Shut-Off, MagSafe Wireless Charging, Fast Charging

10. IMPORTANT SAFETY INFORMATION

- Do not disassemble or modify the power bank.
- Do not expose to fire or high temperatures.
- Keep out of reach of children.
- Do not use if the power bank is damaged or swollen.
- Dispose of the product responsibly according to local regulations.

11. OFFICIAL PRODUCT VIDEO

Watch the official product video for a visual guide on using your zicBee MagSafe Power Bank.

Your browser does not support the video tag.

Video: 10000mAh MagSafe Magnetic 15W Wireless Power Bank for iPhone. This video demonstrates the features and usage of the power bank, including magnetic attachment, wired charging, and portability.



© 2024 zicBee. All rights reserved.

For support, please visit the [zicBee Store on Amazon](#).