

[Manuals.plus](#) /

› [warmiplanet](#) /

› warmiplanet Ceiling Fans with Lights and Remote Control, Dimmable, 48-Inch, Black, Silent Motor, 3-Blades User Manual

warmiplanet WICF01-1

warmiplanet 48-Inch Ceiling Fan User Manual

Model: WICF01-1

INTRODUCTION

Thank you for choosing the warmiplanet 48-inch Ceiling Fan with Lights and Remote Control. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new ceiling fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.

SAFETY INFORMATION

To reduce the risk of electrical shock, fire, or personal injury, always follow these basic safety precautions:

- Read all instructions and safety information before installing your fan.
- All electrical work must be performed by a qualified, licensed electrician.
- Turn off power at the main circuit breaker box before beginning installation.
- Ensure the installation site is suitable for the fan's weight and size.
- Do not bend the blade holders when installing the blades, balancing the blades, or cleaning the fan.
- Never insert foreign objects between rotating fan blades.
- Use only replacement parts specified by the manufacturer.

PACKAGE CONTENTS

Carefully unpack your ceiling fan and check that all components are present and undamaged. Refer to the image below for a visual guide to the included parts.

Multi-function Handy Remote Control




Figure 1: All components included in the warmiplanet 48-inch Ceiling Fan package.

- Ceiling Fan Motor Assembly
- 3 Fan Blades (reversible, black/wood grain)
- LED Light Kit (24-watt, dimmable)
- Remote Control with Wall Bracket
- Mounting Bracket and Hardware
- Downrod
- Canopy
- Instruction Manual

SETUP AND INSTALLATION

Follow these steps to properly install your warmiplanet ceiling fan. For a visual guide, please refer to the installation video provided below.

Video 1: Official installation guide for the warmiplanet 48-inch ceiling fan. This video demonstrates each step of the assembly and mounting process.

Step 1: Install the Hanging Bracket

Secure the hanging bracket to your ceiling joist or an approved electrical junction box. Ensure it is firmly attached to support the fan's weight.



Figure 2: Installation of the hanging bracket, crucial for secure mounting.

Step 2: Assemble the Downrod and Motor

Feed the electrical wires from the motor through the downrod. Attach the downrod to the motor assembly, ensuring all screws are tightened securely.




Figure 3: Assembling the downrod and motor, ensuring proper wire routing.

Step 3: Hang the Fan and Make Electrical Connections

Carefully lift the fan assembly and hang it onto the installed bracket. Connect the electrical wires according to local electrical codes and the provided wiring diagram. Ensure all connections are secure and insulated.




Figure 4: Wiring connections for the ceiling fan, follow local electrical codes.

Step 4: Attach Fan Blades and Light Kit

Securely attach the fan blades to the motor housing. Install the LED light kit by connecting the wires and fastening the light cover. Ensure the light cover is properly seated and secured.



Figure 5: The fully assembled warmiplanet 48-inch Ceiling Fan.

OPERATING INSTRUCTIONS

Your warmiplanet ceiling fan comes with a multi-function remote control for convenient operation. Familiarize yourself with the remote's buttons and features.

Three Color Temperature

Three Color Light With Memory
Function Meet Your Needs



Uniform light



Low power consumption



Softened line of sight



Long lifespan

Warm

White

3000K

4000K

6000K



3000K
Warm Light



4000K
Natural Light



6000K
Cool White Light

Figure 6: Multi-function remote control for the warmiplanet ceiling fan.

Fan Speed Control

Use the speed buttons (Low, Med, High) on the remote to adjust the fan's airflow. The fan features a silent motor for quiet operation.



Figure 7: Three adjustable fan speeds for customized comfort.

LED Light Control

The fan includes a 24-watt dimmable LED light. Press the Light ON/OFF button to toggle the light. Continuously pressing the Light ON/OFF button will cycle through three color temperatures: Cool White (6000K), Natural Light (4000K), and Warm White (3000K). The light also has a memory function, retaining the last used color temperature.

Powerful and Mute Motor

Sound is less than 50dB when working
Noiseless Experience



Figure 8: The LED light offers three color temperature options.

Timer Function

Set a timer for the fan to automatically turn off after 1, 3, or 6 hours using the dedicated timer buttons on the remote.

Video 2: Demonstration of the warmiplanet 48-inch ceiling fan's features, including light and speed adjustments.

MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To avoid damage to the finish, clean the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Cleaning:** Dust the blades regularly to prevent dust buildup, which can affect airflow and balance.
- **Tightening Screws:** Periodically check all screws on the fan and mounting hardware to ensure they are tight. Loose screws can cause wobbling or noise.

TROUBLESHOOTING

If you encounter any issues with your ceiling fan, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low/dead	Check circuit breaker/wall switch; Verify all wire connections are secure; Replace remote control battery.
Fan wobbles	Loose blade screws; Improperly balanced blades; Loose mounting bracket	Tighten all blade screws; Use balancing kit (not included) to balance blades; Ensure mounting bracket is securely fastened.
Light does not work	Loose wire connection to light kit; Faulty LED module; Remote control issue	Check light kit wiring; Contact customer support for replacement LED module; Check remote battery/functionality.
Remote not responding	Battery low/dead; Remote not paired; Obstruction between remote and receiver	Replace battery; Refer to remote pairing instructions (if applicable); Remove any obstructions.

SPECIFICATIONS

Feature	Detail
Brand	warmiplanet
Model Name	WICF01-1
Color	48inch-Black-3Blades
Electric Fan Design	Ceiling Fan
Power Source	AC
Product Dimensions	48"D x 48"W x 13.9"H
Room Type	Indoor
Special Features	Remote Controlled, Adjustable Color Temperature, Timer, LED Light
Wattage	65.00 Watts
Number of Blades	3
Air Flow Capacity	3411 Cubic Feet Per Minute
Voltage	120 Volts
Light Type	LED
Blade Material	Wood
Item Weight	14.85 Pounds
UPC	795802475735

WARRANTY AND SUPPORT

warmiplanet stands behind the quality of its products.

- **Motor Warranty:** The motor of the ceiling fan is covered by a 10-year warranty. If the motor doesn't work, it can be replaced free of charge for up to 10 years.
- **Whole Fan Warranty:** The entire fan (excluding the motor) is covered by a 2-year warranty.
- **Customer Support:** If you have any questions or require assistance with installation or any other issues, please contact warmiplanet customer support. We aim to reply within 24 hours.